



OPERATOR'S MANUAL

Metal Working



VARIABLE SPEED VERTICAL BAND SAW MODEL: BSV-24VS-V2

Baileigh Industrial Holdings LLC

P.O. Box 531

Manitowoc, WI 54221-0531

Phone: 920.684.4990

Fax: 920.684.3944

Baileigh-Sales@jpwindustries.com

REPRODUCTION OF THIS MANUAL IN ANY FORM WITHOUT WRITTEN APPROVAL OF BAILEIGH INDUSTRIAL HOLDINGS LLC IS PROHIBITED. Baileigh Industrial Holdings LLC, Inc. does not assume and hereby disclaims any liability for any damage or loss caused by an omission or error in this Operator's Manual, resulting from accident, negligence, or other occurrence.

Rev. 03/2022

© 2021 Baileigh Industrial Holdings LLC



Table of Contents

THANK YOU & WARRANTY	1
INTRODUCTION.....	3
GENERAL NOTES.....	3
SAFETY INSTRUCTIONS	4
SAFETY PRECAUTIONS	6
Dear Valued Customer:.....	6
TECHNICAL SPECIFICATIONS	8
TECHNICAL SUPPORT	9
UNPACKING AND CHECKING CONTENTS.....	10
TRANSPORTING AND LIFTING	11
INSTALLATION.....	11
Anchoring the Machine.....	12
GETTING TO KNOW YOUR MACHINE	13
Control Panel.....	15
Fence Guide.....	18
ASSEMBLY AND SET UP	18
ELECTRICAL.....	19
BEFORE EACH USE	21
Whenever Saw is Running	21
Blade Terminology.....	22
Breaking in a Band Saw Blade	22
Metal Chip Indicators.....	23
BLADE CARE	23
Choosing A Saw Blade.....	23
Width of Blade	24
Length of Blade	24
BLADE BREAKAGE.....	24
MATERIAL SELECTION.....	25
SAW OPERATION.....	26
OPERATION OF BLADE WELDER	27
Overall Description	27
Preparing the Saw Band Prior to Welding	28
Preparing the Blade Welder.....	29
Making the Weld.....	29
Annealing the Weld	31
Grinding the Weld.....	31
SAW ADJUSTMENTS	32
Guide Post.....	32
Graduated Scales to Show Tilt of Table	32
Adjusting the Blade Guides	33
Blade Tension Adjustment Wheel.....	34
Changing a Blade	35
BLADE TRACKING.....	36



Regular Adjustment	36
LUBRICATION AND MAINTENANCE	38
Blade Shear Lubrication	39
Upper Wheel Housing Items.....	39
Table Support Lubrication	39
CABINET ASSEMBLY – BREAKDOWN.....	40
Cabinet Assembly – Part List.....	41
WORK TABLE ASSEMBLY – BREAKDOWN	42
Work Table Assembly – Part List.....	43
LOWER WHEEL SET ASSEMBLY – BREAKDOWN.....	44
Lower Wheel Set Assembly – Part List.....	45
GUIDEPOST ASSEMBLY – BREAKDOWN	46
Guidepost Assembly – Part List.....	47
UPPER WHEEL SET ASSEMBLY – BREAKDOWN	48
Upper Wheel Set Assembly – Part List.....	49
WELDER ASSEMBLY- BREAKDOWN.....	50
Welder Assembly – Part List	51
ELECTRICAL DIAGRAM	53
Electrical Diagram Part List	54



THANK YOU & WARRANTY

Thank you for your purchase of a machine from Baileigh Industrial Holdings LLC. We hope that you find it productive and useful to you for a long time to come.

Inspection & Acceptance. Buyer shall inspect all Goods within ten (10) days after receipt thereof. Buyer's payment shall constitute final acceptance of the Goods and shall act as a waiver of the Buyer's rights to inspect or reject the goods unless otherwise agreed. If Buyer rejects any merchandise, Buyer must first obtain a Returned Goods Authorization ("RGA") number before returning any goods to Seller. Goods returned without an RGA will be refused. Seller will not be responsible for any freight costs, damages to goods, or any other costs or liabilities pertaining to goods returned without a RGA. Seller shall have the right to substitute a conforming tender. Buyer will be responsible for all freight costs to and from Buyer and repackaging costs, if any, if Buyer refuses to accept shipment. If Goods are returned in unsalable condition, Buyer shall be responsible for full value of the Goods. Buyer may not return any special-order Goods. Any Goods returned hereunder shall be subject to a restocking fee equal to 30% of the invoice price.

Specifications. Seller may, at its option, make changes in the designs, specifications or components of the Goods to improve the safety of such Goods, or if in Seller's judgment, such changes will be beneficial to their operation or use. Buyer may not make any changes in the specifications for the Goods unless Seller approves of such changes in writing, in which event Seller may impose additional charges to implement such changes.

Limited Warranty. Seller warrants to the original end-user that the Goods manufactured or provided by Seller under this Agreement shall be free of defects in material or workmanship for a period of twelve (12) months from the date of purchase, provided that the Goods are installed, used, and maintained in accordance with any instruction manual or technical guidelines provided by the Seller or supplied with the Goods, if applicable. The original end-user must give written notice to Seller of any suspected defect in the Goods prior to the expiration of the warranty period. The original end-user must also obtain a RGA from Seller prior to returning any Goods to Seller for warranty service under this paragraph. Seller will not accept any responsibility for Goods returned without a RGA. The original end-user shall be responsible for all costs and expenses associated with returning the Goods to Seller for warranty service. In the event of a defect, Seller, at its sole option, shall repair or replace the defective Goods or refund to the original end-user the purchase price for such defective Goods. Goods are not eligible for replacement or return after a period of 10 days from date of receipt. The foregoing warranty is Seller's sole obligation, and the original end-user's exclusive remedy, with regard to any defective Goods. This limited warranty does not apply to: (a) die sets, tooling, and saw blades; (b) periodic or routine maintenance and setup, (c) repair or replacement of the Goods due to normal wear and tear, (d) defects or damage to the Goods resulting from misuse, abuse, neglect, or accidents, (e) defects or damage to the Goods resulting from improper or unauthorized alterations, modifications, or changes; and (f) any Goods that has not been installed and/or maintained in accordance with the instruction manual or technical guidelines provided by Seller.

EXCLUSION OF OTHER WARRANTIES. THE FOREGOING LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ANY AND ALL OTHER EXPRESS, STATUTORY OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED. NO WARRANTY IS MADE WHICH EXTENDS BEYOND THAT WHICH IS EXPRESSLY CONTAINED HEREIN.

Limitation of Liability. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY OTHER PARTY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR DOWN TIME) ARISING FROM OR IN MANNER CONNECTED WITH THE GOODS, ANY BREACH BY SELLER OR ITS AGENTS OF THIS AGREEMENT, OR ANY OTHER CAUSE WHATSOEVER, WHETHER BASED ON CONTRACT, TORT OR ANY OTHER THEORY OF LIABILITY. BUYER'S REMEDY WITH RESPECT TO ANY CLAIM ARISING UNDER THIS AGREEMENT IS STRICTLY LIMITED TO NO MORE THAN THE AMOUNT PAID BY THE BUYER FOR THE GOODS.



Force Majeure. Seller shall not be responsible for any delay in the delivery of, or failure to deliver, Goods due to causes beyond Seller's reasonable control including, without limitation, acts of God, acts of war or terrorism, enemy actions, hostilities, strikes, labor difficulties, embargoes, non-delivery or late delivery of materials, parts and equipment or transportation delays not caused by the fault of Seller, delays caused by civil authorities, governmental regulations or orders, fire, lightening, natural disasters or any other cause beyond Seller's reasonable control. In the event of any such delay, performance will be postponed by such length of time as may be reasonably necessary to compensate for the delay.

Installation. If Buyer purchases any Goods that require installation, Buyer shall, at its expense, make all arrangements and connections necessary to install and operate the Goods. Buyer shall install the Goods in accordance with any Seller instructions and shall indemnify Seller against any and all damages, demands, suits, causes of action, claims and expenses (including actual attorneys' fees and costs) arising directly or indirectly out of Buyer's failure to properly install the Goods.

Work By Others; Safety Devices. Unless agreed to in writing by Seller, Seller has no responsibility for labor or work performed by Buyer or others, of any nature, relating to design, manufacture, fabrication, use, installation or provision of Goods. Buyer is solely responsible for furnishing and requiring its employees and customers to use all safety devices, guards and safe operating procedures required by law and/or as set forth in manuals and instruction sheets furnished by Seller. Buyer is responsible for consulting all operator manuals, ANSI or comparable safety standards, OSHA regulations and other sources of safety standards and regulations applicable to the use and operation of the Goods.

Remedies. Each of the rights and remedies of Seller under this Agreement is cumulative and in addition to any other or further remedies provided under this Agreement or at law or equity.

Attorney's Fees. In the event legal action is necessary to recover monies due from Buyer or to enforce any provision of this Agreement, Buyer shall be liable to Seller for all costs and expenses associated therewith, including Seller's actual attorney fees and costs.

Governing Law/Venue. This Agreement shall be construed and governed under the laws of the State of Wisconsin, without application of conflict of law principles. Each party agrees that all actions or proceedings arising out of or in connection with this Agreement shall be commenced, tried, and litigated only in the state courts sitting in Manitowoc County, Wisconsin or the U.S. Federal Court for the Eastern District of Wisconsin. Each party waives any right it may have to assert the doctrine of "forum non conveniens" or to object to venue to the extent that any proceeding is brought in accordance with this section. Each party consents to and waives any objection to the exercise of personal jurisdiction over it by courts described in this section. Each party waives to the fullest extent permitted by applicable law the right to a trial by jury.

Summary of Return Policy.

- 10 Day acceptance period from date of delivery. Damage claims and order discrepancies will not be accepted after this time.
- You must obtain a Baileigh issued RGA number PRIOR to returning any materials.
- Returned materials must be received at Baileigh in new condition and in original packaging.
- Altered items are not eligible for return.
- Buyer is responsible for all shipping charges.
- A 30% re-stocking fee applies to all returns.

Baileigh Industrial Holdings LLC makes every effort to ensure that our posted specifications, images, pricing and product availability are as correct and timely as possible. We apologize for any discrepancies that may occur. Baileigh Industrial Holdings LLC reserves the right to make any and all changes deemed necessary in the course of business including but not limited to pricing, product specifications, quantities, and product availability.

For Customer Service & Technical Support:

Please contact one of our knowledgeable Sales and Service team members at:
(920) 684-4990 or e-mail us at Baileigh-Service@jpwindustries.com



INTRODUCTION

The quality and reliability of the components assembled on a Baileigh Industrial Holdings LLC machine guarantee near perfect functioning, free from problems, even under the most demanding working conditions. However, if a situation arises, refer to the manual first. If a solution cannot be found, contact the distributor where you purchased our product. Make sure you have the serial number and production year of the machine (stamped on the nameplate). For replacement parts refer to the assembly numbers on the parts list drawings.

Our technical staff will do their best to help you get your machine back in working order.

In this manual you will find: (when applicable)

- Safety procedures
- Correct installation guidelines
- Description of the functional parts of the machine
- Capacity charts
- Setup and start-up instructions
- Machine operation
- Scheduled maintenance
- Parts lists

GENERAL NOTES

After receiving your equipment remove the protective container. Do a complete visual inspection, and if damage is noted, **photograph it for insurance claims** and contact your carrier at once, requesting inspection. Also contact Baileigh Industrial Holdings LLC and inform them of the unexpected occurrence. Temporarily suspend installation.

Take necessary precautions while loading / unloading or moving the machine to avoid any injuries.

Your machine is designed and manufactured to work smoothly and efficiently. Following proper maintenance instructions will help ensure this. Try and use original spare parts, whenever possible, and most importantly; **DO NOT** overload the machine or make any modifications.




Note: *This symbol refers to useful information throughout the manual.*



IMPORTANT

PLEASE READ THIS OPERATORS MANUAL CAREFULLY

It contains important safety information, instructions, and necessary operating procedures. The continual observance of these procedures will help increase your production and extend the life of the equipment.



SAFETY INSTRUCTIONS

LEARN TO RECOGNIZE SAFETY INFORMATION

This is the safety alert symbol. When you see this symbol on your machine or in this manual, **BE ALERT TO THE POTENTIAL FOR PERSONAL INJURY!**



Follow recommended precautions and safe operating practices.

UNDERSTAND SIGNAL WORDS

A signal word – **DANGER**, **WARNING**, or **CAUTION** – is used with the safety alert symbol. **NOTICE**, which is not related to personal injury, is used without a symbol.

DANGER: Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING: Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION: Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE: Indicates a situation which, if not avoided, could result in property damage.

DANGER

WARNING

CAUTION

NOTICE




SAVE THESE INSTRUCTIONS.
Refer to them often and use them to instruct others.




PROTECT EYES

Wear safety glasses or suitable eye protection when working on or around machinery.




PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protective devices such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



DUST HAZARD

Wear appropriate dust mask. Dust created while using machinery can cause cancer, birth defects, and long-term respiratory damage. Be aware of the dust hazards associated with all types of materials.




CALIFORNIA PROPOSITION 65

WARNING: Cancer and Reproductive Harm.
www.P65Warnings.ca.gov



BEWARE OF CUT AND PINCH POINTS

Moving saw blade may result in loss of fingers or limb. **DO NOT** operate with guard removed. **Follow lockout/tagout procedures before servicing.**



EMERGENCY STOP BUTTON

In the event of incorrect operation or dangerous conditions, the machine can be stopped immediately by pressing the **E-STOP** button. Twist the emergency stop button clockwise (cw) to reset. Note: Resetting the E-Stop will not start the machine.





SAFETY PRECAUTIONS



Metal working can be dangerous if safe and proper operating procedures are not followed. As with all machinery, there are certain hazards involved with the operation of the product. Using the machine with respect and caution will considerably lessen the possibility of personal injury. However, if normal safety precautions are overlooked or ignored, personal injury to the operator may result.

Safety equipment such as guards, hold-downs, safety glasses, dust masks and hearing protection can reduce your potential for injury. But even the best guard will not make up for poor judgment, carelessness or inattention. **Always use common sense** and exercise **caution** in the workshop. If a procedure feels dangerous, don't try it.

REMEMBER: Your personal safety is your responsibility.



WARNING: FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS PERSONAL INJURY

Dear Valued Customer:

- All Baileigh machines should be used only for their intended use.
- Baileigh does not recommend or endorse making any modifications or alterations to a Baileigh machine. Modifications or alterations to a machine may pose a substantial risk of injury to the operator or others and may do substantial damage to the machine.
- Any modifications or alterations to a Baileigh machine will invalidate the machine's warranty.

PLEASE ENJOY YOUR BAILEIGH MACHINE!PLEASE ENJOY IT SAFELY!

1. **FOR YOUR OWN SAFETY, READ INSTRUCTION MANUAL BEFORE OPERATING THE MACHINE.** Learn the machine's application and limitations as well as the specific hazards.
2. **Only trained and qualified personnel can operate this machine.**
3. **Make sure guards are in place and in proper working order before operating machinery.**
4. **Remove any adjusting tools.** Before operating the machine, make sure any adjusting tools have been removed.
5. **Keep work area clean.** Cluttered areas invite injuries.
6. **Overloading machine.** By overloading the machine, you may cause injury from flying parts. **DO NOT** exceed the specified machine capacities.
7. **DO NOT** bypass or defeat any safety interlock systems.
8. **Dressing material edges.** Always chamfer and deburr all sharp edges.



9. **Do not force tool.** Your machine will do a better and safer job if used as intended. **DO NOT** use inappropriate attachments in an attempt to exceed the machine's rated capacity.
10. **Use the right tool for the job. DO NOT** attempt to force a small tool or attachment to do the work of a large industrial tool. **DO NOT** use a tool for a purpose for which it was not intended.
11. **Dress appropriately. DO NOT** wear loose fitting clothing or jewelry as they can be caught in moving machine parts. Protective clothing and steel toe shoes are recommended when using machinery. Wear a restrictive hair covering to contain long hair.
12. **Use eye protection.** Always wear ISO approved protective eye wear when operating machinery. Wear a full-face shield if you are producing metal filings. Eye wear shall be impact resistant, protective safety glasses with side shields which comply with ANSI Z87.1 specification. Use of eye wear which does not comply with ANSI Z87.1 specification could result in severe injury from breakage of eye protection.
13. **Do not overreach.** Maintain proper footing and balance at all times. **DO NOT** reach over or across a running machine.
14. **Stay alert.** Watch what you are doing and use common sense. **DO NOT** operate any tool or machine when you are tired.
15. **Check for damaged parts.** Before using any tool or machine, carefully check any part that appears damaged. Check for alignment and binding of moving parts that may affect proper machine operation.
16. **Observe work area conditions. DO NOT** use machines or power tools in damp or wet locations. Do not expose to rain. Keep work area well lighted. **DO NOT** use electrically powered tools in the presence of flammable gases or liquids.
17. **Blade adjustments and maintenance.** Always keep blades sharp and properly adjusted for optimum performance.
18. **Keep children away.** Children must never be allowed in the work area. **DO NOT** let them handle machines, tools, or extension cords.
19. Keep visitors a safe distance from the work area.
20. **Store idle equipment.** When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep them out of reach of children.
21. **DO NOT operate machine if under the influence of alcohol or drugs.** Read warning labels on prescriptions. If there is any doubt, **DO NOT** operate the machine.
22. **Turn off** power before checking, cleaning, or replacing any parts.
23. Be sure **all** equipment is properly installed and grounded according to national, state, and local codes.
24. Keep **all** cords dry, free from grease and oil, and protected from sparks and hot metal.
25. Inspect power and control cables periodically. Replace if damaged or bare wires are exposed. **Bare wiring can kill! DO NOT** touch live electrical components or parts.



TECHNICAL SPECIFICATIONS

<u>Model No.</u>	<u>BSV-24VS-V2</u>
<u>Electrical</u>	
Power Supply	230V, 3ph, 60Hz
Main Drive Motor	3HP (2.2kw), 230V, 9.8A, 6P, 3Ph, 60Hz
Grinder Motor	1/8HP/ 230V, 1ph
Welding Type / Transformer	Butt Welder / 4.2KVA
Weld Capacity (Width)	.118" – .625" (3 – 16mm)
Speed Meter	DM94C
Work Lamp	LED Lamp 220V 9W
Inverter	3HP/ 230V /3ph RM6 RHYMEBUS
Power Cord	14WAG X4C 2.08MM X4C 105°C/ 300VAC UL
<u>Capacity</u>	
Blade Speed	Variable Speed
Cutting Capacity (Height)	12.2" (310mm)
Throat Depth	23.62" (600mm)
Blade Width (Min-Max.)	0.12" – 0.63" (3 – 16mm)
Blade Thickness	.025" (0.64mm)
Blade Length (Min-Max.)	177.95" – 179.13" (4520 – 4550mm)
Standard Machine Blade (included)	0.511" (13mm) 14T
Blade Speed	85 – 2200 FPM
Table Tilt	15° L & 45° R
Table Height	36.22" (920mm)
Table Area	24.4" x 24.4" (620 x 620mm)
Blade Wheel Dimension	24.4" (620mm)
<u>Packing</u>	
Net Weight	935lbs (425kgs)
Gross Weight	1031lbs (469kgs)
Machine Overall Dimension (LxHxW)	451.18" x 77.95" x 33.07" (1300 x 1980 x 840mm)
Packaging Overall Dimension (LxHxW)	53.54" x 85.43" x 33.46" (1360 x 2170 x 850mm)



TECHNICAL SUPPORT

Our technical support department can be reached at 920.684.4990 and asking for the support desk for purchased machines. Tech Support handles questions on machine setup, schematics, warranty issues, and individual parts needs: (other than die sets and blades).

For specific application needs or future machine purchases contact the Sales Department at: Baileigh-Service@jpwindustries.com, Phone: 920.684.4990, or Fax: 920.684.3944.



Note: *The photos and illustrations used in this manual are representative only and may not depict the actual color, labeling or accessories and may be intended to illustrate technique only.*



Note: *The specifications and dimensions presented here are subject to change without prior notice due to improvements of our products.*



UNPACKING AND CHECKING CONTENTS

Your Baileigh machine is shipped complete. Separate all parts from the packing material and check each item carefully. Make certain all items are accounted for before discarding any packing material.

⚠ WARNING: SUFFOCATION HAZARD! Immediately discard any plastic bags and packing materials to eliminate choking and suffocation hazards to children and animals.
If any parts are missing, **DO NOT** place the machine into service until the missing parts are obtained and installed correctly.

Cleaning

⚠ WARNING: DO NOT USE gasoline or other petroleum products to clean the machine. They have low flash points and can explode or cause fire.

⚠ CAUTION: When using cleaning solvents work in a well-ventilated area. Many cleaning solvents are toxic if inhaled.

Your machine may be shipped with a rustproof waxy coating and/or grease on the exposed unpainted metal surfaces. Fully and completely remove this protective coating using a degreaser or solvent cleaner. Moving items will need to be moved along their travel path to allow for cleaning the entire surface. For a more thorough cleaning, some parts will occasionally have to be removed. **DO NOT USE** acetone or brake cleaner as they may damage painted surfaces.

Follow manufacturer's label instructions when using any type of cleaning product. After cleaning, wipe unpainted metal surfaces with a light coating of quality oil or grease for protection.



Important: This waxy coating is **NOT** a lubricant and will cause the machine to stick and lose performance as the coating continues to dry.






TRANSPORTING AND LIFTING

NOTICE: *Lifting and carrying operations should be carried out by skilled workers, such as a truck operator, crane operator, etc. If a crane is used to lift the machine, attach the lifting chain carefully, making sure the machine is well balanced.*

Follow these guidelines when lifting with truck or trolley:

- The lift truck must be able to lift at least 1.5 – 2 times the machines gross weight.
- Make sure the machine is balanced. While transporting, avoid rough or jerky motion, and maintain a safe clearance zone around the transport area.
- Use a forklift with sufficient lifting capacity and forks that are long enough to reach the complete width of the machine.
- Remove the securing bolts that attach the machine to the pallet.
- Approaching the machine from the side, lift the machine on the frame taking care that there are no cables or pipes in the area of the forks.
- Move the machine to the required position and lower gently to the floor.
- Level the machine so that all the supporting feet are taking the weight of the machine and no rocking is taking place.



INSTALLATION

IMPORTANT:

Consider the following when looking for a suitable location to place the machine:


- Overall weight of the machine.
- Weight of material being processed.
- Sizes of material to be processed through the machine.
- Space needed for auxiliary stands, worktables, or other machinery.
- Clearance from walls and other obstacles.
- Maintain an adequate working area around the machine for safety.
- Have the work area well illuminated with proper lighting.
- Keep the floor free of oil and make sure it is not slippery.



- Remove scrap and waste materials regularly, and make sure the work area is free from obstructing objects.
- If long lengths of material are to be fed into the machine, make sure that they will not extend into any aisles.
- **LEVELING:** The machine should be sited on a level, concrete floor. Provisions for securing it should be in position prior to placing the machine. The accuracy of any machine depends on the precise placement of it to the mounting surface.
- **FLOOR:** This machine distributes a large amount of weight over a small area. Make certain that the floor is capable of supporting the weight of the machine, work stock, and the operator. The floor should also be a level surface. If the unit wobbles or rocks once in place, be sure to eliminate by using shims.
- **WORKING CLEARANCES:** Take into consideration the size of the material to be processed. Make sure that you allow enough space for you to operate the machine freely.
- **POWER SUPPLY PLACEMENT:** The power supply should be located close enough to the machine so that the power cord is not in an area where it would cause a tripping hazard. Be sure to observe all electrical codes if installing new circuits and/or outlets.

Anchoring the Machine

- Once positioned, anchor the machine to the floor, as shown in the diagram. Use bolts and expansion plugs or sunken tie rods that connect through and are sized for the holes in the base of the stand.
- This machine requires a solid floor such as concrete at a minimum of 4" (102mm) thick. 6" (153mm) minimum is preferred.





GETTING TO KNOW YOUR MACHINE





Item	Description	Function
A	Power Cord	Verify machine power requirements before making connections. Verify 110V or 220V
B	Grinder	Grinds welded area of blade back to original material thickness.
C	Blade Welding Station	Welds blade together.
D	Blade Shear	Trims end of blade square prior to welding
E	Emergency Stop Switch	Removes power to the operating controls and stops operation.
F	Start / Stop Control	Push buttons to start and run the saw blade and stop the saw blade when the cut is complete.
G	Variable Speed Hand Wheel	Changes the speed of the saw blade. Used while the machine is running.
H	Speed Display	Displays the speed of the blade in MPM (Meters Per Minute).
J	Upper Access Door	Houses the upper pulley, and tensioner.
K	Guide Post Tension Knob (not visible in this view)	Located on the back side of the upper wheel housing, use this to loosen the guide post for adjustment.
L	Guide Post Adjustment Knob	Use to raise or lower the guide post to provide minimum clearance to the work piece.
M	Work Lamp	Provide additional light to the cut area.
N	Blade Tension Adjustment	Turn to increase or decrease blade tension.
O	Fence	Sets a specific and repeatable distance for cutting material to a specific width.
P	Air Tube	Provide air to the work site to blow chip away from cut area.
Q	Upper Blade Guide	Holds the blade in position and minimizes blade twist.
R	Work Table	Supports material and provide several ways to control angle cuts.
S	Table Tilt	Trunions used to allow the table to tilt up to 15° left or right.
T	Lower Blade Access Door	Houses the drive pulley.
	Miter Gauge (not shown)	Sets a specific and repeatable angle for cutting material.



Control Panel

A DRO Indicator. Displays the speed of the blade in FPM (Feet Per Minute).

B Speed Control. This potentiometer will vary the input signal to the VFD which in turn will vary the frequency output to the motor thus controlling the speed of the motor and then the blade.

C Power Indicator Lamp. The power indicator lamp will illuminate when the key switch is turned to the ON position.


D Key Switch. The key switch powers the operating controls On to allow either cutting or welding.

E Function Selector Switch. This selector switch provides for one operation at a time. In the Left position, the welder will be active. In the Right position, the saw will be active.

F On Push Button. Press this button to start and run the blade when operating conditions are safe for the blade to move. Make sure the blade is rotating downward towards the work table.

G Stop Push Button. Press this button to stop the blade any time that the operator is not directly and actively engaged in a cutting operation.

H Emergency Stop Button (E-Stop). In the event of incorrect operation or dangerous conditions, the machine can be stopped immediately by pressing the **E-STOP** button. Twist the emergency stop button clockwise (cw) to reset. **Note:** Resetting the E-Stop will not start the machine.





Blade Shear

The blade shear is attached to the saw frame, just left and up from the saw band weld station.

It will cut saw bands ranging in width from 0.062" to 1" (1.6mm to 25.4mm) and thickness of 0.025" to 0.035" (0.63mm to 0.89mm).

Weld Station


J Welder Controls. The Dial is used to set the pressure or force used to press the ends of the blade together.

Press and hold the Green push button to complete the weld. Press and hold the Red push button to Anneal the weld.

K Weld Jaws / Electrodes. The weld jaws clamp and hold the blade in position during the weld. The left jaw moves toward the right using the Pressure Dial.

Both jaws are the electrodes which transfer the electrical current to the blade material being welded to create the weld puddle (melted metal) which will flow together to melt the end together as one piece.

L Grinder Switch. Toggle the switch to the ON position to start and run the grinding wheel. Grind the blade to remove rough spots and create a smooth surface without making the area thinner than the rest of the blade.





Lower Wheel Housing

The lower wheel housing has the lower wheel (drive wheel), the debris brush, and the debris tray.

- The lower wheel is the drive wheel which is connected via a shaft to the drive sheave and thus the motor through the drive belt.
- The brush is used to help control / remove chips and metal fillings from getting between the blade and wheel. Keep it clean and adjust as it wears. The bristles should have a slight pressure against the pulley at all times.
- The debris tray will collect larger chips and metal fillings. The tray will slide out and back in for regular cleaning.



Tilting Work Table



The work table may be tilted from 15° to 45°. The outboard side of the table will lift to create a 15° angle or lowered to a 45° angle.

Tilting the table is done on the back side of the saw. Just under and forward of the degree scale is the clamping nut. Loosen the nut, tilt the table to the desired angle and tighten the nut to hold the angle.



Upper and Lower Blade Guides

The blade guides provide side-to-side and back support for keeping the blade straight while cutting material. The blade guides are tungsten steel where they come in contact with the blade to reduce wear on the guides. The guides must be kept properly adjusted for accurate cuts.





Fence Guide

A fence guide is provided with this saw to aid in precise cut lengths and repeat cuts.



ASSEMBLY AND SET UP

⚠ WARNING: For your own safety, **DO NOT** connect the machine to the power source until the machine is completely assembled and you read and understand the entire instruction manual.

Fence Installation

- Remove and retain the two hex head cap screws installed into the front work table edge.
- Position the fence mounting bar onto the front edge of the work table and install and tighten the two hex head cap screws.
- Install the fence by setting the clamping body over the fence rail with the clamping handle lifted.
- Slide the fence left or right as needed and press down on the lock handle with just enough force to hold the fence in position.





ELECTRICAL

⚠ WARNING: Baileigh Industrial Holdings LLC is not responsible for any damage caused by wiring up to an alternative 3-phase power source other than direct 3-phase. If you are using an alternate power source, consult a certified electrician or contact Baileigh Industrial Holdings LLC prior to energizing the machine.

⚠ CAUTION: HAVE ELECTRICAL UTILITIES CONNECTED TO MACHINE BY A CERTIFIED ELECTRICIAN!
Check if the available power supply is the same as listed on the machine nameplate.

⚠ WARNING: Make sure the grounding wire (green) is properly connected to avoid electric shock. DO NOT switch the position of the green grounding wire if any electrical plug wires are switched during hookup.

Power Specifications

Your machine is wired for 230 volts, 60hz alternating current. Verify the input power supply before making any electrical connections. Before connecting the machine to the power source, make sure the power source is OFF.

Before switching on the power, you must check the voltage and frequency of the power to see if they meet with the requirement, the allowed range for the voltage is $\pm 5\%$, and for the frequency is $\pm 1\%$.

Considerations

- Observe local electrical codes when connecting the machine.
- The circuit should be protected with a time delay fuse or circuit breaker with an amperage rating slightly higher than the full load current of machine.
- A separate electrical circuit should be used for your machines. Before connecting the motor to the power line, make sure the switch is in the "OFF" position and be sure that the electric current is of the same characteristics as indicated on the machine.
- All line connections should make good contact. Running on low voltage will damage the motor.
- In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This machine is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.



⚠ WARNING: In all cases, make certain the receptacle in question is properly grounded. If you are not sure, have a qualified electrician check the receptacle.

- Improper connection of the equipment-grounding conductor can result in risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.
- Check with qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the machine is properly grounded.
- Repair or replace damaged or worn cord immediately.

Power cord connection:

1. Turn the main disconnect switch on the control panel to the OFF position.
2. Unwrap the power cord and route the cord away from the machine toward the power supply.
 - a. Route the power cord so that it will NOT become entangled in the machine in any way.
 - b. Route the cord to the power supply in a way that does NOT create a trip hazard.
3. Connect the power cord to the power supply and check that the power cord has not been damaged during installation.
4. When the machine is clear of any obstruction. The main power switch may be turn ON to test the operation.
5. Turn the switch OFF when the machine is not in operation.



BEFORE EACH USE


- For dusty operations, wear a face shield along with safety goggles.
- It is important to choose the right blade for the material and the type of cutting you plan to do. This saw is equipped with a bi-metallic blade which can be used to cut stainless steel, steel, iron, brass, aluminum, wood, plastic.
- Make sure the direction of rotation arrow on the blade matches the direction arrow on the saw. The blade teeth should always point downward at the front of the saw.
- Make sure the blade is sharp, undamaged and properly aligned. With the saw unplugged, push the power-head all the way down. Rotate the blade by hand checking for clearance. If the blade hits anything, make the adjustments shown in the Maintaining Maximum Cutting Capacity section.
- Never cut freehand.
- Make sure the cut-off piece can move sideways after it is cut off. Otherwise, it could get wedged against the blade and thrown violently.
- Never turn the saw "ON" before clearing everything except the work piece beneath the blade.
- Never put lubricants on the blade while it is spinning.

Whenever Saw is Running

- Never confine the piece being cut out.
- Never hold it, clamp it, touch it, or use length stops against it. It must be free to move sideways. If confined, it could get wedged against the blade and thrown violently.
- Avoid awkward hand positions where a sudden slip could cause a hand to move into the blade.
- Let the blade reach full speed before cutting.
- Feed the saw into the work piece only fast enough to let the blade cut without bogging down or binding.
- Before freeing jammed material, turn the switch off and unplug the saw. Wait for all moving parts to stop.
- After finishing a cut, keep holding the saw bow down, release the switch, and wait for all moving parts to stop before moving your hands.



Blade Terminology



A	BLADE WIDTH	The widest part of the blade measured from the back edge of the blade to the tip of the tooth.
B	GULLET DEPTH	The distance from the tooth tip to the bottom of the curved area.
C	TOOTH RAKE	The angle of the tooth face from a line perpendicular to the length of the blade.
D	BLADE BACK	The distance between the back edge of the blade and the bottom of the gullet.
E	TOOTH PITCH	The distance between tooth tips.
F	TPI	The number of teeth per inch when measured from gullet to gullet.
G	GAUGE	The thickness of the blade.
H	TOOTH SET	The distance a tooth is bent from the blade.
I	KERF	The width of material that is removed by the blade when cutting.

Breaking in a Band Saw Blade

Sharp cutting edges with extremely small edge radii are required for high cutting capacity. To achieve the optimal tool life we recommend breaking-in the blade accordingly. The correct cutting speed is determined by the material being cut and its dimensions. It is very important that the new blade is first used with only 50% of the determined feed rate. This will avoid micro-breakages of the blade because of too large chip thicknesses. New band saw blades may tend toward vibrations and vibration sounds. In this case a slight reduction of the cutting speed is helpful. With small workpiece dimensions approximately 300cm² of the material should be cut for breaking-in. If large work piece dimensions are to be cut we recommend a breaking-in period of about 15 minutes. After breaking-in you may slowly increase the feed rate up to the determined value.



Metal Chip Indicators

Chips are the best indicator of correct material feed force. Monitor chip information and adjust feed accordingly.

- Thin or Powdered Chips – increase feed rate or reduce saw speed
- Burned Chips – reduce feed rate and / or saw speed
- Curly Silvery and Warm Chips – optimum feed rate and saw speed

Baileigh Industrial offers a wide selection of tooth styles for various cutting applications. Please phone Baileigh Industrial at (920.684.4990) or fax to (920.684.3944) to have one of our technicians assist you in selecting the proper band saw blade for your cutting applications.

BLADE CARE

The bandsaw blade is subjected to a tremendous amount of strain. Make sure to always use the appropriate feed rate for the type material you are cutting.

Be sure to select a blade of the proper width, style, and pitch that will produce the best cut in your material. Choosing the wrong blade can produce excess heat that can adversely affect the life of the blade.

A clean blade performs much better than one that is dirty. Blades that are gummed up and dirty offer more resistance when cutting through the material. This in turn creates unnecessary heat in the blade.

Choosing A Saw Blade

A general-purpose blade is furnished with this band saw.

To achieve a quality, economical, and efficient saw cut, the following points must be taken into consideration:

- Type of material being cut (ferrous or non ferrous)
- Material hardness and physical dimensions
- Blade descent rate
- Longitudinal speed of blade
- Blade tooth profile



Choose a tooth pitch that is suitable for the workpiece. Thin walled profiles, including tubes and pipes require close toothing. At least 3-6 teeth should be in contact with the material while cutting. Large solid or transverse sections require widely spaced toothing to allow for greater volume of chips and better tooth penetration. Soft materials such as plastics, light alloys, mild bronze, Teflon, etc. require widely spaced toothing to avoid clogging.

Width of Blade

The blade width determines the largest and the smallest curve that can be cut. Usually the wider a blade is, the more accurate and straighter it will cut.

Length of Blade

The length of the band saw blade can be measured with a tape measure at its circumference or by the formula below:

$$\text{Blade Length} = (2 \times A) + (3.14 \times B)$$

A = the distance in inches between the band saw pulley centers (when the upper pulley is midway in its adjustment range).

B = the band saw pulley diameter.

BLADE BREAKAGE

In some cases, blade breakage is unavoidable due to the stresses that are imparted on the blade. Avoidable breakage is often the result of poor care, or poor operator judgment when it comes to adjusting or mounting the blade or blade guides.

Listed below are some of the more common reasons for blade breakage.

- Top blade guide assembly is set too high above the piece part.
- The blade is tensioned incorrectly.
- Piece part is fed into the blade too quickly.
- Blade teeth are dull or broken.
- Blade is not properly aligned with the guides.
- Forcing a large width blade to cut a small radius.
- Using a blade with an improperly finished weld joint.
- Allowing the blade to run when not in use. (**NEVER** leave an unattended blade running.)



MATERIAL SELECTION

⚠ CAUTION: It must be determined by the customer that materials being processed through the machine are **NOT** potentially hazardous to operator or personnel working nearby.

When selecting materials keep these instructions in mind:

- Material must be clean and dry. (without oil)
- Material should have a smooth surface, so it processes easily.
- Dimensional properties of material must be consistent and not exceed the machine capacity values.
- Chemical structure of material must be consistent.
- Buy certificated steel from the same vendor when possible.



SAW OPERATION

⚠ CAUTION: Always wear proper eye protection operating the saw. The bandsaw blade is sharp and will cut fingers and hands. Keep hands and fingers clear of the blade. Use a block of wood as a pusher for the material being cut. It is recommended to always wear leather gloves when working near the blade.

1. Verify the work area including the table is clear of obstructions.
2. Set the guide post (**A**) to approximately .25" (6.35mm) above the piece part and tighten the guide post knob.
3. Set the table and if being used, the fence as needed to complete the cut. Have a push block within reach without crossing the blade path or vision of the cut area. Simulating the cut without power may be helpful.
4. Set the work lamp position to provide additional light at the cut site without interfering with the material or the ability to maintain control of the material for the entire cut.
5. Have proper support for the material to be cut. This should include both the finished piece and the excess material.
6. Press the start button to energize the motor starting the blade. The saw blade should now be moving. If any abnormal sounds or vibrations are noticed, press the red stop button immediately.
7. Adjust the variable speed (**B**) until the desired speed is indicated on the speed display.
8. Carefully place the material on the table.
9. When positioned, feed the material into the blade using a steady smooth motion.
10. When the cut is complete, press the red stop button on the control panel and wait until the blade stops before removing any material near the blade.





OPERATION OF BLADE WELDER

Overall Description

⚠ CAUTION: The bandsaw blade is sharp and can cut your hand or fingers. Always disconnect power to the saw and wear leather gloves when working near the blade.

The weld station on the Baileigh band saw can butt weld and anneal blades from 0.118" (3mm) to 0.625" (16mm) wide by 0.032" (0.8mm) thick. It is a resistance type welder with two jaws that secure the blade ends during the welding process. A selector knob is turned counterclockwise (**ccw**) to pre-load the left jaw, forcing the blade ends against one another. When the operator presses the weld button, electric current passes through the butted blade ends. The left jaw blade end is pushed into the molten puddle and welded to the right blade end. Remove the blade from the jaws if any weld flash is present and carefully grind it off. The blade joint must now be placed back into the jaws where annealing of the weld joint takes place. This procedure will reheat the weld area so it is not so brittle and should return it to its original condition.

It may become necessary to weld blades when:

- They break unexpectedly and the teeth are still sharp enough to cut.
- You need to make blades from a bulk saw blade coil.
- When you need to weld a blade that was cut to make an internal contour cut on a piece part.



Preparing the Saw Band Prior to Welding

⚠ CAUTION: Shear Hazard – Keep Hands From Under Blade.


Blade Cutter To cut the band apart or to cut the band to a specified length, use the blade shear. The shear is capable of cutting saw bands from 0.118" to .625" (3mm to 16mm) in width and 0.025" to 0.035" (0.63mm to 0.89mm) in thickness. To use the blade cutter, raise the handle, lay between the blades perpendicular to the cutting knife, and make the cut.

If the saw band is not square after shearing, use the grinding wheel to square it up. Take small cuts so as not to overheat the blade band. To get both ends of the band to match perfectly, twist it and hold the ends so that the teeth are on opposite sides and pointing in opposite directions. Now grind as shown below.




Tooth Spacing on Blade Band Occasionally one or more teeth may have to be ground off on either side of the cut to ensure blade tooth uniformity.

Good Weld



Poor Weld






Preparing the Blade Welder

⚠ WARNING: The electrical current that flows through the blade welder when operating could cause Serious Personal Injury or Death. To avoid the risk of electrocution, never touch any metal part of the weld station during welding or annealing of the blade.

1. Make sure the jaws of the welder are clean to make good electrical contact.
2. Check that the jaws will adequately hold the thickness of blade you are using.
3. The left jaw should slide easily when turning the weld force selector knob.
4. Check over the grinding wheel and make sure it is in good condition.

Making the Weld


1. Before making a weld, turn off the band saw motor by pressing the red “stop” button.
2. Turn the weld pressure selector knob clockwise (cw) to the “0” position.
3. After squaring the ends of the blade, insert the spine edge of the blade into each jaw butting the cut ends together and centered between the jaws.
4. Secure the blade by raising the handles. Check that the blade ends fit together with no gap. If a gap is noticed, remove and re-square the blade.
5. Turn the weld force selector knob from “0” to the third marker. This would be for a 0.25” (6.3mm wide blade. (Every 2mm of blade width = 1 marker approx.). this applies pressure to hold the ends of the blade together.






⚠ WARNING: Sparks from the blade welding operation can be thrown in all directions and can cause serious personal injury or fire. When using the blade welder, always protect yourself and others from flying sparks. Keep fire extinguisher equipment close by and **DO NOT** weld near flammables.

6. Press and hold the green weld button until the left jaw blade end is pushed into the molten puddle and welded to the right blade end. As soon as the left jaw moves into the right jaw, release the green weld button. Electric current passes through the butted blade ends. The left jaw blade end is pushed into the molten puddle and welded to the right blade end. Inspect the weld carefully after removing from the welder.
7. If you see what appears to be an excessive amount of flashing you can try backing off on the weld force setting.



Check blade band misalignment with a straight edge







Annealing the Weld

⚠ CAUTION: The bandsaw blade is sharp and can cut your hand or fingers. Heat from the welding and annealing process can cause severe burns. Always wear leather gloves when working near the blade.

1. When a saw band is butt welded, the site of the weld “air hardens” and will become brittle. To return the metal to its approximate original state it must be gradually heated and cooled several times called annealing.
2. Turn the weld force selector knob to “0”.
3. Clamp the saw band in the jaws making sure to carefully center the weld. It is still brittle.
4. Press the red annealing button quickly with a few short bursts to make the weld area a dull orangish-red. (The wider the blade, the more bursts and time it will take.) After reaching a dull orangish-red, allow the area to cool 15-30 seconds and then repeat the heat twice more. **Too much heat can damage the temper or burn through and destroy the weld.**
5. After welding and tempering the blade, test the strength and flexibility of the saw band by bending it in an arc similar to the pulley on the saw.



Bend Like This



Not Like This

Grinding the Weld

⚠ CAUTION: The bandsaw blade is sharp and can cut your hand or fingers. Keep hands and fingers away from rotating grinding wheel. Wear proper eye protection. Always wear leather gloves when working near the blade.

1. The grinding wheel is used for both preparing the saw band for welding and removing flash after annealing. Flash must be removed from both sides of the weld to maintain the blades actual thickness. This will then allow the blade to pass through the guides without any obstructions.
2. **DO NOT** burn or overheat the weld area when grinding.



SAW ADJUSTMENTS


Guide Post

The guide post assembly serves two purposes.

- First, it positions the orange blade guard between the piece part and the upper pulley housing to protect the operator from the exposed blade.
- Second, it positions the upper blade guides close to the piece part for support of the blade.

To properly position the guide post:


1. DISCONNECT POWER FROM THE BANDSAW.
2. Loosen the guide post knob (A).
3. Use the handwheel (B) to lower or raise the guide post.
4. Locate the bottom of the blade guides .25" (6.35mm) above the piece part and tighten the guide post knob to hold it securely.



Graduated Scales to Show Tilt of Table

The table can be tilted either forward or back and left or right, or in combination.

It can be tilted 15° left and 45° right. For left and right tilting, the table has a scale to indicate the tilt angle.






Adjusting the Blade Guides

1. DISCONNECT POWER FROM THE BAND SAW.
2. Check to make sure the guide post is secure, and the blade has been properly tensioned.
3. Using a 5mm hex wrench you need to loosen the socket cap screws "A" and "B".
4. Slide the blade guide bracket so the blade guides are approximately 0.06" (1.58mm) behind the tooth gullets as shown. Tighten socket cap screw "A" only.



Note: The blade guides need to be adjusted far enough back so they are behind the tooth gullets when the blade is pushed back against the blade support.



5. With socket capscrew "B" still loose, slide the blade support rod up to, but not touching the back end of the blade. Re-tighten socket capscrew "B".
6. Next the blade needs to be centered between the blade guides. To do this, first loosen the socket capscrews "C" using a 5mm hex wrench. Now slide a piece of copy machine paper or a dollar bill between each side of the blade guide and the blade. Either of them should be 0.004" (0.1mm) thick. Gently pinch the paper between the blade guides and the blade. Now tighten each socket capscrew "C". (Check the position of the air nozzle). The guides should now be positioned correctly without touching the blade.



Note: Over time the blade inserts will wear. When this happens, flip over and reverse the guides. If the blade wears a groove into the blade support, loosen and rotate it to a new spot.




Blade Tension Adjustment Wheel

Without proper tension a bandsaw blade cannot deliver the necessary cutting efficiency. Not enough tension can lead to blade runout, increased wear, and poor finish on the piece part. Too much tension can cause the blade to break. To check the blade tension, you can use a blade tensioner or by hand as explained below.

To properly tension the blade, follow the procedure below.

1. DISCONNECT POWER FROM THE BANDSAW.
2. Open the upper pulley access door.
3. Loosen the guide post adjusting knob and raise the upper blade guide as high as it will go and secure it.
4. Check the blade deflection at a point halfway between the table and the upper blade guide. It should be about 0.37" (9.5mm) when applying a moderate side pressure.
5. If a tension adjustment is necessary, make small adjustments to the handwheel. Turning the handwheel clockwise (cw) increases the tension and turning it counterclockwise (ccw) will decrease the blade tension. After adjusting the handwheel, rotate the top pulley several times by hand and then re-check the deflection.



Note: As the top pulley is rotated, make sure the blade does not touch the flange of the pulley.




IMPORTANT: To prolong the life of the blade, release the tension on the blade if the bandsaw will be idle for an extended period of time.



Changing a Blade

⚠ CAUTION: The bandsaw blade is sharp and can cut your hand or fingers. Always disconnect power to the saw and wear leather gloves when working near the blade.

1. DISCONNECT POWER FROM THE BANDSAW.
2. Unlatch and swing open the upper and lower pulley access doors.
3. From under the table, remove the two hand knobs (A) and lift the insert out of the table.
4. Release the blade tension by rotating the tension wheel (B) counterclockwise (ccw).
5. Put on gloves to protect your hands. Now slide the blade off of the upper and lower sheaves, around the blade guards, and through the slot in the table.
6. Install the new blade in the reverse order with the teeth facing forward toward the door and the tips of the teeth pointing downward toward the worktable.
7. Make sure the blade is centered on the wheels and engaged between the upper and lower blade guides.
8. Turn the tension wheel to tighten the blade following the “Blade Tension Adjustment Wheel” procedure.
9. Carefully make a few rotations of the top sheave by hand to make sure the blade band is tracking evenly.






BLADE TRACKING

Regular Adjustment

⚠ CAUTION: This adjustment will have the blade exposed to possible. The bandsaw blade is sharp and can cut your hand or fingers. Use extreme care when blade.

When changing blade and especially when changing the width of the blade, it may be necessary to adjust the tracking to keep the blade centered on drive wheel.

1. DISCONNECT POWER FROM THE BANDSAW.
2. Open the upper wheel door.
3. Loosen the lock knob (A).
4. Turn the Speed Control down (counterclockwise) to the lowest speed setting.
5. Connect the saw to the power supply and power on.
6. Watch the blade travel over the drive wheel. The blade should track in the middle of the wheel.
7. Slowly and a little at a time, turn the adjustment knob (B) to cause the blade to move toward the middle of the wheel. Allow the blade to run several rotations after any adjustment.
8. When the tracking is centered, tighten the lock knob (A).
9. Continue to allow the blade to rotate several more times to verify the setting.
10. Stop the saw and close the wheel door(s) before returning the saw to service.






Coarse Adjustment



Note: Blade tracking has been set at the factory and should not require adjusting. Before making any tracking adjustments, try a new blade. Warped blades will not track properly.

If a tracking issue occurs, adjust the top sheave.
When the blade band is tracking towards the flange:

1. Loosen the (4) bearing plate mounting bolts.
2. Back out the top (2) jack screws a bit.
3. Re-tighten the (4) mounting bolts and check the tracking again.
4. Reverse the procedure to track the blade band away from the flange.





LUBRICATION AND MAINTENANCE



WARNING: Make sure the electrical disconnect is OFF before working on the machine.

Maintenance should be performed on a regular basis by qualified personnel.

Always follow proper safety precautions when working on or around any machinery.

Daily Maintenance

- Do a general cleaning by removing dust and metal chips from the machine.
- Clean the blade brush.
- Inspect the saw blade for wear.
- Check that the blade guards and emergency stop button are in good working order.
- If you did blade welding, clean the clamping pads.

Weekly Maintenance

- Thoroughly clean the machine.
- Remove chips from inside the guard housing for the saw blade.



Note: When cleaning chips and debris from the machine, use a brush and a shop vacuum. **DO NOT** blow off the machine with compressed air. The force of the compressed air may force chips into critical mechanisms or may inflict injury to yourself or others.

- Use compressed air to clean the blade guides.
- Inspect the grinding wheel for wear.

Monthly Maintenance

- Check the blade guides and blade support for wear. (rotate or replace if necessary)
- Tighten any loose bolts, nuts, or screws on the machine.
- Re-grease the drive bearings.
- Inspect the blade brush for wear. (Adjust or replace)
- Grease the pivot of the blade shear.
- Wipe shafts and threaded rods with a light lubricant.
- Inspect the V-belts for wear (every 3 months)



Note: Proper maintenance can increase the life expectancy of your machine.



Blade Shear Lubrication

Apply a light coating of grease to the pivot mechanism as necessary.




Upper Wheel Housing Items

Apply grease to the tension slide blocks, tension adjustment screw and the blade guide post rack as needed to keep them moving freely and free from rust.




Table Support Lubrication

Grease the pivoting table support as often as needed.





CABINET ASSEMBLY – BREAKDOWN






Cabinet Assembly – Part List

Item	Part No.	Description	Size	Qty.
1	BSV24VS-V2-01	Lower Wheel Door		1
2	BSV20VS-V2-02	Hing Pin Lower		2
3	TS-2245102	Socket Head Button Screw	M5*0.8P*8mm	6
4	BSV20VS-V2-04	Control Panel		1
4-1	BSV20VS-V2-4-1	Blade Speed Digital Readout Meter		1
4-2	BSV20VS-V2-4-2	Start Button		1
4-3	BSV20VS-V2-4-3	Stop Button		1
4-4	BSV20VS-V2-4-4	Power Button		1
4-5	BSV20VS-V2-4-5	Select Switch Button		1
4-6	BSV20VS-V2-4-6	Emergency Stop Button		1
5	BSV24VS-V2-5	Blade Cleaning Brush		1
6	TS-1503061	Socket Hex Cap Screw	M6*1.0P*25mm	1
7	BSV24VS-V2-7	Upper Wheel Door		1
8	BSV20VS-V2-8	Hinge Pin Upper		2
9	TS-1490021	Hex Cap Screw	M8x16mm	2
10	BSV20VS-V2-10	Blade Shear		1
11	BSV20VS-V2-11	Air Pump		1
12	BSV24VS-V2-12	Bandsaw Cabinet		1
13	BSV20VS-V2-13	Air Hose	4*6mm	1
14	BSV20VS-V2-14	Air Nozzle		1
15	BSV20VS-V2-15	Work Lamp (Led)	220V	1
16	BSV20VS-V2-16	Door Knob		2
17	TS-1503041	Socket Hex Cap Screw	M6*1.0P*15mm	2
18	TS-1502041	Socket Hex Cap Screw	M5x16mm	4
19	TS-1550041	Flat Washer	M6	10
20	TS-2246102	Socket Head Button Screw	M6*1.0P*10mm	10
21	BSV24VS-V2-21	Back Cover		1
22	BSV24VS-V2-22	Chip Pan		1
23	BSV20VS-V2-23	Lower Blade Guard Set		2
24	BSV20VS-V2-24	Hex Cap Screw	M6-1*10mm	4
25	TS-1550041	Flat Washer	M6	4



WORK TABLE ASSEMBLY – BREAKDOWN






Work Table Assembly – Part List

Item	Part No.	Description	Size	Qty.
101	TS-1503051	Socket Hex Cap Screw	M6*1.0P*20mm	2
102	TS-1550041	Flat Washer	M6	2
103	BSV20VS-V2-103	Tungsten Support		2
104	BSV20VS-V2-104	Guide Seat (lower)		1
105	BSV20VS-V2-105	Lower Guide Rod		1
106	TS-1503061	Socket Hex Cap Screw	M6*1.0P*25mm	2
107	BSV20VS-V2-107	Trunnion Base		1
108	TS-2311101	Hex Nut	M10	1
109	TS-1550071	Flat Washer	M10	1
110	TS-1550061	Flat Washer	M8	4
111	TS-1490031	Hex Cap Screw	M8*1.25P*20mm	4
112	TS-1504041	Socket Hex Cap Screw	M8*1.25P*20mm	4
115	BSV20VS-V2-115	Trunnion		1
116	BSV20VS-V2-116	Lock plate		1
117	BSV24VS-V2-117	Table		1
118	BSV24VS-V2-118	Fence		1
119	BSV20VS-V2-119	Fence Rail		1
120	BSV20VS-V2-120	T - Block	M12	1
121	TS-1504041	Socket Hex Cap Screw	M8x20mm	2
122	BSV20VS-V2-122	Lock Screw		1
123	BSV24VS-V2-123	Table Insert		1
123-	BSV24VS-V2-123-1	Plastic Knob		2
124	BSV24VS-V2-118	Miter Gauge Assembly		1



LOWER WHEEL SET ASSEMBLY – BREAKDOWN






Lower Wheel Set Assembly – Part List

Item	Part No.	Description	Size	Qty.
201	BSV24VS-V2-201	Rubber ring	500mm	2
202	BSV24VS-V2-202	Lower Wheel		1
202-1	BSV24VS-V2-202-1	Saw Blade (not show)		1
203	TS-2311201	Hex nut	M20	1
204	TS-2360201	Flat Washer	M20	1
205	BSV24VS-V2-205	Key	7x7mm	
206	BSV24VS-V2-206	Lower Wheel Shaft		
207	BSV24VS-V2-207	Key	7x7x46mm	
208	BB6206	Ball Bearing	6206	2
209	BSV24VS-V2-209	Bearing Housing		1
210	BSV24VS-V2-210	Special Screw		4
211	BSV24VS-V2-211	Hex Cap Screw	M10x1.5x50mm	4
212	BSV24VS-V2-212	Hex Nut	M28x1.75	2
213	BSV20VS-V2-214	Wheel Pulley		1
213-1	BSV24VS-V2-A63	Belt	A63	2
214	TS-1492031	Hex Cap Screw	M12*1.5*35mm	2
214-1	TS-1540081	Hex nut	M12	2
214-2	TS-2361121	Lock Washer	M12	2
215	BSV20VS-V2-217	Motor Pulley		1
216	TS-1524021	Set Screw	M8*1.25P*10mm	2
217	BSV24VS-V2-217	Motor	3HP/ 220V/ 3Ph/ 6P	1
218	TS-1490041	Hex Cap Screw	M8x1.25x25mm	8
219	BSV24VS-V2-219	Motor Bracket		1
220	TS-1550061	Flat Washer	M8	16
221	TS-1540061	Hex Nut	M8	8



GUIDEPOST ASSEMBLY – BREAKDOWN






Guidepost Assembly – Part List

Item	Part No.	Description	Size	Qty.
501	TS-1503051	Socket Hex Cap Screw	M6-1*20	2
502	TS-1550041	Flat Washer	M6	2
503	BSV20VS-V2-503	Blade Guide		2
504	BSV20VS-V2-504	Blade Guide Bracket Upper		1
506	TS-1503051	Socket Hex Cap Screw	M6-1*20	1
507	BSV20VS-V2-507	Pin	4*6	2
508	BSV20VS-V2-508	Guidepost Clamp Plate		1
509	BSV20VS-V2-509	Guidepost Rack		1
510	BSV20VS-V2-510	Guidepost Bracket		1
511	TS-2361141	Lock Washer	M14	3
512	BSV20VS-V2-512	Lock Knob		1
513	BSV20VS-V2-513	Special Screw		1
514	BSV20VS-V2-514	Guidepost Pinion Gear		1
515	BSV20VS-V2-515	Worm Gear		1
516	BB609ZZ	Bearing	609zz	1
517	BSV20VS-V2-517	Hand Wheel Handle		1
518	BSV20VS-V2-518	Hand Wheel		1
519	BSV20VS-V2-519	Collar		1
519-1	TS-1523011	Set Screw	M6-1*6	1
520	BSV20VS-V2-520	Worm Gear Bracket		1
521	TS-2361061	Lock Washer	M6	1
522	TS-1503051	Socket Hex Cap Screw	M6-1*20	1
523	BSV20VS-V2-523	Blade Guard		1
524	TS-1550061	Flat Washer	M8	4
525	TS-1490021	Hex Cap Screw	M8-1.25*16mm	4



UPPER WHEEL SET ASSEMBLY – BREAKDOWN






Upper Wheel Set Assembly – Part List

Item	Part No.	Description	Size	Qty.
601	BSV24VS-V2-601	Upper Wheel	620mm	1
601-1	BSV24VS-V2-601-1	Rubber Ring		1
602	TS-2310201	Hex Nut	M20x1.5	1
603	TS1550111	Flat Washer	M20	
604	BB6206	Ball Bearing	6206	1
605	BSV24VS-V2-605	Bearing Housing		1
606	BSV24VS-V2-606	Upper Wheel Shaft		1
607	KEY7726	Key	7x7x26mm	1
608	BB6206	Ball Bearing	6206	1
609	BSV20VS-V2-604	Retaining Ring	STW30#	1
610	TS-0060071	Hex Cap Screw	3/8"-16x1-1/2"	2
611	TS-0720091	Lock Washer	3/8"	2
612	BSV20VS-V2-619	Pivot Pin		2
613	TS-1504051	Socket Hex Cap Screw	M8*1.25P*25mm	4
614	TS-1550061	Flat Washer	M8	4
615	BSV20VS-V2-611	Racket Plate		2
616	TS-1523011	Set Screw	M6*1.0P*6mm	2
617	BSV20VS-V2-613	Collar		2
618	BSV20VS-V2-614	Thrust Bearing	2901	2
619	BSV20VS-V2-615	Tensioning Bracket		1
620	BSV24VS-V2-620	Leadscrew Bracket		1
621	TS-1504051	Socket Hex Cap Screw	M8*1.25P*25mm	2
622	TS-1523011	Set Screw	M6*1.0P*6mm	2
623	BSV20VS-V2-616	Tension Leadscrew		1
624	BSV20VS-V2-617	Tensioning Handwheel		1
625	BSV20VS-V2-622	Lock knob w/ Screw (Large)	M10*1.5P	1
626	BSV20VS-V2-623	Lock knob (small)	M10*1.5P	1
627	BSV20VS-V2-624	Tube		1
628	BSV20VS-V2-621	Spring		1
629	BSV20VS-V2-620	Arrow		1



WELDER ASSEMBLY- BREAKDOWN





Welder Assembly – Part List

Item	Part No.	Description	Size	Qty.
301	TS-0050171	Hex Cap Screw	1/4"-20*4"	1
302	BSV20VS-V2-302	Transformer Bracket		1
303	TS-130005	Flat Washer	1/4"	2
304	TS-0561011	Hex Nut	1/4"x20	2
305	BSV20VS-V2-305	Limit Switch		1
306	TS-1503061	Socket Head Cap Screw	M6-1*25	1
307	TS-1503021	Socket Head Cap Screw	M6-1*10	2
308	BSV20VS-V2-308	Limit Switch Bracket		1
309	BSV20VS-V2-309	Sliding Block		1
310	BSV20VS-V2-310	Welding Clamp Left		1
311	BSV20VS-V2-311	Welding Jaw Left		1
312	TS-1503031	Socket Head Cap Screw	M6-1*12	1
313	BSV20VS-V2-313	E-Clip	4mm	1
314	BSV20VS-V2-314	Shaft		1
315	BSV20VS-V2-315	Clamp Lever		1
316	TS-1503031	Socket Head Cap Screw	M6-1*12	1
317	BSV20VS-V2-317	Sliding Block Base		1
318	TS-1503041	Socket Head Cap Screw	M6-1*16	1
319	BSV20VS-V2-318	Grinder Cover		1
320	TS-1540041	Hex Nut	M6	1
321	TS-1550041	Flat Washer	6mm	1
322	BSV20VS-V2-322	Grinding Wheel	DIA 2-1/2"	1
323	TS-1550041	Flat Washer	6mm	1
324	BSV20VS-V2-324	Grinder Motor	1/8HP 220V 1PH	1
324-1	BSV20VS-V2-324-1	Capacitor	3Mf250V	1
325	BSV20VS-V2-325	ON/OFF Switch		1
326	TS-1514021	Socket Head Flat Screw	M6-1*16	1
327	TS-1514031	Socket Head Flat Screw	M6-1*20	1
328	BSV20VS-V2-328	Welding panel		1
329	BSV20VS-V2-329	Clamp pressure Knob		1
330	BSV20VS-V2-330	E-Clip	4mm	1
331	BSV20VS-V2-331	Clamp Lever		1
332	BSV20VS-V2-332	Shaft		1



Item	Part No.	Description	Size	Qty.
333	BSV20VS-V2-333	Welding Clamp Right		1
334	BSV20VS-V2-334	Insulating Plate		1
335	TS-1550041	Flat Washer	6mm	1
336	TS-1503051	Socket Head Cap Screw	M6-1*20	1
337	TS-1503051	Socket Head Cap Screw	M6-1*20	1
338	BSV20VS-V2-338	Welding Jaw Right		1
339	TS-1503051	Socket Head Cap Screw	M6-1*20	1
340	TS-1540041	Hex Nut	M6	1
341	TS-1550041	Flat Washer	6mm	1
342	BSV20VS-V2-342	Pressure Cam		1
343	BSV20VS-V2-343	Cam Shaft		1
344	BSV20VS-V2-344	Tension Spring	0.8*25mm	1
345	TS-0207021	Socket Head Cap Screw	1/4-20*1/2	1
346	BSV20VS-V2-346	Bracket		1
347	BSV20VS-V2-347	Annealing Push Button		1
348	BSV20VS-V2-348	Welding Push Button		1
349	BSV20VS-V2-349	Transformer	4.2KVA 220V	1



Electrical Diagram Part List

Item	Part No.	Symbol	Description
1	BSV24VS-V2-EL1	KM1	Contactor (Saw Blade Motor)
2	BSV24VS-V2-EL1	KM2	Contactor (Grinder Motor)
3	BSV20VS-V2-EL3	M2	Grinder Motor
4	BSV24VS-V2-EL4	M1	Saw Blade Motor
5	BSV24VS-V2-EL5	F	Fuse 5A (2pcs)
6	BSV20VS-V2-EL6	P1	Key switch for main Power
7	BSV20VS-V2-EL7	PB1	Off switch
8	BSV20VS-V2-EL8	PB2	Main Motor start Switch
9	BSV20VS-V2-EL9	PB3	Emergency Switch
10	BSV20VS-V2-EL10	S1	Select switch for Cut / Weld function
11	BSV20VS-V2-EL11	R	Relay (VFD Run Signal)
12	BSV20VS-V2-EL12	P	Air Pump
13	BSV20VS-V2-EL13	VR	Variable Speed Knob



NOTES



NOTES



BAILEIGH INDUSTRIAL HOLDINGS LLC
1625 DUFEK DRIVE MANITOWOC, WI 54220
PHONE: 920. 684. 4990 FAX: 920. 684. 3944
www.baileigh.com