

Wide Belt Sander

Owner's Manual



Model 3760



Model 4375



Safety Speed Manufacturing

13943 Lincoln Street NE

Ham Lake, MN 55304

Tel: 763-755-1600 Fax: 763-755-6080

www.safetyspeed.com

sales@safetyspeed.com

Table Of Contents

Warranty	4	Maintenance	29-40
Safety Information	5-6	-Repairs	29
Set Up	7-10	-Lubrication	29
-Electrical Service Requirements	8	-Sanding Head Rollers	29
-Single Phase	8	-Conveyor Table Rollers-	29
-Three-phase Electrical Service (230v)	9	-Bronze Bushings	29
-Air Service	10	-Jack Screws	29
-Dust Collection	10	-Conveyor Drive Gear Reducer-	30
Introduction To The Components ..	11-18	-Swing Arm Top Idler Roller	30
-Load Meter	11	-All Metal Moving Parts	30
-Air Control	11	-Drive Motor Belt Tension	30
-Sanding Heads Start Control	12	-Platen Graphite Replacement	31
-Sanding Head Stop Control	12	-Platen Felt Replacement	32
-Emergency Stop Locations	13	-Contact Roller Resurfacing	33
-Conveyor Table Speed Adjustment Controls	14	-Contact Roller Removal/Replacement	34
-Conveyor Table Height Adjustment Gauges	15	-Contact Roller Reinstallation	35
-Gauge With Ruler And Indicator	15	-Re-leveling The Contact Roller	35
-Simple Stationary Pointer	16	-Pinch Roller and Idler Roller Replacement	36
-Optional Digital Positioning Gauge System	16	-Rear Idler Roller Leveling	37
-Abrasive Belt Tracking System	17-18	-Level The Table	37
Sanding Operations -	19-28	-Level The Conveyor Table	38
-Operational Checklist	19	-Wide Belt Sander Belt Tracking	39
-Abrasive Sanding Belt General Information	20	Trouble Shooting -	41-44
-Abrasive Sanding Belt Installation	21	-Machine Will Not Start	41
-Operating The Machine	22-24	-Unwanted Surface Marks	41-42
-Introduction To The Platen	25	-Sanding Belt Tracking-	42-44
-37" X 60" Model Platen	26	Exploded Views and Parts List	45-60
-Installing and Using the Platen	26	-4375 Exploded Views and Parts	45-52
-4375 Series Models Platen-	27	-3760 Exploded Views and Parts	53-59
-Platen Removal 4375	28	Electrician Wiring Schematics	60-61
		-Single Phase Wiring Schematic	60
		-Three Phase Wiring Schematic	61

This page was intentionally left blank.

The information in this manual covers the following models:

WBS 3760

WBS 4375

The manual is provided to assist operators and service people in the proper upkeep and maintenance of Safety Speed units.

This manual is published for informational purposes only and the information so provided should not be considered as all-inclusive or covering all contingencies. If further information is required, Safety Speed Manufacturing should be consulted.

Warranty

Safety Speed Mfg. warrants the parts and workmanship of this tool for one year from the date of manufacture. Safety Speed Mfg. will repair or replace, at our cost, any component that is determined to be defective.

Such repair or replacement is limited to providing satisfactory replacement parts from our factory.

Safety Speed Mfg. assumes no responsibility for making repairs on site.

Any parts returned to the factory must be returned freight prepaid.

Safety Speed Mfg. assumes no responsibility for damage or accidents resulting from the misuse of this tool, its misapplication, or failure to follow precautionary safety measures.

Safety Speed Mfg. assumes no responsibility for any consequential damage or loss of production.

Safety Speed Mfg. will not be responsible for claims made for machines that are not used or maintained in the normal course of business, used for applications not intended, or modified in any way.

A message from all of us at Safety Speed Manufacturing

Thank you for purchasing a Safety Speed Wide Belt Sander. We take pride in building these fine products in the U.S.A. Each product is designed to give years of dependable service. Our wide belt sanders are built from the finest components we can specify. Every machine is individually assembled by our employees, some of whom have been building products for the industry for more than 25 years. We appreciate that you chose our products for your applications.

The employees of
Safety Speed Manufacturing
Ham Lake, MN

Safety

Read And Save All Instructions For Future Use

WARNING: Always follow basic safety precautions when using electrical tools. This will reduce the risk of fire, electrical shock, and personal injury.

Safety Information

You must read and understand this manual before using the equipment. You must also read any labels and safety warnings packaged with or attached to this unit.



USE COMMON SENSE AT ALL TIME!



KNOW YOUR POWER TOOL. You must read this manual carefully to learn your power tool's applications and limitations. Before operation it is important that you know the potential hazards associated with this type of tool.



DO NOT ALLOW UNQUALIFIED PEOPLE TO OPERATE THE MACHINE.



AVOID DANGEROUS ENVIRONMENTS. Do not use your power tool in damp or wet locations. Do not use your power tool in the presence of explosive atmospheres (gaseous fumes, dust, or flammable materials). Remove all materials or debris that may be ignited by sparks.



KEEP WORK AREA CLEAN AND WELL LIT. Cluttered, dark work areas invite accidents. Provide at least 200 watts of lighting at the front work area of the machine. Eliminate all shadows that could interfere with clear viewing of the work area.



DRESS PROPERLY. Do not wear loose fitting clothing or jewelry. Wear a protective hair covering to contain long hair. Unprotected hair may be caught in moving parts. When working outdoors wear rubber gloves and insulated non-skid footwear. Keep hands and gloves away from moving parts.



USE SAFETY EQUIPMENT. Everyone in the work area should wear safety goggles or glasses with side shields. The safety goggles and/or glasses should comply with current safety standards. Wear hearing protection during extended use of the machine. Wear a dust mask for dusty operations. Hard hats, face shields, safety shoes, etc. should be used when specified or necessary. Keep a fire extinguisher nearby.



KEEP BYSTANDERS AWAY. Keep children and bystanders at a safe distance from the work area.



MAKE THE WORKSHOP CHILD PROOF. Install padlocks and master switches, etc. to make the workshop child proof.



NEVER LEAVE THE MACHINE RUNNING UNATTENDED. Turn the power off. Do not leave the machine until it comes to a complete stop.



PROTECT OTHERS IN THE WORK AREA FROM DEBRIS. Provide barriers or shields as needed to protect others in the work area from flying debris such as chips and sparks.



SECURE THE WORK. Hold your work securely with a clamp, vice or other practical means. This will free both hands to control the machine.



USE THE RIGHT MACHINE/TOOL. Do not use the machine or any of its attachments to do a job for which it is not recommended. Do not alter the tool, remove guards or operate the machine without all proper guarding in use.



USE PROPER ACCESSORIES. Using non-recommended accessories may be hazardous. Be sure accessories are properly installed and maintained. Do not defeat the purpose of a guard or other safety device when installing an accessory or attachment.



CHECK FOR DAMAGED PARTS. Inspect guards and other parts before use. Check for misalignment, binding of moving parts or improper mounting of parts. Also check for broken parts and other conditions that may affect operation. Turn the tool off immediately if abnormal noise or vibration occurs. Have the problem corrected before further use. Do not use a damaged tool. Tag damaged parts “DO NOT USE” until repaired. Repair or replace a damaged guard or other damaged parts. For all repairs, insist on an identical replacement part.



REMOVE ALL ADJUSTING WRENCHES AND TOOLS FROM THE MACHINE BEFORE TURNING IT ON.



GROUND YOUR MACHINE. When in doubt as to the grounding of your machine, consult a qualified electrician before using your machine.



AVOID ACCIDENTAL STARTING. Do not use the tool if the power switch does not turn it on and off. Observe correct lock-out tag procedures when performing maintenance on your machine.



DO NOT FORCE THE TOOL. Your tool will perform best at the rate for which it was designed. Excessive force only causes operator fatigue. Excessive force also causes increased machine wear and increased risk. This all can cause reduced control of the machine and results in a danger to the operator.



KEEP HANDS AWAY FROM ALL CUTTING, SANDING EDGES, HOLDDOWNS AND MOVING TABLE PARTS.



DO NOT ABUSE THE POWER CORD. Keep the cord and other wiring away from heat, oil, sharp objects, cutting tools and moving parts.



DO NOT OVER REACH. MAINTAIN CONTROL. Keep proper footing and balance at all times. Maintain a firm grip.

Set Up

Set Up

Complete the following steps to prepare your machine for use.

1. Remove the machine from the pallet. It is recommended to lift the machine from the underside of the machine, between the legs. See Fig. 2. It is important to remember that the machine is very heavy and unstable until it is secured to the floor.
2. Position the machine in its designated location in your shop. Consider the services of compressed air, dust collection and electricity. Also position the machine considering your environment's limitations for in-feed and out-feed space. See Fig. 1.

Mount the machine to the floor. Use the holes on each of the four corners of the machine frame to mount it to the floor. See Fig. 3.




Figure 1: Machine Dimensions

Model 3760

A = 50 1/2" (1280mm)

B = 63" (1600mm)

C = 47" (1190mm)

Weight=1400 lbs (635 kg)

Model 4375

A = 53" (1346mm)

B = 70" (1780mm)

C = 56" (1422mm)

Weight= 2389 lbs. (1083 kg)



Figure 2: Place Moving Jacks Here



Figure 3: Mounting Holes

Electrical Service Requirements

Electrical servicing of the machine must be completed by an experienced, licensed electrician.

NOTE: Refer to the exploded view and parts list in the back of the manual for a full view of the electrical components.



CAUTION: Electrical servicing of the machine must be completed by an experienced, licensed electrician.

Single Phase

To connect the unit in a single phase operation, complete the following steps.

1. Connect 220 volt services to the positions labels L-1 and L-2 on the main magnetic starter. See Fig. 4 & 5.
2. Connect the ground wire from the service to the grounding bar inside the control panel. See Fig. 6.

Connect the neutral wire from the service to the wire labeled “neutral.” See Fig. 6.

NOTE: If there is not a neutral wire in the incoming service, then connect the small neutral wire from the machine to the grounding bar. This may already be connected from the factory but should be double checked by your electrician as part of the wiring procedure.




Figure 4: Electrical Connections




Figure 5: Electrical Schematic




Figure 6: Starter

Three-phase Electrical Service (230v)

CAUTION: Always unplug the machine from its power source before performing any electrical wiring.

NOTE: Refer to the exploded view and parts list in the back of the manual for a full view of the electrical components.

1. Check for a high leg. The high leg must be connected to L-3 only. Failure to do this may result in electrical damage to the 110V circuit that originates from L-1. See Fig. 7.
2. Connect the ground wire from the service to the grounding bar. See Fig. 7.
3. Connect a neutral from the service to the pig tail labeled “neutral.” See Fig. 7 or 8.
4. Check the direction of rotation of the contact roller from the front belt viewer. The contact roller should rotate in a counter-clockwise rotation when looking at it from this position. If the contact roller is rotating clockwise, the electrical service coming into L-1 and L-2 needs to be reversed. See Fig. 7 and 8.

NOTE: If contact roller is turning clockwise it will cause your sanding belt to mistrack.

Electrical service is now connected to your machine.

CAUTION: Always contact a qualified electrician to perform electrical services.




Figure 7: Electrical Connections




Figure 8: Electrical Schematic




Figure 9: Check Rotation

Air Service

Connect the supply air line to the 1/4" pipe fitting at the top of the machine. The machine requires 1CFM at 65-100 pounds of compressed air service. An air nipple is provided at the top of the machine's frame. See Fig. 10.

NOTE: *If you have any issues with debris or water from the air service, it is optimum to install a filter in-line ahead of the service into the sander.*

Dust Collection

Connect an appropriate dust collection system (1000-1800 CFM) to the machine. The machine utilizes a 6" dust chute. The dust exits through the top of the machine. See Fig. 11.

NOTE: *Failure to connect the machine to an appropriate dust collection system may result in problems with the machine's operation. These problems can include false signals from the belt tracking mechanisms. These problems can also include premature wear of the machine's components.*




Figure 10: Air Service




Figure 11: Dust Collection Chute

Introduction To The Components

Introduction

This chapter will describe, in detail, the individual components of the unit. It is required to review this chapter and have a good understanding of the machine components *before* operating your sander.

The Wide Belt Sander is controlled through the use of the miscellaneous buttons and switches on the front of the Control Panel. See Fig 12. The following pages will give a brief description of each item.

Load Meter

The sander is equipped with a main motor load meter. See Fig. 13. The motor load is shown in a percentage basis on the meter. The machine should not be run when the pointer on the load meter is into the red band area (over 100%). You can reduce the load by slowing down the conveyor table speed, lowering the table, or raising or removing the platen.

Air Control

The air control is located toward the top of the control panel. See Fig. 14. The toggle switch turns the air on and off. It is labeled “Air On Controls.” See Fig. 14. Leave the air switch in the “Off” position when the machine is not being used. See Fig. 14.

A single regulator regulates the air coming into the wide belt sander. The regulator is located inside the machine cabinet on the in-feed side. The regulator should be adjusted to between 60 and 65 psi of air pressure.* The machine is running at optimum operation at this adjustment. See Fig. 29 & 30. Page 15.

*High altitudes may require more air pressure for optimal operation.



CAUTION: Never turn the air off until the sanding head has come to a complete stop.



Figure 12: Control Panel




Figure 13: Load Meter Air Control



Figure 14: Air Control

Sanding Head Start Control

The “Start” Button is a green colored button labeled “Sanding Head Start.” See Fig. 15. The machine will not start if an emergency stop has been activated. It also will not start if there is not air pressure to the machine. You must completely read and understand this operator’s manual before operating the machine.

Sanding Head Stop Control

Press the red colored button on the control panel to stop the sanding belt rotation during normal operating conditions. This button is labeled “Sanding Head Stop.” See Fig. 17. Pressing this button will turn off the sanding head and the conveyor table.




Figure 15: Control Panel




Figure 16: Green Start Button



Figure 17: Red Stop Button

Emergency Stop Locations

There are multiple emergency stop systems in place on the machines. On the 43" x 75" belt sander there is one on the front of the table. See Fig. 19. On the 37" x 60" machine, this stop is located just above the opening to the sanding head on the cabinet. See Fig. 18. The other emergency stop on both machines is a mushroom-shaped button located on the front of the control panel. Use the stops located on the outside of the machine in any emergency situation where the machine needs to be stopped immediately.

There are also two emergency stops inside the cabinet that will automatically shut the machine down in the event that the abrasive sanding belt overtracks to the left or right hand side of the machine. See Fig. 20. Inside the belt loading door there is a safety switch which requires the door to be closed before operation. The other emergency stops must be pressed to shut the machine down.

There is also an emergency load cut off on 3 phase machines.



Figure 18: 37" x 60" Belt Sander Emergency Stops



Figure 19: 43" x 75" Belt Sander Emergency Stops




Figure 20: Automatic Emergency Stop Switches

Conveyor Table Speed Adjustment Controls

Your machine is equipped with an electric DC motor with an adjustable feed speed. You can adjust the speed of the conveyor table from 0-18 feet per minute. This is accomplished by turning the black knob on the control panel. See Fig. 21 & 22. The conveyor belt speed adjustment knob is labeled with a 0-10 scale. Turn the knob clockwise (towards 10) for faster conveyor belt feed rate. Turn the knob counter-clockwise (towards 0) for slower conveyor belt feed rate.



Figure 21: Control Panel



Figure 22: Conveyor Table Speed Adjustment

Conveyor Table Height Adjustment Gauges

There are two table height gauges included as standard equipment on the Safety Speed Cut Wide Belt Sanders. There is also one optional gauge available. See Fig. 25. The two standard height gauges are simple systems. One has a ruler with an indicator and the other is a simple stationary pointer. See Figs. 23 & 24. Utilizing the standard or optional gauges will help you get the most accurate, consistent and professional results from your sander. The points listed below address a description and explanation of the use of each of the table height gauges on the machine.

Gauge With Ruler And Indicator

This gauge is positioned on the left-hand side (hand wheel side) of the machine. It is positioned vertically. There is a red colored indicator which points to your position on the ruler. This shows the table height in relationship to the contact roller. See Fig. 23. It is also used to indicate when you have reached your desired material thickness. This gauge is to be used in conjunction with a material thickness gauge. It is also used in conjunction with the second standard gauge on the machine, the stationary pointer.



Figure 23: Gauge with Ruler and Indicator



Figure 24: Stationary Table Height Gauge



Figure 25: Optional Table Height Digital Readout Gauge

Simple Stationary Pointer

The simple stationary pointer is colored white and is located on the left side of the machine on the red safety bar. This is directly above the machine's table. See Fig. 26. This pointer is used for quick setting of the table height according to your material thickness. To use this gauge, place your material down on the table and underneath the white tab. Adjust the table up or down until the highest point on your panel fits underneath the white stationary pointer. This will prepare you to sand without worrying about overloading the machine. This gauge is designed to make a quick, simple table height adjustment.



Figure 26: Stationary Pointer

Optional Digital Positioning Gauge System

The optional digital read out system utilizes a digital display to help you appropriately adjust the table height. See Fig. 27. This gauge measures the distance that you are raising or lowering the table, in relationship to the contact roller. You will also use it for measuring the actual dimension on your last (finishing) sanding passes. Refer to the operating and installation instructions included with the digital read out for more information on operating this gauge.



Figure 27: Optional Digital Read Out

Abrasive Belt Tracking System

The machine is equipped with an air regulator. The regulator should be adjusted to approximately 60 to 65 psi. This is for all operations of the machine. The regulator can be adjusted by turning the yellow knob located on the front of the regulator. See Fig. 28.

There are two air valves that are located on the front door. See Fig. 28.

Valve No. 1 controls the air flow into the tracking piston. See Fig. 28. The tracking piston is located behind the control panel inside the machine's cabinet. The amount of air flowing into the piston controls how quickly the swing idler roller tracks the sanding belt to the left side of the machine.

Valve No. 2 located inside the door controls the air flow into the tensioning piston. The tensioning piston pushes the swing arm idler roller up to tension the abrasive sanding belt. See Fig. 29.

Valve No. 3 controls the air flow out of the tracking piston. This controls how fast the swing arm roller tracks the abrasive sanding belt back to the right side of the machine toward the photoelectric eye. See Fig. 28.

ABRASIVE BELT TRACKING QUESTIONS ANSWERED

How does the tracking system work?

The abrasive sanding belt rides on three rollers. Two of the rollers are on the bottom and one roller is on the top of the machine. The one on the top steers the belt. From the factory, the top roller is just off from parallel with the bottom rollers. The right end of the roller is closer to the feed side of the machine. The left side is closer to the out feed side of the machine. The roller pivots in the middle. The right side of the machine is the electrical box side. The left side is the hand wheel side.

With the top roller set this way, the belt will track toward the eye. The tracking solenoid is turned on and off with the eye switch when the invisible light beam is broken by the abrasive sanding belt. The eye will energize the tracking solenoid valve when it is covered. The valve will open, letting air pass through it and into the tracking air piston.




Figure 28: Air Valves and Regulator



Figure 29: Air Valve #2

The piston comes out, it then pushes on the right side of the top roller moving that end of the roller closer to the out feed side of the machine. The belt will then track to the left side of the machine until the sanding belt clears the eye. When the eye is clear, the solenoid valve closes. Air pressure that is in the air piston will exhaust through the photoelectric eye, keeping the eye clear of sawdust. The piston will then be pulled back by spring pressure making the sanding belt track towards the right side again and beginning the cycle over.

NOTE: Under normal working conditions every time the eye gets covered, the tracking solenoid will open and close making a clicking sound. It is normal to hear multiple clicking sounds if the eye is being covered by an uneven belt edge. Adjustments must be made when there is not a clicking sound.

Sanding Operations

Operational Checklist



Before operating your unit, completely read and have a full understanding of this operator's manual.

You should not operate your unit unless you have a full understanding of how the machine operates.

Before operating your machine, review the following steps.

1. Three-phase machines: Double-check the contact roller rotation and/or sand paper. Confirm that your sand paper is turning counter clockwise. See Fig. 31.
2. All access doors are to remain closed for operation.
3. Make sure all machine guards are bolted in place and the belt loading door is closed. See Fig. 32.
4. Adjust the conveyor table to the proper height for the thickness of the material you are sanding. Refer to the "Table Height Adjustment Gauges" page 15. Also shown in Fig. 33.



Before operating the machine, the operator must be familiar with the operating procedures of the machine. Do not operate the machine without full knowledge and understanding of the steps in operating the unit.




Figure 31: Contact Roller Should Turn Counter-Clockwise




Figure 32: Machine Guards



Figure 33: Table Height Adjustment

Abrasive Sanding Belt General Information

Choose the appropriate abrasive sanding belt grit for your intended application. Utilize the table below as a quick guideline to help you choose an appropriate abrasive sanding belt for your application.

GRIT	APPLICATIONS
36-40 GRIT	<ol style="list-style-type: none"> 1. Use on rough lumber. 2. For heavy stock removal. 3. Abrasive sanding applications.
60 GRIT	Use to remove adhesives. Use for dimensioning of already planed stock.
80 GRIT	<ol style="list-style-type: none"> 1. Use for light dimensioning. 2. Use for general clean-up of stock. 3. Removes coarser grit sanding passes and/or planer marks.
100-120 GRIT	Use as an in-between belt to remove sanding marks from coarser grit sanding passes.
150-180 GRIT	Used for finishing passes.
220 GRIT	Use to remove cross-grain scratches.

Figure 34: Abrasive Sanding Belt Applications



Figure 35: Wide Belt Sander

Abrasive Sanding Belt Installation

Complete the following steps to install the sanding belt.

1. Turn the air pressure switch to the off position. See Fig. 36.

NOTE: Do not turn air off until sanding head has come to a complete stop.

2. Open the belt loading door. See Fig. 37. Release lever for sanding head and remove spacer-block.
3. Place the abrasive sanding belt over the top of the top swing idler roller. See Fig. 37.
4. Position the abrasive sanding belt over one of the lower rollers. See Fig. 37.
5. Rotate the abrasive sanding belt over the last roller while pushing the abrasive sanding belt into the machine. See Fig. 37.
6. Pay special attention to the positioning of the abrasive sanding belt. Position the abrasive belt between the spring limit switches.

NOTE: Be sure the belt is not pushed all the way against the back of the machine.

The machine has two spring limit switches. See Fig. 38. They will automatically actuate the emergency stop and prevent the machine from starting if either of the switches are engaged. They will also engage if the abrasive sanding belt tracks too far left or right. See Fig. 38.

7. Once belt is in position replace platen spacer block and secure sanding head with lever.



Figure 36: Air Pressure Switch




Figure 37: Install Sanding Belt




Figure 38: Spring Limit Switch

Operating The Machine

Complete the following steps to operate the machine:

1. Measure the thickness of the material to be sanded. Adjust the table height adjustment handwheel. See Fig. 39. Adjust until the ruler indicator reads slightly less than the thickness of the material to be sanded. See Fig. 39.
2. Turn the air pressure switch to the “On” position. See Fig. 40.
3. Press the green button labeled “Sanding Head Start.” See Fig. 40. The sanding head will then start. During this normal operation you will have a regular clicking sound. This is normal. When the abrasive sanding belt rotates in normal operation, it will pass back and forth, left to right across the electric eye. The eye will turn on the tracking solenoid. If the edge of the abrasive sanding belt should become frayed, it will click even more often. This is also normal.
4. Press the conveyor start button labeled “Conveyor Start.” This will start the conveyor belt turning. See Fig. 41.




Figure 39: Table Height Adjustment



Figure 40: Air Pressure Switch and Sanding Head Start Button



Figure 41: Conveyor Start Button

5. Adjust the speed of the conveyor belt. Refer to the “conveyor belt speed adjustment” section on page 14. See Fig. 42.
6. Stand to one side or the other of the infeed table. Never stand directly inline with the table. Serious injury could occur in a kick-back situation.
7. Place the material onto the front end of the conveyor bed on the in-feed side of the machine. See Fig. 44. Your material will feed in the same direction as the conveyor table belt is rotating.



CAUTION: Do not place your fingers directly under the material. this could cause personal injury.



CAUTION: Never stand directly inline with the table. Serious injury could occur in a kick-back situation.

8. Feed your material into the machine. Keep an eye on the load meter. The load meter gauge measures the percentage of load on the motor when the material comes into contact with the platen.

Load Meter

The sander is equipped with a main motor load meter. See Fig. 13. The motor load is shown in a percentage basis on the meter. The machine should not be run when the pointer on the load meter is into the red band area (over 100%). You can reduce the load by slowing down the conveyor table speed, lowering the table, or raising or removing the platen.



Figure 42: Conveyor Belt Speed



Figure 43: Table Height Adjustment




Figure 44: CAUTION: Never Stand Directly In Line With The Table Infeed Table. A Kick-back Situation Could Cause Serious Injury.

9. It is important to use the full width of the abrasive sanding belt whenever possible. Feed the stock in alternating areas of the conveyor table to evenly wear the abrasive sanding belts. See Fig. 45. Feeding the stock into the machine in alternating areas of the conveyor table will also give longer life to the components of the machine such as the contact roller, conveyor belt and conveyor table.
10. On earlier sanding passes with coarser abrasive sanding belts, pieces can be fed into the machine at an angle up to 45 degrees. See Fig. 46. When sanding extra long pieces, start the pieces on one side of the conveyor belt. Angle them so the trailing end will exit the machine on the opposite side of the conveyor belt. This will use the whole width of the machine and the abrasive sanding belt. See Fig. 46.
11. When sanding with finer grits, or finishing sanding, to get best results, you need to run the piece straight through the sander in the direction of the grain. See Fig. 47. If you do not, sanding scratches may be more apparent on finished product.




Figure 45: Use Full Width Of Machine



Figure 46: Angle Feed



Figure 47: Straight Feed

Introduction To The Platen

The platen is used only for finish sanding.

NOTE: The platen is not designed for stock removal. Use the platen only for finish sanding. Stock removal should be completed first. See Fig. 48.

NOTE: All sanding marks should be removed with a medium grit belt before finish sanding with a platen.

NOTE: With the stock removal and sanding marks removal completed, you are now ready to use the platen for finish sanding.




Figure 48: Platen And Installation

37" X 60" Model Platen

The platen is removable on the 3760. The platen is not installed on the machine from the factory. Install the platen for the final finishing pass or two of 120 grit or finer belts.

Installing and Using the Platen:

1. Turn off machine by turning the air control to the "off" position.

NOTE: Do not turn air off until sanding belt has come to a complete stop.

2. Open the belt loading door, loosen the sanding head lever and remove the spacer block. See Fig.49.
3. Slide the complete platen between the two bottom rollers on the platen support. See Fig. 49& 50.
4. Replace the spacer block and tighten the sanding head lever.
5. After completing the finish sanding, remove the platen and store for future use. When not in use the platen should be stored in a dry clean area out the way of the operator.




Figure 49: Platen 37"x 60"




Figure 50: Remove Platen After Completing The Finish Sanding Step. 37"x 60" Only

4375 Series Models Platen

The platen is used only for finishing sanding. Complete the following steps for finish sanding on the Model 4375 with the platen:

1. Locate the platen adjustment system. It is located inside the belt loading door. See Fig. 51.
2. Locate the spring loaded adjusting knob. See Fig. 51. The spring loaded adjusting knob can be positioned in any of a series of holes in a half circle formation. See Fig. 51.
3. If the spring loaded adjusting knob is up (as shown in Fig. 51), the platen is up. If the adjusting knob is down, the platen is down. See Fig. 51.
4. The adjustment holes represent various positions for the platen. The adjustment holes enable the platen to have varying degrees of pressure against the material being sanded. The platen comes into contact with the abrasive belt around the middle hole (3:00 position) adjustment. The platen is adjustable up and down a full 1/8".
5. Adjust the platen according to the desired position.
6. Feed your material into the machine keeping an eye on the load meter. The load meter gauge measures the percentage of load on the motor. The machine should not be run when the pointer on the load meter is into the red band area (over 100%). You can reduce the load by slowing down the conveyor table speed, lowering the table, or raising or removing the platen
7. Generally, table height adjustment is not recommended when the platen is in use. Sanding pressure should be solely controlled through the platen adjustment system.
8. After completing the finish sanding, adjust the spring loaded adjustment knob back to the 12 o'clock position to start using your contact roller again. See Fig. 51.




Figure 51: Platen Adjustment System - 43"x75" Only

4375 Platen Removal

To remove the platen, complete the following steps:

1. Lower the platen by turning the platen adjustment knob to the 6:00 position (43" x 75" only.)
2. Release sanding head hold down lever.
3. Remove the sanding spacer block. See Fig. 52.
4. Pull the platen out from the belt loading door. See Fig. 53.

The platen should be inspected periodically for wear. Refer to the platen maintenance instructions in the Maintenance Section.




Figure 52: Platen



Figure 53: Remove Platen As Shown

Maintenance

Repairs

If repairs on your machine are needed beyond your capability, call Safety Speed at 800-772-2327. Safety Speed can provide technical advice or give you the name of a dealer near you who can service your machine.



WARNING: Always disconnect power to the machine before doing any maintenance.



WARNING: Always contact a qualified electrician for any electrical repairs.

Lubrication

The following areas should be lubricated.

Sanding Head, Contact, and Idler Rollers

The sanding head, contact roller, and idler rollers are fitted with grease zerts. Grease the rollers every 20 hours of operation or once a month, whichever time frame is shorter. See Fig. 54 & 55.

Conveyor Table Rollers

The conveyor table rollers should be greased every three to four months.

Bronze Bushings

The bronze bushings are located on the jack screws, hand wheels (not shown) and at the ends of each of the two pinch rollers (not shown). Lubricate the bushings with motor oil every 30 days. See Fig. 56.

Jack Screws

The jack screws that support the conveyor belt should be cleaned with a solvent. The threads should be lubricated with a lithium based grease every 30 days or more often in harsher or heavy use environments. See Fig. 56.



Figure 54: Grease Zerts On Sanding Head Roller




Figure 55: Grease Zerts On Contact Roller




Figure 56: Jack Screw

Conveyor Drive Gear Reducer

The conveyor drive gear reducer is supplied with a life-time lubricant. See Fig. 57.

Swing Arm Top Idler Roller

The swing arm (top idler roller) has a pivot bushing. The bushing should be lubricated with motor oil every 30 days. See Fig. 58.

All Metal Moving Parts

As a general rule of thumb, the metal moving parts of the machines should be lubricated every 30 days.

Drive Motor Belt Tension

Check the tension of the drive motor belt, or belts, every 30 days. The tension can be adjusted by lowering the motor evenly. The belt(s) should only be as tight as needed to prevent the belt from slipping. See Fig. 59.




Figure 57: Conveyor Drive Gear Reducer




Figure 58: Swing Arm Top Idler Roller




Figure 59: Drive Motor Belt Tension

Platen Graphite Replacement

The platen should be inspected periodically for wear. There are three main components to the platen:

1. The platen sleeve. See Fig. 61.
2. The platen graphite. See Fig. 61.
3. The platen felt. See Fig. 61.

Inspect the platen for wear marks that run through the graphite. If the graphite is worn through at any position, the graphite should be replaced with new graphite. Also inspect the white felt between the platen sleeve and the graphite. The white felt pad should have a consistent flat surface. If the surface is not consistent and flat, the felt should be replaced. See Felt Replacement Instructions.

An irregular sanded surface will result from using bad graphite and/or felt.

To replace the platen graphite complete the following steps:

1. Remove the small fasteners that hold the graphite in place. See Fig. 61.
2. Remove the graphite. See Fig. 61.
3. Inspect the white felt underneath the graphite for wear or uneven surface.
4. Replace the graphite and felt if necessary. See Fig. 61.
5. Reassemble and reinstall the platen into the wide belt sander when ready to use.




Figure 60: Platen




Figure 61: Platen Component

Platen Felt Replacement

The platen should be inspected periodically for wear. There are three main components to the platen:

1. The platen sleeve. See Fig. 63.
2. The platen graphite. See Fig. 63.
3. The platen felt. See Fig. 63.

Inspect the platen for wear marks that run through the graphite. If the graphite is worn through at any position, the graphite should be replaced with a new graphite. Also inspect the white felt between the platen sleeve and the graphite. The white felt pad should have a consistent flat surface. If the surface is not consistent and flat, the felt should be replaced. See Felt Replacement Instructions.

An irregular sanded surface will result from using bad graphite and/or felt.

To replace the platen felt complete the following steps:

1. Remove the small fasteners that hold the platen graphite in place. See Fig. 63.
2. Remove the graphite. See Fig. 63.
3. Remove the felt and replace with a new felt. See Fig. 63.
4. Reinstall or replace the graphite. See Fig. 63.
5. Reassemble and reinstall the platen into the wide belt sander. See Fig. 63.




Figure 62: Felt and Graphite




Figure 63: Graphite Platen Cover

Contact Roller Resurfacing

The conveyor table and the contact roller must be exactly parallel with each other. If they are not exactly parallel, the contact roller will wear unevenly into a cone shaped surface.

If uneven wear has not yet occurred refer to the conveyor table leveling procedures in this manual.

If wear has occurred or if rubber is pitted or grooved producing wavy marks in material, it may be necessary to resurface the contact roller.

To resurface the contact roller complete the following steps.

1. Locate a piece of furniture grade particle board or another very flat consistent substrate.
2. Cut it to 18" x 38" for the 37" x 60" model sander or 18" x 44" for the 4375 model sander.
3. Adhere a 60 or 80 grit abrasive sanding belt to the panel, preferably a silicon carbide mineral abrasive.
4. Remove the abrasive sanding belt from the sander.

Lower the table height until no material would be removed on a pass.

5. Press the sanding head start button. See Fig. 65.
6. Press the conveyor start button. See Fig. 65.
7. Adjust the table height so you will remove a minimal amount of rubber from roller.
8. Run the sanding board through the machine. Remove a minimal amount of rubber on each pass until you have removed the defect in the roller.

NOTE: *It is important to adjust the conveyor bed height so the sanding board will just barely come into contact with the contact roller. You must remove a minimal amount of rubber from the roller on each pass. By making these very light passes, you will minimize heat and loading of the abrasive.*

After resurfacing your contact roller it may be necessary to adjust the machine's pinch rollers and the rear idler roller. Refer to pinch rollers and rear idler roller adjustments on page 36.



Figure 64: Contact Roller



Figure 65: Control Panel

Contact Roller Removal/Replacement

To remove the contact roller complete the following steps:

1. Remove the bolt on door on the side of the machine.
2. Remove the drive pulley. This is accomplished by unscrewing the three 1/4" bolts from the hub. Then screw them into the other threaded holes on the hub. See Fig. 66.
3. Unbolt and remove the dust collection chute from the inside of the cabinet. See Fig. 67.
4. Remove the housing bolts from the two bearings on the ends of the contact roller. See Fig. 68.
5. Remove the contact roller. See Fig. 68.

Complete the following steps to remove the contact roller bearing.

1. Loosen and remove the set screws from the bearing. Loc Tite has been used to cement them in place.
2. The bearings have also been cemented with Loc Tite.
3. Pull the bearings off using a gear puller.



CAUTION: Do not grab the cast housing of the bearing with the gear puller. It may cause damage to the bearing or the bearing's cast housing.




Figure 66: Remove Drive Pulley



Figure 67: Remove Dust Chute




Figure 68: Remove Contact Roller

Contact Roller Reinstallation

To reinstall the contact roller complete the following steps:

1. Clean the roller shafts with a solvent such as rubbing alcohol or paint thinner.
2. Clean the inside of the bearing's set screw holes with solvent.
3. Slide the left and right bearings onto the shaft.
4. Install contact roller and bolts starting from right to left.
5. Adjust the contact roller so it measures 2" from the right side wall to the end of the rubber. See Fig. 71. Apply a few drops of Loc Tite to each set screw of the shaft.

Re-leveling The Contact Roller

It is recommended to use a dial indicator to level the roller. If a dial indicator is not available you can use a steel ruler.

To level the contact roller use the same size metal spacers, as shown in Fig. 70, and complete the following steps:

1. Place the metal spacers under the roller, on top of the table. See Fig. 70.

NOTE: *You may also need to roll back the side of the conveyor belt to expose the steel table by loosening the tensioning bolts and then wrapping something around the belts and pulling tight.*

2. Slide the bars under the roller and compare the friction from the right to the left.
3. Loosen the bearing bolts. Slide the roller up or down until it is parallel with the conveyor table.
4. Re-tighten bolts.
5. Reinstall the drive pulley and side cover.




Figure 69: Contact Roller



Figure 70: Two Metal Spacers




Figure 71: Bearing Bolts

6. Lower the front pinch roller back in place. The pinch roller should go up and down about 1/64 inch - 1/32 inch when material passes under it.

Pinch Roller and Idler Roller Replacement

These rollers are positioned parallel to the contact roller. The pinch rollers (one on the in-feed and one on the out-feed) are to be adjusted 1/16" lower than the contact roller. The rear idler roller (steel roller behind the contact roller) is to be positioned 1/16" higher than the contact roller.

The idler roller replacement instructions are very similar to the contact roller re-installation on the previous page. Refer to this section for replacement of the idler roller. See Figures 72, 73, and 74.




Figure 72: Idler Roller



Figure 73: Metal Spacers




Figure 74: Idler Roller

Rear Idler Roller Leveling

To level the rear idler roller complete the following steps:

1. Place two metal spacers of equal height on the conveyor table under both rollers. Figure 75.
2. Raise the table until the material just comes into contact with the contact roller.
3. Loosen the bearing housings on the ends of the rear idler roller.
4. Place spacers on material under steel roller, lifting it about 1/16" above the bottom of the contact roller.




Figure 75: Two Spacers Under Roller

Level The Table

To level the table complete the following steps.

1. Cut a board in half.
2. Send the two boards through the machine sanding both of them at the same time, one board on the right side and the other board on the left side. See Fig 76.
3. Measure the two pieces with a micrometer or a dial calliper. If the table is level the two pieces should measure the same exact thickness.

If they do not measure the same complete the following steps to level the conveyor table.



Figure 76: Send two boards through machine.

Level The Conveyor Table

Complete the following steps to level the conveyor table.

1. Remove the bottom guards.
2. Place shims under the jack screw bearings on the low side of the table. Figure 77.

NOTE: This is a two-person job.

3. Pry up the bearing using two screwdrivers, one from each side. The other person then slides the shim under the bearing.
4. Check the table for corner rock.
5. Lift each corner of the table up and down. The table should be sitting on all four jack screws evenly.
6. Add additional shims as necessary to level the conveyor table.



Figure 77: Jack Screw

Wide Belt Sander Belt Tracking

If the belt is tracking too far one-way or not tracking at all.

Was the belt recently changed? Different grit, manufacturer, backing, weight and construction can effect how the belt tracks.

Check to see if any adjustments have recently been made to the machine, if the #1 or #3 valves have been adjusted to obtain correct belt oscillation.

If the belt will not or is continuously tracking to the right:

1. The first thing to do is to make sure the photo eye, and photo eye reflector are free of debris. Wipe off both the eye and reflector.
2. Check to see if the photo eye is working, to do this remove the belt, and turn the machines air on. If the tracking piston is protruded it can mean two things; either the photo eye does not work or it is not aimed at the reflector, make sure the eye is aimed at the reflector and that the reflector is clean. (Make sure that the motor is OFF) Next, check if the photo eye solenoid is working. To do this turn the air to the machine on and cover the photo eye with something. If the solenoid is working properly the solenoid will make a (clicking) noise and the tracking piston shaft will extend outward. If nothing happens it can mean the solenoid may not work.

If the belt will not or is continuously tracking to the left:

3. The first thing to do is to make sure the photo eye, and photo eye reflector is free of debris. Wipe off both the eye and reflector.
4. Verify the rotation of the sanding belt. It should be turning counter clockwise if looking at it from the loading door. If it is turning clockwise flip the two low leg wires around on the three-phase motor.

If the tracking piston needs to extend out faster open (loosen) the #1 valve, if it needs to extend slower the #1 valve needs to be closed (tighten). If the piston needs to retract faster open (loosen) the #3 valve, if it needs to retract slower close (tighten) the #3 valve. The tracking piston should always be moving in or out to achieve correct oscillation.

If the conveyer is tracking too far in one direction, the tracking screws need to be adjusted.

1. If the belt is tracking too far to the right. (Reverse the sides if tracking too far to the left.)
 - a. Loosen the left tension screw exactly 5 turns. (Has to be exact, before starting to turn note where the wrench is.)
 - b. When the belt tracks back to the middle, tighten the left tension screw exactly 5 turns.

Tighten the right tension screw 1/4 turn and watch the belt for 5 minutes. After the 5 minutes adjust accordingly, but only tighten or loosen a maximum of a 1/4 turn at a time and watch for 5 minutes in between each adjustment. Do not over tighten the bolts, if needed loosen the other side. Over tightening can cause stress on conveyer belt, stripping of the screws, or destruction of the conveyer.

This page was intentionally left blank.

Trouble Shooting

TROUBLE SHOOTING

PROBLEM	CAUSE	SOLUTION
Machine will not start	The machine is equipped with an air cut-out switch. It will prevent the machine from starting if there is not enough air pressure to run the machine.	<ol style="list-style-type: none"> 1. Check for correct air pressure. 2. Check all Emergency Stop switches, one may be tripped. 3. Check power disconnect.
	The sanding belt limit switch is bent or stuck in the “on” position.	You should hear a faint click from the switch when the switch is moved to the left or right. If you do not hear a faint click, the arm is bent and needs to be straightened. A small screwdriver is recommended to bend the switch back into shape.
Unwanted surface marks.	<ol style="list-style-type: none"> 1. After a board has been sanded, you might see chatter, ripple or washboard marks on the surface of the board. NOTE: This might not be apparent until after a board has been finished. 2. This can happen if the settings for the conveyor belt have been adjusted. Example: The four dials inside the control box 3. This can also happen when the conveyor belt is loose on the table due to stretching. The tensioning bolts must be tightened. 	<ol style="list-style-type: none"> 1. To prevent these marks, lower the platen. When the platen is lowered it will sand less per pass and should give you the smooth finish needed. NOTE: Passing the material through the machine twice in the finishing sanding process is recommended for eliminating unwanted surface marks. If the marks are still there, run your conveyor belt slower. This will allow more time for your abrasive sanding to remove the marks. 2. Readjust the four conveyor belt dials inside the control box. The conveyor low voltage control board is on the right hand side inside the control panel. The four white dials should read from the back of machine to front as follows: 10:00, 11:00, 3:00, and 10:30 respectively. 3. Tighten the conveyor belt tensioning bolts. See page 39.

Trouble Shooting

PROBLEM	CAUSE	SOLUTION
	The abrasive sanding belts have a splice. They are usually taped to hold them together. The belt is thicker at this point. Every time the splice comes into contact with the material during the sanding operation it will put a mark onto the material.	To prevent these marks, lower the platen. When the platen is lowered it will sand less per pass and should give you the smooth finish needed. NOTE: Passing the material through the machine twice in the finishing sanding process is recommended for eliminating unwanted surface marks. If the marks are still there, run your conveyor belt slower. This will allow more time for your abrasive sanding to remove the marks.
Wavy marks or groove on your material. These marks are not horizontal like a washboard in the previous problem, they are vertical (in-feed to out-feed direction).	These marks are caused by the following: 1. Grooves in your contact roller. 2. Build-up on your contact roller. 3. A worn out platen. 4. A dull spot on your abrasive sanding belt.	1. Replace the platen material. 2. Replace the abrasive sanding belt. 3. Clean the contact roller. 4. Resurface the contact roller. 5. Replace the contact roller.
The sanding belt tracks to the right until it shuts the machine down.	Sometimes foreign matter enters the air lines. This debris lodges in the No.1 air valve. The No.1 air valve is the valve that is located on the far left of the machine. Air cannot pass through the air valve, therefore, the tracking piston does not come out and cannot pivot the top roller. The belt continues to go to the right side until it shuts the machine off.	Open the number 1 air valve. This will allow the debris to travel through the air valve and exit the machine. This will make the belt track towards the left. The valve should then be closed down until the sanding belt tracks slow again. This adjustment must be done when the unit is running so you can see the top roller move. WARNING: Be very careful not to come into contact with any moving parts. Do not wear neckties, gloves or long sleeves when performing this maintenance. Watch the top roller. Close the valve until the roller moves slow.
Belt Tracks Off	Due to 3~ electrical incorrectly installed.	Wiring is opposite causing contact roller to spin clockwise versus counter clockwise. Reverse the two low legs, L1 & L2.

PROBLEM	CAUSE	SOLUTION
<p>The belt still tracks to the right.</p>	<p>The solenoid valve is not working properly or the electric eye is not working.</p> <p>The electric photo eye light beam is not hitting the reflector.</p>	<ol style="list-style-type: none"> 1. Remove the right side cover, exposing the tensioning piston and top roller. 2. Remove the back door on the model 3760 or 4375. 3. Turn the air control to the “on” position. Remove the abrasive sanding belt. With the motor in the “off” position, place your hand in between the reflector and the eye. This will block the invisible beam. <p>Check to see if tracking piston is extended. If it is, then that means that there is something wrong with the eye. (Example: fake signal, misaligned, dirty)</p> <p>You should hear the solenoid click on and off. If you do not, either the eye’s invisible light beam is not getting to and from the reflector or the solanoid valve is not working or the eye is not working.</p> <p>Check if the light beam is hitting the reflector. Complete the following steps to ensure the light beam is hitting the reflector:</p> <p>Place a reflective surface against the lense of the photoeye. If there is still no clicking heard and piston action seen, move the reflector in front of the eye. If the eye is bad or the solanoid is bad, test both with a volt meter or 110 volt test light. ONLY A LICENSED ELECTRICIAN SHOULD COMPLETE THE FOLLOWING TEST.</p> <ol style="list-style-type: none"> 1. Disconnect power from the machine. Remove the electrical box cover. Place a screw in one corner of the cover with the cover back facing towards you. Screw the cover corner to the electrical box corner facing the rear. 2. Reconnect power to the machine. <p>CAUTION: Do not touch any bare wires with hands or any un-insulated tools. Serious electrical shock may occur.</p>

PROBLEM	CAUSE	SOLUTION
<p>Sanding belt tracks to the left.</p>	<p>Foreign matter can get into the air line. The debris moves around and lodges in the air valve. This blocks the air flow from the belt tracking piston. Without air exhausting from the tracking piston, the piston will stay out. The belt will continue to track to the left side of the machine until it hits the safety switch. This shuts down the machine.</p>	<p>Open the No. 3 air valve a turn or two. Foreign matter will move through the air valve and exit the machine. This will allow the air to escape from the air piston. This allows the piston to move back. The sanding belt will then track towards the right side of the machine again. With the air valve open this much, the belt will track back to the right very fast. The valve then has to be closed down until the sanding belt tracks slow again. This adjustment must be done when the machine is running.</p> <p>WARNING: Be very careful not to come in contact with any moving parts. Do not wear neck ties, gloves or long sleeves. Serious injury could result.</p> <p>If the belt continues to track to the left, make sure it is going in the opposite direction of the material that is feeding into the machine. In other words, the rubber contact roller should be turning counter-clockwise when looking at it from the belt loading door See Page 40.</p>
<p>The sanding belt tracks perfectly without any load, but does not track perfectly when sanding material.</p>	<p>The bottom rollers are not parallel with each other.</p>	<p>Leave the rubber contact roller in place. Adjust the rear steel idler roller. See Page 36 and 37.</p>

4375 Exploded View & Parts List

A.




Figure 78



Figure 79

Key	Part Number	Description
1.	WB612	Front Guard
2.	WB626	Front Face Plate
	WB513	Height Indicator
3.	WB611	Conveyor Guard
4.	WB651	E-Stop Handle
5.	WB616	Front Lower Panel
6.	WB660	Control Panel Cover
7.	WB36B	Gummy Belt
8.	WB610	Table
9.	WB662	Door Handle
	WB663	Door Latch



Figure 80



Figure 81

Key	Part Number	Description
1.	WB613	Left Side Door
2.	WB638	Table Lift Assembly:
	WB544	Table Wheel Handle
	WB516-43	Table Lift Handle
	WB109	Handle Support Plate
	WB54	(2) Bushings
		Bevel Gear
3.	WB607	Left Lower Panel
4.	WB622	Ruler Indicator
5.	WB131	Front Table Roller
6.		Belt Tension Adjust Bolt
7.	WB132	Rear Table Roller
8.	WB658	(2) Rear Table Roller Bearings
9.	WB624	Left Side Table Guard
10.	WB621	Curved Guard
11.	WB662	Door Handle
	WB663	Door Latch




Figure 82




Figure 84



Figure 85



Figure 83

Key	Part Number	Description
1.	WB615	Right Side Panel
2.	WB101	DC Motor
3.	WB102	Gear Reducer
	WB79	Roller Gear (30 tooth)
	WB38	Reducer Gear (15 tooth)
	WB539-43	Reducer Chain
4.	WB705	Lower Reducer Guard
5.	WB668	E-Stop Rod Spring (5) Washers (2) Cotter Pins
6.	WB69	E-Stop Switch
7.	WB704	Upper Reducer Guard
8.	WB510	E-Stop bushing

Key	Part Number	Description
1.	WB614	Rear Panel
2.	WB616	Lower Rear Panel
3.	WB608	Top Cover Panel




Figure 86



Figure 88




Figure 87




Figure 89

Key	Part Number	Description
1.	WB617	Dust Vent
2.	WB16	Pressure Gauge
3.	WB14	Photo Eye
4.	WB623 WB105C	Photo Eye Holder 1/4 x 1/4 NPT, 90
5.	WB543	Photo Eye Reflector
6.	WB68 WB115RH	Right Limit Switch: Limit Switch Right Limit Switch Cover
7.	WB76	Limit Switch Spring
8.	WB605	Platen Shaft
9.	WB634	Platen Holder
10.	WB89	(2)Platen Spring

Key	Part Number	Description
1.	WB128	Swing Arm Roller
2.	WB135 WB659	Left Swing Arm Bearing Swing Arm Block
3.	WB618	Swing Arm
4.	WB 68 WB115LH WB76	Left Limit Switch: Limit Switch Left Limit Switch Cover Limit Switch Spring
5.	WB112	Left Contact Roller Bearing
6.		Right Limit Switch (see Figure 87 Key #6)
7.	WB129	Contact Roller
8.	WB100	Right Contact Roller Bearing
9.	WB628	Swing Arm Busing Bracket
10.	WB545	Swing Arm Shaft Bushing
11.	WB200-43	Tension Piston
12.	WB658	Right Swing Arm Bearing
13.	WB15	Air Regulator




Figure 90



Figure 92




Figure 91



Figure 93

Key	Part Number	Description
1.	WB112	Left Contact Roller Bearing
2.	WB137	Front, Left Pinch Roller Bracket
3.	WB130	Pinch Roller
4.	WB100	Right Contact Roller Bearing
5.	WB137	Front, Right Pinch Roller Bracket
6.	WB129	Contact Roller
	WB133	Contact Roller Kit

Key	Part Number	Description
1.	WB658	Right Idler Roller Bearing
2.	WB137	Rear, Right Pinch Roller Bracket
3.	WB642 WB110	Rear, Right Jackscrew Cap Jackscrew Cap Bushing
4.	WB127	Idler Roller
5.	WB658	Left Idler Roller Bearing
6.	WB130	Pinch Roller
7.	WB137	Rear, Left Pinch Roller Bracket (Bracket Flipped)
8.	WB640 WB110	Rear, Left Jackscrew cap Jackscrew Cap Bushing
9.	WB719	Rear, Right Jackscrew
10.	WB40	Jackscrew Bearing
11.	WB719	Rear, Left Jackscrew
12.	WB40	Jackscrew Bearing



Figure 94



Figure 95




Figure 96




Figure 97

Key	Part Number	Description
1.	WB74	(3) Swing Arm Spring
2.	WB202	Swing Arm Piston

Key	Part Number	Description
1.	WB719 WB53	Front, Left Jackscrew With Bevel Gear
2.	WB40	Jackscrew Bearing
3.	WB538-43	Table Chain
4.	WB719	Front, Right Jackscrew
5.	WB40	Jackscrew Bearing
6.	WB62 WB65 WB66	Sander Motor - 10 HP Sander Motor - 20 HP Sander Motor - 30 HP
7.	WB52	Idler Gear
8.	WB629	Chain Adjustment Bracket
9.	WB641 WB110	Front, Left Jackscrew Cap Jackscrew Cap Bushing
10.	WB643 WB110	Front, Right Jackscrew Cap Jackscrew Cap Bushing
11.	WB23	(4) Table Bushing
12.	WB528	(4) Jackscrew Nut




Figure 98




Figure 99

Key	Part Number	Description
1.	WB108	Roller Bushing - 10 HP
	WB106	Roller Bushing - 20 HP
	WB106	Roller Bushing - 30 HP
2.	WB104	Roller Pulley - 10 HP
	WB656	Roller Pulley - 20 HP
	WB547	Roller Pulley - 30 HP
3.	WB541	Brake Block Wood
4.	WB201	Brake Piston
5.	WB657	(2) Belts - 10 HP
	WB654	(3) Belts - 20 HP
	WB654	(4) Belts - 30 HP
6.	WB103	Motor Pulley - 10 HP
	WB655	Motor Pulley - 20 HP
	WB548	Motor Pulley - 30 HP
7.	WB107	Motor Bushing - 10 HP
	WB113	Motor Bushing - 20 HP
	WB550	Motor Bushing - 30 HP

Key	Part Number	Description
1.	WB18	Low Air
2.	WB540	Ground Bar
3.		Neutral and Hot Bar
4.	WB17	Main Contact
5.	WB556	Fuse Holder
	WB557	Fuse
6.	WB98	Current Transformer
7.	WB11	Brake Contact
8.	WB11	Table Contact
9.	WB77	N/O Contact Block/Bracket
10.	WB77	N/O Contact Block/Bracket
	WB111	N/C Contact Block Only
11.	WB95	N/C Contact Block/Bracket
12.	WB77	N/O Contact Block/Bracket
13.	WB95	N/C Contact Block/Bracket
14.	WB13	DC Drive Variable Speed Controller
15.	WB95	N/C Contact Block/Bracket
	WB96	N/O Contact Block Only
16.	WB652	Inside Electrical Panel




Figure 100

Key	Part Number	Description
1.	WB78	On/Off Legend Air
2.	WB93	On/Off Switch Air
3.	WB90	Push Button, Green
4.	WB91	Push Button, Red
5.	WB92	Push Button, Yellow
6.	WB91	Push Button, Red
7.	WB13	Conveyor Feed Rate Adjustment Switch
8.	WB67	Load Meter
9.	WB84	E-Stop Mushroom Switch




Figure 101

Key	Part Number	Description
1.	PS516	Air Hose
2.	WB105A	1/4 x 1/4 NPT, strait
3.	WB 703	Air Fitting, Female
4.	WB12 WB105C	#1 Solenoid Solenoid 1/4 x 1/4 NPT, 90 Long Threaded Tube
5.	WB12 WB105C WB105E	#2 Solenoid Solenoid (2) 1/4 x 1/4 NPT, 90 Threaded Tube 1/4 x 1/8 Flow Control Valve
6.	WB12 WB105C	#3 Solenoid Solenoid (2) 1/4 x 1/4 NPT, 90
7.	WB105E	(2) 1/4 x 1/8 Flow Control Valve
8.	WB105D	(2) 1/4 Tube Tee
9.	WB105F	1/4 x 1/8, 90





Figure 102

Key	Part Number	Description
1.	WB713 WB627 WB34 WB31	Platen Kit Complete Platen Holder, Galvanized 1005 Pressed White Felt, 43" Platen Graphite
2.	WB637	Hold Down Clamp
3.	WB666 WB72	Platen Adjustment Pin Platen Pin Spring
4.	WB138	Safety Switch
5.	WB710	Safety Switch Bracket
6.	WB139	Door Key

3760 Exploded View & Parts List



Figure 103




Figure 105



Figure 104



Figure 106

Key	Part Number	Description
1.	WB502	Front Upper Panel
2.	WB505	Front Lower Panel
3.	WB534	Control Panel
4.	WB518 WB513	E-Stop Bar Height Indicator
5.	WB140	Pressure Gauge
6.	WB15	Air Regulator
7.	WB511	Front Table Guard
8.	WB36	Gummy Belt
9.	WB83	Front Table Roller
10.	WB531	Table Height Indicator: Ruler Indicator 8 1/2" Ruler
11.	WB507	Table
12.	WB75	E-Stop Spring (Behind Bar)
13.	WB105E	(2) Flow Control Valves (Air Adjustments Valves)

Key	Part Number	Description
1.	WB67	Load Meter
2.	WB93 WB78	On/Off Air Switch On/Off Legend
3.	WB90	Push Button Knob, Green
4.	WB91	Push Button Knob, Red
5.	WB92	Push Button Knob, Yellow
6.	WB91	Push Button Knob, Red
7.	WB13	Conveyor Feed Rate Adjustment Switch (See DC Switch Board)
8.	WB94	Red Mushroom E-Stop
9.	WB508	Dust Chute
10.	WB506	Top Panel
11.	WB105	Quick Air Connect, Male
12.		Clamp (Main Power) Supply Entry




Figure 107




Figure 108

Key	Part Number	Description
1.	WB542	Door Handle
2.	WB501	Left Side Door Panel
3.	WB85 WB40	Rear Table Roller (2) Rear Roller Bearing (Both Sides)
4.	WB504	Lower Left Side Panel
5.		Table Tension Bolt (7/16 - 14 x 4, grade 5)
6.	WB516 WB544 WB10 WB109 WB54	Table Lift Handle: Handle Support Plate Handle Grip Wheel Handle (2) Bushings Handle Bevel Gear




Figure 109

Key	Part Number	Description
1.	WB500	Right Side Panel
2.	WB60	DC Motor
3.	WB61 WB56 WB51 WB539	Reducer Conveyor Gear (21 tooth) Roller Gear (12 tooth) Conveyor Chain
4.	WB536	Reducer Guard
5.	WB69	E-Stop Switch




Figure 110

Key	Part Number	Description
1.	WB503	Rear Top Panel
2.	WB505	Rear, Lower Panel




Figure 111




Figure 112

Key	Part Number	Description
1.	WB543	Photo Eye Reflector
2.	WB537	Photo Eye Holder
3.	WB105C	1/4 x 1/4 NPT, 90
4.	WB14	Photo Eye
5.	WB68	Limit Switch (right)
	WB115-RH	Limit Switch Cover RH
6.	WB76	Limit Switch Spring
7.	WB519	Wire Strap
8.	WB710	Door Safety Switch
		Door Switch Bracket
9.	WB508	Dust Chute



Figure 113




Figure 114



Figure 115



Figure 116

Key	Part Number	Description
1.	WB82	Swing Arm Roller
2.	WB44	Left Swing Arm Bearing
3.	WB521	Swing Arm
4.	WB68	Left Limit Switch:
	WB115LH	Limit Switch
	WB76	Left Limit Switch Bracket
		Limit Switch Spring
5.	WB530	Platen Holder
6.	WB535	Swing Arm Bushing Bracket
7.	WB23	Swing Arm Bushing
8.	WB200	Tension Piston
9.	WB525	Front, Left Jackscrew Cap
10.	WB524	Front, Right Jackscrew Cap

Key	Part Number	Description
1.	WB43	Right Contact Roller Bearing
2.	WB80	Contact Roller
	WB522	Contact Roller Kit
3.	WB137	Front, Right Pinch Roller Bracket
4.	WB81	Front Pinch Roller
5.	WB137	Front, Left Pinch Roller Bracket




Figure 117




Figure 119



Figure 118




Figure 120




Figure 121

Key	Part Number	Description
1.	WB84	Idler Bottom Roller
2.	WB41	(2) Contact Roller Bearings (Both Sides)
3.	WB137	Rear, Right Pinch Roller Bracket
4.	WB253	Rear, Right Jackscrew Cap
5.	WB81	Pinch Roller (Not Shown in Photo)
6.	WB137	Rear, Left Pinch Roller Bracket
7.	WB517	Rear, Left Jackscrew Cap
8.	WB515	Rear, Right Jackscrew
9.	WB41	Rear, Right Jackscrew Bearing
10.	WB515	Rear, Left Jackscrew
11.	WB41	Rear, Left Jackscrew Bearing
12.	WB41	Right Swing Arm Bearing

Key	Part Number	Description
1.	WB515	Front, Left Jackscrew W/ 30 Tooth Bevel Gear
2.	WB53	DC Front, Left Jackscrew Bearing
3.	WB538 PS862	Table Chain Master Link
4.	WB515	Front, Right Jackscrew
5.	WB41	Front, Right Jackscrew Bearing
6.	WB62 WB64	10 HP Motor - 10 HP 15 HP Motor - 15 HP
7.	WB52	Idler Gear
8.	WB629	Chain Adjustment Bracket
9.	WB22	(4) Jackscrew Nut Bushing
10.	WB118	(4) Jackscrew Nut




Figure 122



Figure 123




Figure 124

Key	Part Number	Description
1.	WB540	Ground Bar
2.		Neutral and Hot Bar
3.	WB17	Main Contact
4.	WB19	Thermal Overload - 15 HP
5.	WB98	Current Transformer
6.	WB11	Brake Contact
7.	WB11	Table Contact
8.	WB77	N/O Contact Block/Bracket
9.	WB77 WB111	N/O Contact Block/Bracket N/C Contact Block Only
10.	WB95	N/C Contact Block/Bracket
11.	WB77	N/O Contact Block Bracket
12.	WB95	N/C Contact Block Bracket
13.	WB13	DC Drive Variable Speed Controller
14.	WB95 WB96	N/C Contact Block Bracket N/O Contact Block Only
15.	WB18	Low Air
16.	WB652	Inside Electrical Panel
17.	WB557 WB556	Fuse Fuse Holder

Key	Part Number	Description
1.	WB74	(3) Swing Arm Springs
2.	WB202	Swing Arm Piston
3.	WB57 WB104	Roller Pulley - 10 HP Roller Pulley - 15 HP
4.	WB46 WB107	Roller Bushing - 10 HP Roller Bushing - 15 HP
5.	WB50 WB134	Belt - 10 HP (2) Belts - 15 HP
6.	WB541	Brake Block, Wood
7.	WB201	Brake Piston
8.	WB47 WB103	Motor Pulley - 10 HP Motor Pulley - 15 HP
9.	WB46 WB108	Motor Bushing - 10 HP Motor Bushing - 15 HP




Figure 125




Figure 126

Key	Part Number	Description
1.	WB12 WB105A WB105C	#1 Solenoid: Solenoid 1/4 x 1/4 NPT, Strait 1/4 x 1/4 NPT, 90
2.	WB12 WB105C WB105B	#2 Solenoid: Solenoid (2) 1/4 x 1/4 NPT, 90 Threaded Collar 1/4 x 1/8 NPT, Strait
3.	WB12 WB105	#3 Solenoid: Solenoid (2) 1/4 x 1/4 NPT, 90
4.	PS516R	1/4" Red Poly Tubing (Air Hose)
5.	WB105B	1/4 x 1/8 NPT, Strait
6.	WB105D	(2) 1/4 Tube Tee
7.	WB710 WB105E WB105F	Air Adjustment Bracket (2) 1/4 x 1/8 Flow Control (2) 1/4 x 1/8 NPT, 90
8.	WB15 WB105C WB105F WB105E	Air Regulator 1/4 x 1/4 NPT, 90 1/4 x 1/8 NPT, 90 1/4 x 1/8 Flow Control




Figure 127



Figure 128





Figure 129

Key	Part Number	Description
1.	WB533	Belt Spacer Block
2.	WB637	Clamping Handle
3.	WB512 WB509 WB33 WB30	Platen Complete Platen, galvanized 1005 Pressed White Felt Platen Graphite
4.	WB139	Flexible Door Key Safety Switch
5.	WB138	Safety Switch



SEE LOCAL ELECTRICAL CODE FOR BEST WIRING PRACTICES

NOTE: IF MEASURED SUPPLY POWER INDICATES A HIGH LEGS, ATTACH THAT PHASE TO CONSOLE.

SYMBOL	DESCRIPTION
AM	AIR VOLTAGE
CON	CONVERTER
DR	DRUM
DS	DRUM SWITCH
ES	EMERGENCY STOP
F	FUSE
LS	LIMIT SWITCH
PB	PUSH BUTTON
PC	PHOTO DISC PRESSURE SWITCH
PE	PHOTO EYE
SOL	SOLENOID
SS	SAFETY SWITCH
SW	SWITCH
TR	TRANSFORMER
MTR	MOTOR
VR	VARIABLE RESISTOR

USA	CANADA
100V - 60 Hz	200V - 60 Hz
115V - 60 Hz	230V - 60 Hz
120V - 60 Hz	240V - 60 Hz
125V - 60 Hz	250V - 60 Hz
130V - 60 Hz	260V - 60 Hz
135V - 60 Hz	270V - 60 Hz
140V - 60 Hz	280V - 60 Hz
145V - 60 Hz	290V - 60 Hz
150V - 60 Hz	300V - 60 Hz
155V - 60 Hz	310V - 60 Hz
160V - 60 Hz	320V - 60 Hz
165V - 60 Hz	330V - 60 Hz
170V - 60 Hz	340V - 60 Hz
175V - 60 Hz	350V - 60 Hz
180V - 60 Hz	360V - 60 Hz
185V - 60 Hz	370V - 60 Hz
190V - 60 Hz	380V - 60 Hz
195V - 60 Hz	390V - 60 Hz
200V - 60 Hz	400V - 60 Hz
205V - 60 Hz	410V - 60 Hz
210V - 60 Hz	420V - 60 Hz
215V - 60 Hz	430V - 60 Hz
220V - 60 Hz	440V - 60 Hz
225V - 60 Hz	450V - 60 Hz
230V - 60 Hz	460V - 60 Hz
235V - 60 Hz	470V - 60 Hz
240V - 60 Hz	480V - 60 Hz
245V - 60 Hz	490V - 60 Hz
250V - 60 Hz	500V - 60 Hz

OPTIONAL TABLE RISE/LOWER TO HOUR METER

UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES.
 DIMENSIONS ARE IN MILLIMETERS.
 UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN MILLIMETERS.
 DIMENSIONS ARE IN INCHES.
 UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN MILLIMETERS.
 DIMENSIONS ARE IN INCHES.


REV	DATE	BY	DESCRIPTION
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

WILL BEI SANDER
 220V 1 PHASE
 SCALE: 3/16" = 1"

SAFETY SPEED
 SAFETY SPEED CONTROL UNIT
 SAFETY SPEED CONTROL UNIT
 SAFETY SPEED CONTROL UNIT

WILL BEI SANDER
 220V 1 PHASE
 SCALE: 3/16" = 1"

1-Phase Wiring Schematic



NOTE:
IF MEASURED SUPPLY POWER INDICATES A
HIGH LEG, ATTACH THAT PHASE TO CONDUIT 3

DEVICE / DESCRIPTION	PE	PHOTO EYE
AMP METER	PS	PRESSURER SWITCH
CON	SOL	SOLENOID
DRIVE	SS	SAFETY SWITCH
EMERGENCY STOP	SW	SAFETY SWITCH
FUSE	T	TRANSFORMER
LIMIT SWITCH	MTR	MOTOR
PUSH BUTTON	VR	VARIABLE RESISTOR

USA	CANADA
(000) - (01)	(000) - (01)
(000) - (02)	(000) - (02)
(000) - (03)	(000) - (03)
(000) - (04)	(000) - (04)
(000) - (05)	(000) - (05)
(000) - (06)	(000) - (06)
(000) - (07)	(000) - (07)
(000) - (08)	(000) - (08)
(000) - (09)	(000) - (09)
(000) - (10)	(000) - (10)

WILLY BEEL SANDER
230V 3 PHASE

DATE	BY	REV
01/11/2011	WBS	1
02/11/2011	WBS	2
03/11/2011	WBS	3
04/11/2011	WBS	4
05/11/2011	WBS	5
06/11/2011	WBS	6
07/11/2011	WBS	7
08/11/2011	WBS	8
09/11/2011	WBS	9
10/11/2011	WBS	10
11/11/2011	WBS	11
12/11/2011	WBS	12

3-Phase Wiring Schematic