



INSTRUCTIONS AND PARTS LIST FOR Models 33-493 Electric Tire Press

II. OPERATION AND CONTROL

B. HOIST

2. **CAUTION!** *Place the hoist crank on the lift drum shaft. The table is raised to the desired height by turning the crank after removing the table pins. Check to make sure the hoist cable is tracking correctly. Run the table channels from top to bottom. The cable should be on each of the two upper pulleys and should track back and forth on the cable drum. Always place table pins under the table channels when servicing or tracking the cable. If a tracking problem exists, contact the Dake factory for instructions. Be sure all table pins are fully inserted in place before applying pressure. Always remove or release pressure on the cable before pressure is applied.*

724 Robbins Road
Grand Haven, MI 49417

Phone (616) 842-7110 (800) 937-3253
Fax (616) 842-0859 (800) 846-3253
Web: www.dakecorp.com
E-Mail: customerservice@dakecorp.com



NO. 33-493 ELECTRIC POWERED HYDRAULIC TIRE PRESS

I. SETTING UP PRESS FOR OPERATION

This press was shipped set-up ready for operation. Have an electrician connect the starter (Item 98) to a power line. The pump can rotate in either direction.

II. OPERATION AND CONTROL

A. RAM MOVEMENT

To raise the ram, turn the release valve handle (Item 81) clockwise so that the release valve (Item 74) is closed. Then press the "raise" button (Item 97) to raise the ram. The ram will raise as long as the operator presses the "raise" button. Ram movement can be stopped at any time by releasing the "raise" button.

After the work has been contacted the press will build pressure. The press will continue to build pressure as the ram advances until the press reaches its maximum tonnage. At this point the relief valve (Item 69) will open allowing oil to return back to the reservoir.

When the ram reaches its maximum stroke of twelve (12) inches the guide angle (Item 101) will contact the stroke limit switch arm (Item 100) tripping the stroke limit switch (Item 99). This opens the electrical circuit to the motor stopping it and preventing the ram from moving any further.

To release pressure and lower the ram, turn the release valve handle (Item 81) counterclockwise to open the release valve (Item 74). This permits the oil to return to the reservoir and the ram to lower.

B. HOIST

The hoist hand crank (Item 17) is provided to raise or lower the upper platen (Item 15) to the proper height for work. To change the vertical position of the upper platen sufficient tension must first be applied to the hoisting cable (Item 32) to permit removal of the table pins (Item 13). The upper platen may then be raised or lowered to the desired position. Then all of the table pins must be inserted.

NOTE: Be sure all table pins are in place before applying any pressure. Also slacken the cable. It is advisable to lower the upper platen one or two holes rather than run the ram and lower platen to the end of its stroke.

III. MAINTENANCE

A. IF OIL LEAKS UP AROUND PISTON —

1. Oil above piston leather:

If the rated stroke of the press is exceeded repeatedly by running the piston so as to uncover the by-

pass hole in the side of the cylinder, the small amount of oil which drains back from the bypass line will collect above the piston leather. Eventually enough may accumulate so that when the piston, is brought to the top of its stroke, oil is forced out between the piston guide and the piston.

This can be remedied by disconnecting the bypass tube line (Item 95) from the cylinder. Then raising the piston slowly to about $2\frac{1}{2}$ " less than its rated stroke allowing the oil above the piston cap to overflow out the bypass hole into a clean can. Replace the tube line. The oil can be put back into the reservoir by removing the fill plug on the top of the reservoir.

B. IF PRESS DOES NOT HOLD PRESSURE —

1. Loose tube connections:

Check all connections and tighten any loose tube nuts.

2. Dirt under release valve ball (Item 77):

To correct this condition, remove the release valve rod, packing nut, packing, and ball. Clean out the valve seat. Reseat the valve ball using a brass rod as a drift and tapping lightly. Reassemble the valve.

If this occurs frequently, the oil should be drained from the reservoir. Then flush the reservoir to remove dirt. Refill the reservoir using Mobil D.T.E. 26 or its equivalent hydraulic oil. The oil must be filtered carefully to remove any foreign substances. Remove $3/4"$ pipe plug (Item 48) and $1/8"$ pipe plug on the side of the reservoir. Fill with oil until oil reaches the $1/8"$ pipe tapped hole (7 gallons). Then replace both plugs.

NOTE: Before filling the reservoir with oil check to see if ram is all the way down. Otherwise over filling could occur.


3. Worn cup leather:

If neither of the previous conditions seems to have been the cause of the press not holding pressure, the trouble may be that the piston leather is worn out or damaged. To inspect the leather, it is best to first remove the lower platen (Item 34). Next remove cap screws which bolt the piston guide to the cylinder flange. Piston and piston guide may now be lifted out of the cylinder and inverted. The leather can now be inspected and replaced if necessary. Reassemble the press being careful not to damage the lip of the leather cup as it enters the cylinder.

C. IF PRESS DOES NOT DEVELOP RATED TONNAGE —

1. Dirt under release valve ball:

Refer to Section B2 above.



ALL PARTS PRICES INCREASED 10%
EFFECTIVE JANUARY 1, 1987

ITEM PART NO.	PART NAME	NO. REQ'D	ITEM PART NO.	PART NAME	NO. REQ'D
1 47411	Frame.....	1	48 1745	3/4" Pipe Plug	1
2 1651	Base Angles.....	2	49 1567	1/4" Pipe Plug	1
3 43365	5/8"-11 x 1-3/4" Hex Cap Screws	4	50 589	1/8" Pipe Plug	1
.. 43648	5/8" Lockwashers	4	51 588	3/8" Pipe Plug	1
.. 43917	5/8"-11 Hex Nuts	4	52 29571	Breather Filter.....	1
4 1819	Stop Blocks.....	4	46051	Oil (7 Gallons Required)	1
5 43348	1/2"-13 x 1-1/4" Hex Cap Screws	8	43647	1/2" Lockwashers	6
.. 43647	1/2" Lockwashers	10	53 43345	1/2" x 3/4" Hex Cap Screws	6
6 2252	"Dale" Name Plate	1	54 36509	Pump & Motor Base	1
7 43876	No. 6-32 x 1/4" Self-Tapping Screw	4	55 2248	Washer - Neoprene	4
8 607	Model No. Plate	1	.. 43645	3/8" Lockwasher	4
9 43573	No. 2 x 3/16" Drive Screws	2	.. 56 43330	3/8" x 1-1/4" Hex Cap Screws	4
10 1812	Head Channels	2	57	Motor	1
11 1553	Table Spacers	4	.. 58 43314	5/16"-18 x 3/4" Hex Cap Screws	4
.. 43649	3/4" Lockwashers	12	.. 59 43644	5/16" Lockwashers	4
12 43919	3/4"-10 Hex Nuts	8	.. 60 43315	Pump Support	1
13 1555	Table Pins	6	.. 61 43644	5/16"-18 x 1" Hex Cap Screws	4
14 44062	3/8" x 2-1/2" Groove-Pins	6	.. 62 950106	Coupling	1
15 1813	Upper Platen	1	.. 63 43469	Pump	1
16 43373	3/4"-10 x 2" Hex Cap Screws	4	.. 64 36761	1/2"-13 x 1" Soc. Hd. Cap Screws	4
17 701653	Crank Assembly	1	.. 65 1567	1/4" Pipe Plug	1
18 739	Hoist Frame	1	.. 66 58227	3/4" x 3/4" FF-S Parker Pipe Nipple	1
19 740	Cable Drum	1	.. 67 37976	Connector Block	1
20 741	Drum Shaft	1	.. 68 1739	3/4" x 2-1/2" Pipe Nipple - Extra Strong	1
21 745	Drum Shaft Key	1	.. 69 29650	Relief Valve - (Set at 6000 psi)	1
22 743	Worm Gear	1	.. 70 712016	Intake Line (Reservoir - Dale Pump)	1
23 43983	Nat'l. Retaining Ring No. XSO-247	2	.. 71 712017	.. 1657 Hex Reducer 3/4"-3/8" - (In Reservoir) Steel	1
24 744	Worm	1	.. 72 1252	.. 17999 1/2" Tube Elbow (In Pump)	1
25 742	Worm Shaft	1	.. 73 18249	.. 71 72010 Tube Assembly (Dale Pump - Relief Valve)	1
26 746	Worm Key	1	.. 74 710557	.. 1752 Release Valve "Section A"	1
27 43982	Nat'l. Retaining Ring No. XSO-239	2	.. 75 1752	.. 76 1935 Release Valve Block	1
.. 700111	Hoist Assembly (Items 17 thru 27)	1	.. 76 1936	.. 77 1936 Ball Retainer	1
.. 43349	1/2"-13 x 1-1/2" Hex Cap Screws	2	.. 78 47946	.. 80 1931 Handle	1
28 1809	Cable Pulley	2	.. 79 1937	.. 81 2230 Washer	1
29 1810	Cable Pulley Shaft	1	.. 80 1931	.. 82 898 Valve Rod Packing (7 Req'd.)	1
30 1563	Cable Pulley	2	.. 81 2230	.. 83 6203 Valve Rod	1
31 1811	Cable Pulley Shaft	1	.. 82 898	.. 84 47948 Release Valve Spacer	1
.. 43978	Nat'l. Retaining Ring No. XSO-230	6	.. 83 6203	.. 84 43334 3/8"-16 2-1/4" Hex Cap Screws	2
32 1837	Cable	1	.. 85 47947	.. 85 43645 3/8" Lockwashers	2
33 583	Cable Clamps - 1/4"	4	.. 86 2025	.. 86 2025 Gauge - 150 Ton	1
34 1798	Lower Platen	1	.. 87 45387	.. 87 45387 Pulse Damper	1
35 24569	3/4" x 3-1/4" 12 Pt. Cap Screws	4	.. 88 44179	.. 88 44179 1/2" x 1-1/2" Pipe Nipple - Extra Strong	3
.. 36863	Decal "Warning - End of Stroke"	1	.. 89 712018	.. 89 712018 Tube Assembly (Release Valve-Release Valve)	1
36 1793	Cylinder	1	.. 90 17999	.. 90 17999 1/2" Tube Elbow	1
37 589	1/8" Pipe Plug	2	.. 91 7074	.. 91 7074 Tube Assembly (Release Valve to Cylinder)	1
38 1796	Piston	1	.. 92 1944	.. 92 1944 7/8" Tube Elbow	1
.. 1567	1/4" Pipe Plug	1	.. 93 1943	.. 93 1943 7/8" Straight Fittings	3
39 31871	Piston Guide	1	.. 94 712019	.. 94 712019 Tube Assembly - By-Pass (Cylinder-Reservoir)	1
.. 43358	1/2"-13 x 4" Hex Cap Screws	6	.. 95 1247	.. 95 1247 3/8" Straight Fittings	2
.. 43359	1/2"-13 x 4-1/2" Hex Cap Screws	4	.. 96 1102	.. 96 1102 Hex Reducer 3/8"-1/4" (Steel)	1
.. 43916	1/2"-13 Hex Nuts	10	.. 97 1156	.. 97 1156 1/4" x 1-1/2" Pipe Nipple - Extra Strong	1
.. 43647	1/2" Lockwashers	10	.. 98 1099	.. 98 1099 1/4" Pipe Elbow 300#	1
40 30425	Piston Cap	1			
.. 41 1539	Piston Leather & Heli Washer	1			
42 1536	Supporting Ring	1			
.. 43332	3/8"-16 x 1-3/4" Hex Cap Screws	8			
.. 43645	3/8" Lockwashers	8			
1 43 1871	Oil Seal	1			
.. 44 52478	Retainer	3			
.. 45 31399	#10-24 x 1/2" Flat Head Machine Screws	3			
46 31400	Wear Ring	2			
707070	Workhead Assembly (Items 36 thru 45) Reservoir	1			
47 47343		1			

*Price on Application C.A. Commercially Available
 All prices are subject to change without notice. Prices do not include freight or any state, city, or county taxes.

ITEM PART NO. NO.	PART NAME	NO. REQ'D
** 29699	Pushbutton Contact Block	1
** 29774	Pushbutton Name Plate "Raise"	1
97 29782	Pushbutton Black Mushroom	1
** 43643	1/4" Lockwasher	3
** 43301	1/4"-20 x 1/2" Hex Cap Screws	3
	— IF 230 VOLT —	
98 38408	A.B. Starter No. 709AAA-43	1
** 29724	N-26 Heater	3
	— IF 70 VOLT —	
98 38409	A.B. Starter No. 709AAB-43	1
** 29722	N-19 Heater	3
99 35941	Micro Limit Switch No. LSA1A	1
100 46743	Micro Limit Switch Arm No. LSZ52CC	1
101 61063	Guide Angle (One Right Hand and One Left Hand) ...	2
** 43645	3/8" Lockwasher	4
** 43326	3/8"-16 x 3/4" Hex Cap Screw	4
706540	Repair Kit (Items 41, 43, 77 & 79)	

* Price on Application

** Not Illustrated

C.A. Commercially Available
Items in Repair Kit

ALL PARTS PRICES INCREASED 10%
EFFECTIVE JANUARY 1, 1987

2. Worn cup leather:
Refer to Section B3 above.

3. Relief valve set low:

The relief valve (Item 69) has been set at the factory to bypass oil back to the reservoir when the press reaches its rated capacity. If, however, the press does not develop its rated tonnage and the above two conditions have been checked, the relief valve may need readjusting. To do this first remove the 1/4" pipe plug (Item 65) in the connector block. Now the valve adjustment screw can be reached with a 7/32" allen wrench. To increase the setting, turn the adjustment screw clockwise. Be careful not to adjust the valve over its rated tonnage or maximum operating pressure of 6000 psi.

NOTE: Do not exceed the maximum operating pressure of 6000 psi.

D. NO RAM MOVEMENT — (motor runs when "raise" button is pressed)

1. Release valve open:

Be sure to have release valve firmly closed when using press.

2. Insufficient oil:

Check oil level in the reservoir with the ram down. Remove the 1/8" pipe plug on the side of the reservoir. The oil level should be up to this hole.

3. Pump loses its prime:

Make sure all pump intake connections are tight — not enough oil in the reservoir.

