




12" X 58" CNC KNEE MILL

MODEL SB1063



OWNER'S MANUAL

South Bend Lathe Co.[®]

Hundreds of Thousands of Lathes Sold With a Tradition of Quality Since 1906!



Scope of Manual

This manual helps the reader understand the machine, how to prepare it for operation, how to control it during operation, and how to keep it in good working condition. We assume the reader has a basic understanding of how to operate this type of machine, and that the reader is experienced with using CNC controls and commands. As with all machinery of this nature, learning the nuances of operation is a process that happens through training and experience. If you are not an experienced operator of this type of machinery, read through this entire manual, then learn more from an experienced operator, schooling, or research before attempting operations. Following this advice will help you avoid serious machine damage, personal injury, and get the best results from your work.

Manual Feedback

We've made every effort to be accurate when documenting this machine. However, errors sometimes happen or the machine design changes after the documentation process—so the manual may not exactly match your machine. If a difference between the manual and machine leaves you in doubt, contact our customer service for clarification.

We highly value customer feedback on our manuals. If you have a moment, please share your experience using this manual. What did you like about it? Is there anything you would change to make it better? Did it meet your expectations for clarity, professionalism, and ease-of-use?

South Bend Lathe, Inc.
c/o Technical Documentation Manager
P.O. Box 2027
Bellingham, WA 98227
Email: manuals@southbendlathe.com

Updates

For your convenience, any updates to this manual will be available to download free of charge through our website at:

www.southbendlathe.com

Customer Service

We stand behind our machines. If you have any service questions, parts requests or general questions about the machine, feel free to contact us.

South Bend Lathe Co.
P.O. Box 2027
Bellingham, WA 98227
Phone: (360) 734-1540
Parts Department: (417) 886-2954
Fax: (360) 676-1075 (International)
Fax: (360) 734-1639 (USA Only)
Email: cs@southbendlathe.com

Table of Contents

| | | | |
|--|-----------|---|------------|
| INTRODUCTION..... | 2 | SERVICE..... | 44 |
| About This Machine..... | 2 | Adjusting Gibs..... | 44 |
| Full View Identification (Left)..... | 3 | Adjusting X-, Y-, and Z- Ballscrew Backlash ... | 45 |
| Full View Identification (Right)..... | 4 | Main Belt Tensioning | 45 |
| Controls Identification (Left)..... | 5 | Servo Motor Belt Replacement | 45 |
| Controls Identification (Right)..... | 6 | TROUBLESHOOTING..... | 48 |
| Control Panel Close-Up Identification..... | 7 | ELECTRICAL..... | 50 |
| Controls & Components..... | 8 | Electrical Safety Instructions | 50 |
| Product Specifications | 11 | Wiring Overview | 51 |
| SAFETY..... | 14 | Wiring Visual Index..... | 52 |
| Understanding Risks of Machinery | 14 | Control Panel Switch Wiring | 52 |
| Basic Machine Safety | 14 | General Component Wiring | 53 |
| Additional Milling Machine Safety..... | 16 | Electrical Schematics..... | 62 |
| PREPARATION | 18 | PARTS | 86 |
| Preparation Overview..... | 17 | Headstock..... | 86 |
| Required for Setup..... | 17 | Quill & Spindle Feed | 89 |
| Unpacking | 18 | Gearbox | 91 |
| Inventory | 18 | Belt Housing..... | 93 |
| Cleaning & Protecting | 19 | Ram..... | 95 |
| Location | 20 | Column, Knee, & Saddle | 97 |
| Lifting & Moving..... | 21 | Table | 99 |
| Leveling & Mounting..... | 22 | Lubrication System..... | 100 |
| Assembly | 22 | Coolant System | 101 |
| Power Requirements..... | 23 | Main Electrical Box | 102 |
| Power Connection | 23 | Electrical Control Box (Internal) | 103 |
| Air Connection | 23 | Electrical Control Box (External) | 104 |
| Test Run | 24 | Accessories | 106 |
| Inspections & Adjustments | 26 | Machine Labels (Left)..... | 107 |
| Spindle Break-In..... | 26 | Machine Labels (Right) | 108 |
| OPERATION..... | 27 | WARRANTY..... | 109 |
| Operation Overview..... | 27 | | |
| Table Movement..... | 28 | | |
| Headstock Movement | 29 | | |
| Ram Movement | 31 | | |
| Downfeed Control | 32 | | |
| Spindle Brake..... | 32 | | |
| Changing Tooling..... | 33 | | |
| MAINTENANCE | 34 | | |
| Maintenance Schedule..... | 34 | | |
| Cleaning | 36 | | |
| Lubrication | 36 | | |
| Coolant Reservoir..... | 41 | | |
| Machine Storage | 43 | | |

About This Machine

Foreword

"Most boys should learn a trade in order that they may become skilled workmen. The trained workman is always in demand...When a boy has learned a trade, becomes a skilled mechanic, he has excellent equipment with which to begin life's battle, but he need not stop there. George Westinghouse, the Wright Brothers, Henry Ford, and the Studebaker Brothers were mechanics, and it was their mechanical training that made their success possible." —**Machine Shop Equipment**, 2nd Ed., 1920, by the O'Brien Brothers, founders of South Bend Lathe.

The first South Bend milling machine debuted in the 1950's. During that time, the milling machine and the already well-established South Bend lathes created the foundation of many tool rooms and school shops across America and beyond her borders. Many young people in those days came of age on South Bend equipment, becoming world-class machinists, mechanical engineers, inventors, and manufacturing visionaries.

A lot has changed in the world since then. Those same school shops have mostly been replaced by computer labs. The technology in the rotary dial phone, television set, mechanical calculator, computer, and camera of that decade could barely fit into one large room together—now they fit into a tiny box that is no bigger than a box of breath mints. And the average production machinist spends more time at a computer than at a machine. Technology has been much refined and the world operates on a much faster pace.

But some things haven't changed. The same human ingenuity and passion that created the best mechanical technology of today still exists within us. The core machines of the modern shop, like this South Bend milling machine, are still fundamentally important.

When you think about it, the greatest mechanical technology of the future will be what we create today. As the owner of a South Bend milling machine, you are now part of a great legacy. What will you create with yours?

Capabilities

This Milling Machine is built for any industrial setting, tool room, or school shop and is built for many years of service. Large workpieces can be supported and is perfect for face milling, end milling, planing, slot or keyway cutting, dovetailing, routing, drilling, reaming, and boring to name a few. With the movable ram and tilting head, all these tasks can be performed on horizontal, vertical, and angled surfaces.

Features

This CNC milling machine features 3-axis table movement with built-in X-, Y-, and Z-axis servo motors. It is constructed with high-grade Meehanite castings, and the saddle and knee ways are Turcite coated and built with wide square ways for maximum support and accuracy throughout the full range of movement.

To ensure quality work results, we have equipped this mill with premium spindle bearings that are rated to extreme tolerances. The spindle taper is NT40 and has servo motor downfeed with a variable feed rate between 0-0.98 FPM and spindle travel of 3.5".

The machine uses a Delta VFD-B inverter with a 5HP induction motor to provide true variable spindle speed from 50-5000 RPM.

The headstock is mounted on a wide dovetail movable ram with 20" of travel on the column and 320° rotating capability. The headstock itself can swivel 90° left/right or 45° forward/back so it can be positioned for nearly any setup needed.

To reduce the time spent doing daily lubrication, this milling machine is outfitted with an electronic lubrication system that automatically lubricates the most critical areas.

A quality Fagor 8055i control panel with excellent electrical components and attention to detail give dependable CNC milling operations.

Last but not least, this milling machine includes a circulating coolant system with the pump and reservoir in the column base.

Full View Identification (Left)




Figure 1. Left side machine view.

Full View Identification (Right)




Figure 2. Right side machine view.

Controls Identification (Left)




Figure 3. Left side controls.

Controls Identification (Right)




Figure 4. Right side controls.

Control Panel Close-Up Identification



Figure 5. Control panel close-up details.

!WARNING

Serious personal injury could occur if you connect the machine to power before completing the setup process. **DO NOT** connect power until instructed to do so later in this manual.

!WARNING

Untrained users have an increased risk of seriously injuring themselves with this machine. Do not operate this machine until you have understood this entire manual and received proper training.

Controls & Components




Figure 6. Control panel close-up details.

Controls & Components

These controls are largely independent of the CNC interface and most will be used in **Machine Start-Up** testing without using CNC programs. Refer to Fagor CD Manuals for CNC testing.

- A. Control Panel:** This is the master location for entering CNC commands and serves as user interface with machine during milling operation.
- B. TABLE UP Button:** Moves work table up until upper limit switch is tripped.
- C. TABLE DOWN Button:** Moves work table down until lower limit switch is tripped.
- D. LIGHT Button:** Toggles work light *ON/OFF*.

- E. MAN (DRO) Button:** Shuts down all servo-driver power and releases the spindle and quill lock so you can use the spindle downfeed lever.
- F. COOLANT Button:** Toggles coolant pump *ON/OFF*.
- G. O.T REL Button:** If axis over travel trips limit switch, alarm message displays and all axis motors stop. The **O.T REL** button resets motors to resume operations.

Note: Pressing *ESC* clears alarm, and pressing *Servo On* initializes jog mode for table to be moved back into the safe area.

- H. Handheld Controller:** Attached to the control box, it controls manual feed of X-, Y-, and Z-axes and has speed multiplying dial functions.




Figure 7. Controls and components.

- I. Servo ON Button:** Takes machine table axis out of Manual Mode and puts machine back into CNC Mode for electronic control of servo motors.
- J. Power OFF (O) Button:** Powers *OFF* all items.
- K. Power ON (I) Button:** Powers *ON* all items.
- L. EMERGENCY STOP Button:** Stops all motors on machine immediately.
- M. Power Drawbar Controls:**
The UP button threads drawbar into the tooling and seats the tooling with spindle. The DOWN button unthreads drawbar from tooling and unseats tooling from spindle for removal.
- N. Drawbar Motor Air and Lubrication System:**
This is a two-part electric over air control system. Up/Down buttons open and close air valve to supply regulated filtered air to drawbar motor. The oiler also adds a drop of oil to the air every time the button is pressed.
- Note:** *The oil is for the drawbar motor only and does not reach the tooling arbors. Arbor and spindle mating surfaces must still be maintained by you.*
- O. Automatic Electronic Lubricator:**
Automatically lubricates machine on timed basis. Manual Override button will lubricate on command.
- Note:** *Lubrication volume and frequency can be set manually by referring to the list of locations in the Maintenance Section of this manual and the oiler instructions.*
- P. Control Box Interface:** When the waterproof cover is opened, revealed is the:
- CAT-5 Port
 - IEEE 1284 DB25 25-Pin Parallel Port
- Q. Machine Status Indicator Light:** When illuminated, a red, yellow, or green light indicates the operation mode of the machine. Refer to the Fagor Manual for all the various modes of operation indicated.
- R. Master Electrical Safety Switch:**
This switch toggles power to all machine systems and most electronic components in electrical box. However, when switched to OFF, the input side is still live, so for all electrical work, this machine must still be disconnected from power first.
- S. Work Lamp ON/OFF Switch:** When switch is in ON position; work light can be turned *ON* and *OFF* at control panel.
- T. VFD Controller:** This control is only used for initial VFD setup at the factory and troubleshooting by authorized and trained technicians. The machine operator will never need to use this control and, tampering with VFD settings can void warranty.



Model SB1063 12" x 58" CNC Knee Mill

Product Dimensions

Weight..... 3814 lbs.
 Width (side-to-side) x Depth (front-to-back) x Height..... 124 x 105-1/2 x 93-1/2 in.
 Footprint (Length x Width)..... 47 x 38 in.

Shipping Dimensions

Type..... Wood Crate
 Content..... Machine
 Weight..... 4015 lbs.
 Length x Width x Height..... 106 x 79 x 100 in.
 Must Ship Upright..... Yes

Electrical

Power Requirement..... 220V, 3-Phase, 60 Hz
 Full-Load Current Rating..... 25A
 Minimum Circuit Size..... 30A
 Connection Type..... Permanent (Hardwire to Shutoff Switch)
 Switch Type..... Control Panel w/Magnetic Switch Protection
 Inverter (VFD) Type..... Delta VFD-B
 Inverter (VFD) Size..... 5 HP

Motors

Spindle

Horsepower..... 5 HP
 Phase..... 3-Phase
 Amps..... 14A
 Speed..... 1730 RPM
 Type..... Induction
 Power Transfer Belt Drive
 Bearings..... Shielded & Permanently Sealed

Coolant Pump

Horsepower..... 1/8 HP
 Phase..... 3-Phase
 Amps..... 0.38A
 Speed..... 3450 RPM
 Type..... Induction
 Power Transfer Direct Drive
 Bearings..... Shielded & Permanently Sealed

X-Axis Feed

| | |
|----------------------|-------------------------------|
| Horsepower..... | 1 HP |
| Phase..... | 3-Phase |
| Amps..... | 5.1A |
| Speed..... | 3000 RPM |
| Type..... | Servo |
| Power Transfer | Belt Drive |
| Bearings..... | Shielded & Permanently Sealed |

Y-Axis Feed

| | |
|----------------------|-------------------------------|
| Horsepower..... | 1 HP |
| Phase..... | 3-Phase |
| Amps..... | 5.1A |
| Speed..... | 3000 RPM |
| Type..... | Servo |
| Power Transfer | Belt Drive |
| Bearings..... | Shielded & Permanently Sealed |

Z-Axis Feed

| | |
|----------------------|-------------------------------|
| Horsepower..... | 1/2 HP |
| Phase..... | 3-Phase |
| Amps..... | 2.6A |
| Speed..... | 3000 RPM |
| Type..... | Servo |
| Power Transfer | Belt Drive |
| Bearings..... | Shielded & Permanently Sealed |

Main Specifications

Operation Info

| | |
|--|-------------|
| Spindle Travel..... | 3.5 in. |
| Max Distance Spindle to Column..... | 27 in. |
| Max Distance Spindle to Table..... | 19 in. |
| Longitudinal Table Travel (X-Axis)..... | 32 in. |
| Cross Table Travel (Y-Axis)..... | 15.7 in. |
| Vertical Table Travel (Z-Axis)..... | 16.5 in. |
| Ram Travel..... | 20 in. |
| Turret or Column Swivel (Left /Right)..... | 320 deg. |
| Head Tilt (Left/Right)..... | 90 deg. |
| Head Tilt (Front/Back)..... | 45 deg. |
| Drilling Capacity for Cast Iron..... | 1 in. |
| Drilling Capacity for Steel..... | 15/16 in. |
| Tapping Capacity..... | 3/4 in. |
| End Milling Capacity..... | 3/4 in. |
| Face Milling Capacity..... | 3-15/16 in. |

Table Info

| | |
|-----------------------------------|----------------|
| Table Length..... | 58 in. |
| Table Width..... | 12-1/2 in. |
| Table Thickness..... | 3-3/8 in. |
| Table Weight Capacity..... | 660 lbs. |
| Number of T-Slots..... | 3 |
| T-Slot Size..... | 5/8 in. |
| T-Slots Centers..... | 3-1/4 in. |
| Number of Longitudinal Feeds..... | Variable Speed |
| X-Axis Table Power Feed Rate..... | 16 FPM |
| Y-Axis Table Power Feed Rate..... | 16 FPM |

Spindle Info

| | |
|--|-------------------------|
| Spindle Taper..... | NT40 |
| Number of Vertical Spindle Speeds..... | Variable Speed |
| Range of Vertical Spindle Speeds..... | 50 - 5000 RPM |
| Quill Diameter..... | 4-1/8 in. |
| Quill Feed Rates..... | Variable: 0 - 0.98 FPM |
| Drawbar Thread Size..... | 5/8-11 |
| Drawbar Length..... | 25-9/16 in. |
| Spindle Bearings..... | Angular Contact - 7210A |

Construction

| | |
|----------------------------|----------------------------|
| Spindle Housing/Quill..... | Cast Iron |
| Table..... | Precision-Ground Cast Iron |
| Head..... | Cast Iron |
| Column/Base..... | Cast Iron |
| Base..... | Cast Iron |
| Stand..... | Cast Iron |
| Paint Type/Finish..... | Enamel |

Other

| | |
|---|------------------|
| Country of Origin | Taiwan |
| Warranty | 1 Year |
| Approximate Assembly & Setup Time | 1 Hour |
| Serial Number Location | Machine ID Label |
| ISO 9001 Factory | No |

Features

3-Axis Servo Driven
 Fagor Control Panel with Hand-Held Controller
 Manual/Servo Mode
 Power Drawbar
 Powered Lubrication System
 Coolant Recycling System
 Auxiliary Worklight

Included Accessories

Tool Box Including the Following Items:
 Flat-Head, Philip Head Screwdrivers
 Closed-End Wrench 19/21mm
 Open-End Wrench 12/14mm
 10-Pc. Hex Wrench Set: 1.5, 2, 2.5, 3, 4, 5, 5.5, 6, 8 & 10mm
 Bottle for Oil




Understanding Risks of Machinery

Operating all machinery and machining equipment can be dangerous or relatively safe depending on how it is installed and maintained, and the operator's experience, common sense, risk awareness, working conditions, and use of personal protective equipment (safety glasses, respirators, etc.).

The owner of this machinery or equipment is ultimately responsible for its safe use. This responsibility includes proper installation in a safe environment, personnel training and usage authorization, regular inspection and maintenance, manual availability and comprehension, application of safety devices, integrity of cutting tools or accessories, and the usage of approved personal protective equipment by all operators and bystanders.

The manufacturer of this machinery or equipment will not be held liable for injury or property damage from negligence, improper training, machine modifications, or misuse. Failure to read, understand, and follow the manual and safety labels may result in serious personal injury, including amputation, broken bones, electrocution, or death.

The signals used in this manual to identify hazard levels are as follows:

| | | | |
|--|--|--|--|
|  DANGER | <i>Death or catastrophic harm WILL occur.</i> |  CAUTION | <i>Moderate injury or fire MAY occur.</i> |
|  WARNING | <i>Death or catastrophic harm COULD occur.</i> | NOTICE | <i>Machine or property damage may occur.</i> |

Basic Machine Safety

Owner's Manual: All machinery and machining equipment presents serious injury hazards to untrained users. To reduce the risk of injury, anyone who uses THIS item MUST read and understand this entire manual before starting.

Personal Protective Equipment: Operating or servicing this item may expose the user to flying debris, dust, smoke, dangerous chemicals, or loud noises. These hazards can result in eye injury, blindness, long-term respiratory damage, poisoning, cancer, reproductive harm or hearing loss. Reduce your risks from these hazards by wearing approved eye protection, respirator, gloves, or hearing protection.

Trained/Supervised Operators Only: Untrained users can seriously injure themselves or bystanders. Only allow trained and properly supervised personnel to operate this item. Make sure safe operation instructions are clearly understood. If electrically powered, use padlocks and master switches, and remove start switch keys to prevent unauthorized use or accidental starting.

Guards/Covers: Accidental contact with moving parts during operation may cause severe entanglement, impact, cutting, or crushing injuries. Reduce this risk by keeping any included guards/covers/doors installed, fully functional, and positioned for maximum protection.

Entanglement: Loose clothing, gloves, neckties, jewelry or long hair may get caught in moving parts, causing entanglement, amputation, crushing, or strangulation. Reduce this risk by removing/securing these items so they cannot contact moving parts.

Mental Alertness: Operating this item with reduced mental alertness increases the risk of accidental injury. Do not let a temporary influence or distraction lead to a permanent disability! Never operate when under the influence of drugs/alcohol, when tired, or otherwise distracted.

Safe Environment: Operating electrically powered equipment in a wet environment may result in electrocution; operating near highly flammable materials may result in a fire or explosion. Only operate this item in a dry location that is free from flammable materials.

Electrical Connection: With electrically powered equipment, improper connections to the power source may result in electrocution or fire. Always adhere to all electrical requirements and applicable codes when connecting to the power source. Have all work inspected by a qualified electrician to minimize risk.

Disconnect Power: Adjusting or servicing electrically powered equipment while it is connected to the power source greatly increases the risk of injury from accidental startup. Always disconnect power **BEFORE** any service or adjustments, including changing blades or other tooling.

Secure Workpiece/Tooling: Loose workpieces, cutting tools, or rotating spindles can become dangerous projectiles if not secured or if they hit another object during operation. Reduce the risk of this hazard by verifying that all fastening devices are properly secured and items attached to spindles have enough clearance to safely rotate.

Chuck Keys or Adjusting Tools: Tools used to adjust spindles, chucks, or any moving/rotating parts will become dangerous projectiles if left in place when the machine is started. Reduce this risk by developing the habit of always removing these tools immediately after using them.

Work Area: Clutter and dark shadows increase the risks of accidental injury. Only operate this item in a clean, non-glaring, and well-lighted work area.

Properly Functioning Equipment: Poorly maintained, damaged, or malfunctioning equipment has higher risks of causing serious personal injury compared to those that are properly maintained. To reduce this risk, always maintain this item to the highest standards and promptly repair/service a damaged or malfunctioning component. Always follow the maintenance instructions included in this documentation.

Unattended Operation: Electrically powered equipment that is left unattended while running cannot be controlled and is dangerous to bystanders. Always turn the power **OFF** before walking away.

Health Hazards: Certain cutting fluids and lubricants, or dust/smoke created when cutting, may contain chemicals known to the State of California to cause cancer, respiratory problems, birth defects, or other reproductive harm. Minimize exposure to these chemicals by wearing approved personal protective equipment and operating in a well ventilated area.

Difficult Operations: Attempting difficult operations with which you are unfamiliar increases the risk of injury. If you experience difficulties performing the intended operation, **STOP!** Seek an alternative method to accomplish the same task, ask a qualified expert how the operation should be performed, or contact our Technical Support for assistance.

Additional Milling Machine Safety

You can be seriously injured or killed by getting clothing, jewelry, or long hair entangled with rotating cutter/spindle. You can be severely cut or have fingers amputated from contact with rotating cutters. You can be blinded or struck by broken cutting tools, metal chips, workpieces, or adjustment tools thrown from the rotating spindle with great force. To reduce your risk of serious injury when operating this machine, completely heed and understand the following:

Understanding Controls: Make sure you understand the function and proper use of all controls before starting. This will help you avoid making mistakes that result in serious injury.

Avoiding Entanglement. DO NOT wear loose clothing, gloves, or jewelry, and tie back long hair. Keep all guards in place and secure. Always allow spindle to stop on its own. DO NOT stop spindle using your hand or any other object.

Wear Face Shield. Always wear a face shield in addition to safety glasses. This provides more complete protection for your face than safety glasses alone.

Use Correct Spindle Speed. Follow recommended speeds and feeds for each size and type of cutting tool. This helps avoid tool breakage during operation and ensures best cutting results.

Inspect Cutting Tool. Inspect cutting tools for sharpness, chips, or cracks before each use. Replace dull, chipped, or cracked cutting tools immediately.

Properly Secure Cutter. Firmly secure cutting tool or drill bit so it does not fly out of spindle during operation.

Power Disruption. In the event of a local power outage during operation, turn spindle switch OFF to avoid a possible sudden startup once power is restored.

Clean Machine Safely. Metal chips or shavings can be razor sharp. DO NOT clear chips by hand or compressed air that can force chips farther into machine—use a brush or vacuum instead. Never clear chips while spindle is turning.

Secure Workpiece To Table. Clamp workpiece to table or secure in a vise mounted to table, so workpiece cannot unexpectedly shift or spin during operation. NEVER hold workpiece by hand during operation.

Properly Maintain Machine. Keep machine in proper working condition to help ensure that it functions safely and all guards and other components work as intended. Perform routine inspections and all necessary maintenance. Never operate machine with damaged or worn parts that can break or result in unexpected movement during operation.

Disconnect Power First. To reduce risk of electrocution or injury from unexpected start-up, make sure mill/drill is turned OFF, disconnected from power, and all moving parts have come to a complete stop before changing cutting tools or starting any inspection, adjustment, or maintenance procedure.

Remove Chuck Key & Spindle Tools. Always remove chuck key, drawbar wrench, and other tools used on the spindle immediately after use. This will prevent them from being thrown by the spindle upon startup.

Preparation Overview

The purpose of the preparation overview is to help you gather your resources and the machine for installation and operation. Steps for these items are covered further later in this section.

The typical preparation process is as follows:

1. Unpack machine inventory the shipment.
2. Inspect the machine for shipping damage.
3. Clean the machine and its components.
4. Review **Precautions Against Product Damage** in the **Fagor Operators Manual**, and if location is acceptable;
5. Electrician verifies the power source voltage, phase, and ground is within specification listed in this manual and the **Fagor Operators Manual**. Refer to Power Requirements on **Page 23** of that manual.
 - If required, surge protection is installed.
6. Move the machine to its operating location.
7. Fasten and shim machine to the floor, or use optional feet and bolts and adjust until level.
8. Install loose components as required.
9. Fill coolant and lubrication oil reservoirs as applicable according to **Lubrication** section starting on **Page 36**.
10. Make remaining adjustments and inspections to ensure machine is ready for operation.
11. Connect machine to power.
12. Read and understand **Fagor Operating Manual**, and its **Monitor Information Layout** on **Page 28**.
13. Complete machine **Test Run** in this manual.
14. Clean and make sure all tools are accounted for and put away.

Required for Setup

The items listed below are required to successfully set up and prepare this machine for operation.

For Lifting

- A forklift or other power lifting device rated for at least 5000 lbs.
- Lifting chain and safety hook rated for at least 5000 lbs.
- One or more assistants.

For Power Connection

- A power source that meets the minimum circuit requirements for this machine. Refer to **Page 23** for details.
- A qualified electrician to ensure a safe and code-compliant connection to the power source.

For Assembly

- Cotton rags
- Applicable PPE for assembly and solvents
- Mineral spirits
- Safety glasses
- Oil can with applicable machine oil
- Grease gun with applicable grease
- Stiff grease brush
- Floor mounting hardware as needed
- Basic shop hand tools

Unpacking

This item was carefully packaged to prevent damage during transport. If you discover any damage, please immediately call Customer Service at (360) 734-1540 for advice. You may need to file a freight claim, so save the containers and all packing materials for possible inspection by the carrier or its agent.

Inventory

Inspect the machine for damage and inventory your shipment for the following items.

Included Documentation List

(Packed Inside of Electrical Box Door)

Fagor Binder Printed Manual:

Fagor CNC 8055 M Programming Manual Ref. 1010, Soft: V01.0X

Fagor CD:

Fagor Manual Man_8055.pdf 8055 M

- Installation Manual
- Operating Manual
- Programming Manual
- Error Solution
- Examples Manual

Delta Printed Manual:

Delta VFD-B Printed

Delta Packet:

- Delta VFD-B Instruction Sheet
- Delta VFD-B Parameter Manual

Delta CD:

Delta AC Motor Drives VFD Series User Manual VFD-B

Power Drawbar Printed Manual:

Air Power Drawbar Operation Manual, PD-150-PD-200

| Description (see Figure 8) | Qty |
|--|-----|
| A. Tool Box..... | 1 |
| B. Feed Lever (see For Manual Mode) | 1 |
| C. Closed-End Wrench 19/21mm | 1 |
| D. Open-End Wrench 12/14mm | 1 |
| E. Hex Wrench 10-Pc. Set 1.5–10mm..... | 1 |
| F. Screwdriver Standard #2..... | 1 |
| G. Screwdriver Phillips #2 | 1 |
| H. Oil Bottle | 1 |
| I. Table Drain Elbow Fittings..... | 2 |
| J. Coolant Hoses with Hose Clamps | 2 |
| K. Machine Feet..... | 4 |
| L. Machine Feet Bolt and Nut Kit..... | 1 |




Figure 8. Shipping inventory.

Cleaning & Protecting

Unpainted surfaces are coated at the factory with a heavy-duty rust preventative for protection during shipment and storage. This long-term coating works very well, but can be time-consuming to thoroughly remove.

Be patient and do a careful job when cleaning and removing the coating. The time you spend doing this will reward you with smooth-sliding parts and a better appreciation for the proper care of the unpainted surfaces.

Although there are many ways to successfully remove the rust preventative, we have cleaned thousands of machines and found the following process to be the best balance between efficiency and minimized exposure to toxic fumes or chemicals.

Before cleaning, gather the following:

- Disposable rags
- Cleaner/degreaser (certain citrus-based degreasers work extremely well and they have non-toxic fumes)
- Safety glasses and disposable gloves

Note: Automotive degreasers, mineral spirits, or WD•40 can be used to remove rust preventative. But before using these products, test a small amount on an inconspicuous area to make sure they will not stain the metal or cause paint to become discolored or peel. Do not use on plastics.



! WARNING
Gasoline and petroleum products have low flash points and can explode or cause fire if used for cleaning. Avoid using these products to remove rust preventative.



! CAUTION

Many cleaning solvents are toxic if inhaled. Minimize your risk by only using these products in a well ventilated area.

NOTICE

Avoid chlorine-based solvents, such as acetone or brake parts cleaner that may damage painted surfaces. Always follow the manufacturer's instructions when using any type of cleaning product.

Basic steps for removing rust preventative:

1. Put on safety glasses and disposable gloves.
2. Coat all surfaces that have rust preventative with a liberal amount of your cleaner or degreaser and let them soak for a few minutes.

Tip: Placing rags that are saturated with your cleaner over areas with heavy concentrations of the rust preventative coating for a period of time is an excellent way to soften the thick deposits for easy removal.

3. Wipe off the surfaces. If your cleaner or degreaser is effective, the rust preventative will wipe off easily.

Tip: To clean off thick coats of rust preventative on flat surfaces, such as beds or tables, use a plastic paint scraper to scrape off the majority of the coating before wiping it off with your rag. (Do not use a metal scraper or it may scratch the surface.)

4. Repeat Steps 2–3 as necessary until clean, then coat all unpainted surfaces with a quality metal protectant or light oil to prevent rust.

Location

Physical Environment

Location is important for safe operation and longevity of machine and parts. For best results, operate this machine in an environment that is free from vibration, excessive moisture, hazardous or flammable chemicals, airborne abrasives, and extreme conditions. The ambient working temperature requirement is: 41°F to 104°F (+5°C to +40°C) and the storage temperature is -13°F to 158°F (-25°C to +70°C). The relative humidity for both is below 90% (non-condensing). Make sure that all environmental conditions listed in the **Fagor Operating Manual** are met. For the list; refer to **Precautions Against Product Damage**.

Electrical Installation

Place this machine near an existing power source. Make sure all power cords are protected from traffic, material handling, moisture, chemicals, or other hazards. Make sure to leave access to a means of disconnecting the power source or engaging a lockout/tagout device.

Lighting


Machine lighting is adequate for safe operation.

Weight Load

Refer to the **Machine Specifications** for the weight of your machine. Make sure that the surface upon which the machine is placed will bear the weight of the machine, additional equipment that may be installed on the machine, and the heaviest workpiece that will be used. Additionally, consider the weight of the operator and any dynamic loading that may occur when operating the machine.

Space Allocation

Consider the largest size of workpiece that will be processed through this machine and provide enough space around the machine for adequate operator material handling or the installation of auxiliary equipment. With permanent installations, leave enough space around the machine to open or remove doors/covers as required by the maintenance and service described in this manual.

| | |
|--|---|
|  | <p>⚠ CAUTION Children or untrained people may be seriously injured by this machine. Only install in an access restricted location.</p> |
|--|---|





Figure 9. Clearances.

Lifting & Moving



The method of lifting and moving the mill described below requires at least two other people for assistance and a hoist or forklift with a lifting strap or chain rated for at least 5000 lbs.

To lift and move mill:

1. Position ram and headstock so lifting eye is centered with the column as illustrated in **Figure 10** (refer to **Ram Movement on Page 31** and **Headstock Movement on Page 29** for detailed instructions).
2. To prevent unexpected movement during lifting and moving; after re-positioning ram and headstock, make sure they are locked in place.

IMPORTANT: Before lifting mill, make sure four turret lock bolts (two on each side of ram, **Figure 11**) are torqued to 47 ft/lbs.




Figure 10. Ram and head position before moving.

3. Verify that lifting eye is threaded completely into ram where all threads are engaged with casting.
4. Attach lifting strap or chain to lifting eye located on top of the ram; or attach lifting straps under ram, as shown in **Figure 11**.




Figure 11. Optional lifting using web straps.

5. Unbolt mill from shipping pallet.
6. With your assistants steadying mill to keep it from swaying and rotating, slowly lift mill a couple of inches.
 - If mill tips forward or backward, lower it to ground and adjust ram or table to balance load. Make sure to re-tighten lock levers and bolts before lifting mill again.
 - If mill lifts evenly, continue to move it to its permanent location.

Leveling & Mounting

Although not required, we recommend that you level your machine and mount it to the floor. Because this is an optional step and floor materials may vary, mounting hardware is not included.

NOTICE

We strongly recommend securing your machine to the floor if it is hardwired to the power source. Consult with your electrician to ensure compliance with local codes.

Leveling

Leveling machinery helps precision components, such as bed ways, remain straight and flat during the lifespan of the machine. Components on an unlevelled machine may slowly twist due to the dynamic loads placed on the machine during operation.

For best results, use a precision level that is at least 12" long and sensitive enough to show a distinct movement when a 0.003" shim (approximately the thickness of one sheet of standard newspaper) is placed under one end of the level.

See the figure below for an example of a high precision level.




Figure 12. Typical precision level.

Bolting to Concrete Floors

To prevent the Model SB1063 from tipping and causing a crushing hazard when heavy workpieces are mounted off-center, we strongly recommend that you bolt the mill to a concrete floor or pad.

There are many different methods of securing the mill to the floor. Lag shield anchors and lag bolts are available in the sizes required for this mill. Also, cutting the floor and pouring footings with embedded J-bolts is another method.

Research options and select the best choice that fits your specific conditions.

Note: *This machine has an oversized electrical box with a control arm mounted to the top. Below the electrical box are two additional support legs (see Figure 13). These adjustable legs are only to be used as supports and should not be fastened to the floor or be used as jack bolts to help level the mill.*




Figure 13. Electrical box support feet.

Assembly

This machine has been fully assembled and tested at the factory for break-in and conversion to CNC operation. No assembly is required; however, retain the tool box, its tools, and the manual downfeed handle from the initial non-CNC configuration. Spindle feed is CNC operated only.

Power Requirements



Grounding Instructions

In the event of certain types of malfunctions or breakdowns; correct machine grounding provides a safe path for electricity to go instead of through YOU as electric shock or electrocution.

This machine must be correctly grounded in accordance with all local codes and ordinances before any machine test run or operation.

Once the machine is set up and assembled as previously described in this manual, it is ready to be connected to the power source.

| | |
|------------------------------------|-----------------------|
| Required Power Source..... | 220V/ Three-Phase |
| With Conversion Kit | 440V/ Three-Phase |
| Phase Converter Allowed | No |
| Full Load Amp Draw | 25 Amps |
| Nominal Voltage Range..... | 208V/220V/240V |
| Frequency | 60 Hz |
| Minimum Circuit Size | 30 Amps |
| Power Cord | Hardwire with Conduit |
| Plug/Receptacle | N/A |
| Minimum Extension Cord Size | *N/R* |
| Maximum Extension Cord Length..... | *N/R* |

N/R = Not Recommended

NOTICE

There are a series of steps that must be followed to when turning the machine ON. Before connecting the machine to power as instructed on the next page, make sure the main power switch located on the electrical box remains OFF. This will disable power to the control panel until it is required in the Test Run on Page 24.

Power Connection

1. Make sure the incoming power source meets the requirements stated in **Power Requirements**.
2. Make sure that all installation conditions are met as outlined in the Fagor Operating Manual, **Precautions Against Product Damage** of the Fagor Manual.
3. To ensure the Delta VFD Drive will operate correctly, only an electrician or qualified personnel can hardwire this machine to the power source.
4. Using an extension cord and plug is not recommended.

Air Connection

1. Make sure the incoming shop air source is between 60-120 PSI.
2. Connect the shop air source to the regulator inlet assembly shown in **Figure 31**, Item C.

Note: *The air connection can use a quick disconnect, or a direct piping connection. However, if a direct connection is used, an ON/OFF valve should be installed at that location so the incoming air can be shut off at the machine for service.*

4. Set the regulator air pressure according to the requirement indicated in the Power Drawbar Manual.

IMPORTANT: If shop air has excessive moisture, you must add an additional water separator assembly.

Test Run

After all preparation steps have been completed, the machine and its safety features must be tested by a person who has existing experience and training using CNC machinery to ensure correct operation.

If you discover a problem with the machine or its safety features, do not operate it further until you have resolved the problem. Refer to the **Troubleshooting** section on **Page 48** for solutions to common problems that may occur. If you need additional help, contact our Tech Support at (360) 734-1540.

During the test run, you will verify the proper operation of the following controls and machine systems:

PART 1:

- Main power switch
- Power ON button
- EMERGENCY STOP button
- Table Up/Down button operation
- Control panel operation
- X-axis table movement
- Y-axis table movement
- Z-axis table movement
- Manual spindle travel
- Power drawbar lubrication
- Power drawbar operation
- Coolant pump system
- Electronic oiler operation
- Work lamp operation
- Power OFF button

PART 2:

- Fagor CNC Testing. Refer to desired Fagor test sequence and/or operation listed below

Fagor Binder Printed Manual:

Fagor CNC 8055 M Programming Manual Ref. 1010, Soft: V01.0X

Fagor CD:

Fagor Manual Man_8055.pdf 8055 M

- Installation Manual
- Operating Manual
- Programming Manual
- Error Solution
- Examples Manual

Test Run the Mill

1. Read and follow safety instructions at the beginning of this manual, take required safety precautions, and make sure machine is set up and adjusted properly.
2. Next review and understand Self Teaching Manual located on the supplied Fagor CD. With CD inserted, click on **Man_8055.pdf** and following list of documentation will be available:

8055 M

- Installation Manual
 - Operating Manual
 - Programming Manual
 - Error Solution
 - Examples Manual
3. Connect compressed shop air to air regulator shown in **Figure 31** on **Page 37**.
 4. Verify that air regulator is set to required PSI listed in the Drawbar Manual.
 5. Turn master power switch on electrical box to ON position.
 - Red power light (see Figure 14) illuminates on front of the control panel, indicating that master power switch is operational and machine is fully powered up.




Figure 14. Initial controls.

6. Press POWER (I) button (see **Figure 14**) on control panel.
 - Red power light will go out, and green ON button light will illuminate, indicating machine is ready for commands.

- Control panel screen will boot up then display main screen.
- When boot-up is finished, the screen will display main screen.

7. Loosen Z-axis locks.
8. Press EMERGENCY STOP button (see **Figure 14**).




Figure 15. Basic push button controls.

9. Press TABLE UP and TABLE DOWN buttons (see **Figure 15**). The buttons should be inoperative indicating that EMERGENCY STOP button successfully shuts **OFF** all motor functions.

Note: *The control panel and rest of machine stays live.*

10. Rotate EMERGENCY STOP button clockwise until it pops out. Wait and allow control panel to boot up again.
11. Press TABLE UP button. Table should raise.
12. Press TABLE DOWN button. Table should lower.

Note: *If table moves opposite to controls used, phase polarity must be corrected.*

- To do this; turn machine **OFF**, disconnect it from power, and swap position of any two L1, L2, or L3 power wires on offending motor.

13. Verify that machine goes into Manual DRO Mode; flip plastic switch cover open and press MAN button (see **Figure 15**).
 - MAN button will illuminate white indicating machine is in manual mode.
14. Press JOG or F4 button (see **Figure 5**) and machine will change to Manual DRO mode. All servo motors will turn **OFF** allowing for manual ballscrew rotation.

While in this manual mode; loosen corresponding lock levers and manually operate following controls:

- X-axis handwheel
- Y-axis handwheel
- Z-axis table up/down handcrank

Note: *Trying to move handwheels before machine is put into manual mode will generate an error message on screen. Once mill is put in manual mode error message will go away.*

15. Refer to **Air Regulator, Filter, Lubricator** instructions on **Page 37** and verify correct volume of oil is injected in drawbar motor supply air.
16. Verify power drawbar system operates by quickly pushing Drawbar DOWN and Drawbar UP buttons (see **Figure 7, View L**).
17. To prevent a dry-run of pump and damage, verify coolant tank is full (refer to Coolant Reservoir on **Page 41**).
18. Point coolant nozzle toward chip pan, and test pump operation by pushing COOLANT button (see **Figure 15**). During operation, adjust coolant flow by moving flow lever (see **Figure 1**) to various positions.
19. Refer to **CESH Electronic Oiler** on **Page 37** and verify that oiler is set to distribute an adequate amount of oil for the number of mechanical repetitions.

20. Press Manual Oil button (see **Figure 30, Item B**). The light should illuminate, oil pump heard, and oil distribution indicated at ways. Do not hold button for longer than four minutes or oil pump can overheat.
21. Turn work lamp **ON** at back of lamp shroud (see **Figure 7, View R**), and then press **LIGHT** button shown in (see **Figure 15**).
 - Light should illuminate.
22. Press **POWER (O)** button to shut machine **OFF** shown in **Figure 14** on control panel.
 - Red power light will illuminate.
 - Control panel screen will turn off.
 - Green **POWER (I)** button light (see **Figure 14**) will go out indicating that **POWER OFF (O)** button is functional and machine is powered but not ready for commands.
23. "Congratulations! The Test Run is complete. Proceed to your desired machine operations outlined in the Fagor CNC Manual(s).

Inspections & Adjustments

The following list of adjustments were performed at the factory before the machine was shipped:

Gib Adjustment**Page 44**

Be aware that machine components can shift during the shipping process. Pay careful attention to the adjustments above during operation of the machine. If you find that the adjustments are not set according to the procedures in this manual or your personal preferences, re-adjust them.

Spindle Break-In

The high-quality bearings and gears used in the mill are manufactured to very close tolerances. The spindle bearings and associated drive system have been broken-in at the factory and no pre-load break-in is required.

NOTICE


Since the mill head was rotated parallel to the table for shipping purposes, you will need to tram the spindle with the table if your first operation requires 90° alignment.

Operation Overview

The purpose of this overview is to first provide the machine operator with a mind's-eye picture of the basic physical milling machine functions. The second purpose is to introduce and link typical CNC control panel concepts and modes with those operations, so the user can find applicable CNC procedures in the Fagor Operating Manual.

Note: Due to the generic nature of this overview, it is not intended to be an instructional guide for performing actual machine operations.

To learn more about specific operations and machining techniques, seek training from people experienced with this type of machine, and do additional research outside of this manual.



! WARNING


To reduce the risk of serious injury when using this machine, read and understand this entire manual before beginning any operations.

In a typical milling operation, the operator does the following:

1. Examines the workpiece to make sure it is suitable for milling.
2. Firmly clamps workpiece to table.
3. Installs correct cutting tool for operation.
4. Loosens the applicable X-, Y-, or Z-axis table and knee locks.
5. Uses CNC control panel or manual controls to confirm correct positioning of cutting tool and workpiece for operation.


If X-, Y-, or Z-axis will be used during operation, operator confirms tool paths, specifications, and associated machine settings.

6. Verifies working envelope does not exceed axis position and travel.



! WARNING

Loose hair, clothing, or jewelry could get caught in machinery and cause serious personal injury. Keep these items away from moving parts at all times to reduce this risk.



! WARNING

During operation, small metal chips may become airborne, leading to serious eye injury. Wear safety glasses to reduce this risk.

Note: Controller will reject program if told to go further than the global coordinate system.

7. Puts on personal protective gear and makes sure workpiece and table are clear of all tools, cords, and other items.
8. Starts the machine, coolant pump, and completes milling operations.
9. Turns machine **OFF**.
10. Removes workpiece and cleans machine.

Table Movement

The table is driven in the X-, Y-, and Z-axes by servo motors that are connected where the handwheels are fastened. These servo motors are the physical interface between CNC digital commands and actual mechanical table movement.

The milling machine is equipped with a Fagor control panel that has an additional handheld controller connected. The CNC system can be switched between Servo Mode and Manual Mode for different types of table movement. Refer to the Fagor manual for complete details.

NOTICE

Always keep the table locked in place unless table movement is required for your operation. Unexpected movement of the table during operations could damage the cutter or workpiece.

While the X- and Y-axis handwheels are spring-loaded outward to the disengaged position, make it a habit to also use the folding handcrank lever feature (see **Figure 16**) to help eliminate entanglement when the table is being power fed.




Figure 16. Handwheel with folding handcrank lever for power-fed safety.

Table & Knee Locks

Refer to **Figures 17–18** for the locations of the locks used to secure the table in place.



Figure 17. X- and Y-axes table lock locations.




Figure 18. Z-axis knee lock locations.

Headstock Movement

The mill head tilts 45° forward and back, and rotates 90° left and right, as shown in **Figures 19–21**.

Tool Needed

Wrench 19mm Qty 1

NOTICE

Always lock headstock firmly in place after tilting or rotating it. Unexpected movement of headstock during operations could cause damage to cutter or workpiece.




Figure 19. Head tilts 45° forward and back.




Figure 20. Head tilts 90° left-and-right.

Tilting Head

1. DISCONNECT MILL FROM POWER!
2. Loosen the three tilt lock bolts on the right side of the ram adapter shown in **Figure 21**.




Figure 21. Head tilting controls.

3. Use one hand to apply pressure to the head in the direction of tilt, then slowly rotate the tilt bolt. Rotating this bolt clockwise will tilt the head back.
4. When the head is in the correct position for your operation, re-tighten all three lock bolts.

Rotating Head

1. DISCONNECT MILL FROM POWER!
2. Loosen four rotation lock bolts on face of head shown in **Figure 22**.




Figure 22. Head rotating controls.

3. Use one hand to apply pressure in direction of rotation, then slowly turn rotation bolt.
4. Re-tighten lock bolts when head is in desired position.

Tramming Spindle

When your operation requires that the spindle axis be precisely perpendicular to the table, you must tram or square the spindle with the table to ensure the spindle is exactly 90° to the table.

This procedure involves mounting a dial test indicator to the quill or spindle, rotating it around the table, and adjusting the head position so that the spindle axis is 90° to the table X- and Y- axes, as illustrated in **Figure 23**.




Figure 23. Spindle axis perpendicular to table X- and Y-axes.

We encourage you to research the many variations of spindle tramming to find the one that works best for you.

Ram Movement

The ram travels forward and backward 20" and rotates horizontally 320° on its turret.

Tool Needed

Wrench 19mm 1

Qty

Moving Ram Back and Forth

1. DISCONNECT MILL FROM POWER!
2. Loosen two lock levers shown in **Figure 24** on right side of ram.




Figure 24. Ram forward and backward movement controls.

3. Make sure there are no obstructions to ram travel, especially with spindle tool around workpiece, then slowly rotate adjustment bolt (see **Figure 24**) to move ram. Rotating bolt clockwise will move ram backward.
4. Re-tighten lock levers.

NOTICE

Always lock ram firmly in place after moving it. Unexpected movement of ram and head during operations could cause damage to cutter or workpiece.

Rotating Ram

1. DISCONNECT MILL FROM POWER!
2. Loosen four lock bolts on top of turret (see **Figure 25**).




Figure 25. Ram rotation lock bolts.

NOTICE

In the next step, take care not to entangle or stretch electrical cabling as you move ram around turret.

3. Push on head to manually rotate it. Use rotation scale (see **Figure 25**) to determine correct position for your operation
4. Re-tighten four lock bolts.

Downfeed Control

When the machine is set to the CNC mode, the quill and spindle become locked with the servo-driven ballscrew. As a result, the manual downfeed lever is disabled and should be removed.

When the machine is placed in Manual mode; the quill and spindle are unlocked and can be controlled manually. For this operation, the downfeed lever can be easily reinstalled as shown below.

To install downfeed lever:

1. DISCONNECT MILL FROM POWER!
2. Position downfeed lever at top of spindle stroke.
3. Align index pin with closest index hole (see **Figure 26**).
4. Slide hub onto shaft until detent pin engages with its associated detent on shaft.




Figure 26. Downfeed handle hub, detents, and pin.

Auto-Downfeed System

Spindle downfeed movement is controlled by toggling from CNC mode to Manual mode. When in CNC mode, the quill is locked with the ballscrew and the feed lever cannot pull the quill down. The opposite is true when in Manual mode.

Spindle Brake

When pushed, the spindle brake lever (see **Figure 27**) activates a switch that turns the spindle motor **OFF** and engages drum-type brake pads to stop spindle rotation.




Figure 27. Location of spindle brake lever.

NOTICE

Spindle brake is typically used in an emergency situation where you need to stop spindle in a hurry. Overuse of spindle brake will lead to excessive wear of brake pads and drum.

Changing Tooling

The mill is equipped with an NT40 spindle taper and a $\frac{5}{8}$ "-11 x $25\frac{9}{16}$ " internal spindle drawbar.

CAUTION

The sharp edges of tools can easily cut your hands and fingers. Always use protection when handling cutting tools.

Loading Tooling

| Items Needed | Qty |
|--------------|-----|
| Rag | 1 |

To load tooling:

1. DISCONNECT MILL FROM POWER!
2. Clean any debris or surface substances from inside spindle taper and mating surface of tooling.

Note: Debris or oily substances can prevent tooling and spindle from properly mating. This condition can cause excessive vibration, poor cutting results, or tool / workpiece damage.

3. Using a thick rag, hold tooling or arbor so they are seated in the spindle bore and lugs are splined with spindle slots.
4. With a sequence of several short presses, push drawbar UP button (see **Figure 28**) to tighten and lock arbor and tooling in place.

Unloading Tooling

| Items Needed | Qty |
|--------------|-----|
| Rag | 1 |

To unload tooling:

1. DISCONNECT MILL FROM POWER!
2. Using a thick rag, hold tooling or arbor carefully to prevent it from falling when drawbar releases it.
3. With a sequence of several short presses, push drawbar DOWN button (see **Figure 28**) to loosen and unseat arbor and tooling.
4. Remove arbor and tooling.





Figure 28. Drawbar controls.

Maintenance Schedule



Regular maintenance will ensure proper care of the equipment. We strongly recommend that all operators make a habit of following the daily maintenance procedures.

For optimum performance from this machine, this maintenance schedule must be strictly followed. Use the **Monthly Maintenance Chart** on **Page 35** to ensure this is done.

Ongoing

To maintain a low risk of injury and maximize efficient machine operation, periodically evaluate the listed items below. If a problem is found, immediately shut the machine down, disconnect it from power, and fix the problem before continuing operations.

- Loose mounting bolts or fasteners.
- Worn, frayed, cracked, or damaged wires.
- EMERGENCY STOP button not working correctly.
- Missing belt or chip guards.
- Reduction in braking speed or efficiency.
- Coolant not flowing correctly.
- Worn or damaged tooling.
- Any other unsafe condition.

Before Beginning Operations

- Make sure the electric box door is closed and properly latched.
- Check the coolant reservoir in the base. Fill it or clean it out if necessary.
- Verify that oiler lubrication reservoirs are full enough for the operation.
- Loosen or tighten applicable table and spindle lock levers for the upcoming operation.

Daily, After Operations


- Push the EMERGENCY STOP button.
- Turn the main power switch to the OFF position.
- Vacuum/clean all chips and swarf from table, slides, and base.
- Wipe down all unpainted or machined surfaces with a high-quality rust preventative compound.
- Wipe away excess flood oil from areas that are auto lubricated.

| Item | Day | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | | | | |
|--------------------------------|-----|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|--|--|--|--|
| Inspection | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Coolant Level | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Air Lubricator Oil Level | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Ele. Lubricator Oil Level | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Gib Adj. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Air Filters | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| End of Day | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Disconnected From Power | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Cleaned & Protected | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Wipe Down Cast Iron | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Lubrication | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Quill | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Speed Range Bearing Sleeve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Headstock Gearing | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Ram Ways | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Head & Ram Rack & Pinion Gears | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Use this chart to keep track of the maintenance performed on the mill. Cross out or initial the "Day" box for each item on the list. If the box is blacked out, maintenance is not required for that item on that day.

Make copies of this page to use each month. Keep each chart as a maintenance record for the mill.

Month/Year:



(360) 734-1540 • FAX: (360) 676-1075
www.southbendlathe.com

Cleaning

Regular cleaning is one of the most important steps in taking good care of this machine. In most shops, each operator is responsible for cleaning the machine immediately after using it or at the end of the day. We recommend that the cleaning routine be planned into the workflow schedule, so that adequate time is set aside to do the job right.

Typically, the easiest way to clean swarf from the ways and table is to use a wet/dry shop vacuum that is dedicated for this purpose only. The small chips left over after vacuuming can be wiped up with a slightly oiled rag. Avoid using compressed air to blow off chips, as it may drive them deeper into moving surfaces and could cause sharp chips to fly into your face or hands.

All visible swarf should be removed daily from the mill during cleaning.

Unpainted & Machined Surfaces

Besides the ways, all other unpainted and machined surfaces should be wiped down daily to keep them rust-free and in top condition. This includes any surface that is vulnerable to rust if left unprotected (especially any parts that are exposed to water-soluble cutting fluids). Typically, a thin film of oil is all that is necessary for protection.

Lubrication

The mill has numerous moving metal-to-metal contacts that require regular and proper lubrication to ensure efficient and long-lasting operation, and to protect your investment.

Other than the lubrication points covered in this section, all other bearings are internally lubricated and sealed at the factory. Simply leave them alone unless they need to be replaced.

Before performing any lubrication task other than using the electronic oiler, **DISCONNECT THE MILL FROM POWER!** Always clean away grime before lubricating.

IMPORTANT: For all lubrication tasks, first clean the debris and grime from the oil cup or grease fitting and the immediate area to prevent contamination of the oil cups, grease fittings, or new lubricant.

Use the schedule and information in **Figure 29** as a daily guide for lubrication tasks.

NOTICE

The following recommended lubrication schedule is based on light-to-medium usage. Keeping in mind that lubrication helps to protect the value and operation of the mill, these lubrication tasks may need to be performed more frequently depending on usage.

| Lubrication Task | Frequency (Hours of Operation) | Page Ref. |
|----------------------------|--------------------------------|-----------|
| Quill | 3–4 hrs. | 39 |
| Table Ways and Ballscrews | Auto Oiler | 37 |
| Speed Range Bearing Sleeve | Before Every Use | 38 |
| Headstock Gearing | 40 hrs. | 38 |
| Ram Ways | 40 hrs. | 39 |
| Head Rack and Pinion | 6 Months | 39 |

Figure 29. Recommended lubrication tasks, schedules, and instruction page references.

CESH Electric Lubricator

Required Oil Viscosity 32-68cSt at 40 Deg. C
 Lubricant Type.....Syncon® R&O Oil
 (ISO VG 32-68)

Manual Auto Frequency 10 Sec every 60 Min
 CNC Auto Frequency 10 Sec every 5 Min
 Reservoir Capacity 2 Liters

The electronic oiler (see **Figure 30**) is connected to metal tubes that direct oil to critical wear points at ways and ballnuts for the spindle, table, saddle, and knee.

- A. Lubrication Adjustment:** Using Interval Time Knob, 10 second pump cycle can be adjusted to intervals shown on the dial.
- B. Manual Oiling:** When pressing Feed Oil Button for manual lubrication, do not push and hold button for longer than four minutes or you will overload lubricator pump. If temperature reaches 100 Deg. F, sensor will stop motor for about 5 minutes to allow for cooling.
- C. Maintenance:** Clean oil filter and discharge outlets every 6 months to maintain correct flow.
- D. Oil Level:** Do not overfill. When oil level falls below safe level, built-in float switch will automatically sound warning buzzer.

Note: Refer to *Electronic Oiler* for Wiring diagram located under its cover and label for further instructions if required.




Figure 30. Oiler controls.

Air Regulator, Filter, Lubricator

Required Oil Viscosity 32-68cSt at 40 Deg. C
 Lubricant Type.....Syncon® R&O Oil
 (ISO VG 32-68)

Drop Frequency.....3 Drops Per Drawbar Change
 Reservoir Capacity 1 fl/oz
 Air Regulator, Filter, Lubricator (see **Figures 31-33**) provide the following functions that support Air Power Drawbar Motor:

Description (see Figure 31)

- A.** Locking Air Pressure Knob (20-130 PSI)
- B.** Regulated Air Pressure Gauge
- C.** Shop Air Inlet (145 PSI Max)
- D.** Air Filter Element (Brass Stone)
- E.** Water Reservoir
- F.** Spring-Loaded Water Drain
- G.** Oiler-Jet Sight Glass
- H.** Oil Flow Adjustment Ring
- I.** Regulated Air Outlet to Control Box
- J.** Oil Reservoir




Figure 31. Air regulator, oiler, filter, and water separator.

- K.** Control Box Assembly
- L.** Air Regulator, Filter, Lubricator Assembly
- M.** Drawbar Motor Control Box Assembly Fuse




Figure 32. Power drawbar air and oiling system.




Figure 33. Drawbar motor control box assembly.

Speed Range Bearing Sleeve

Lubricant Type..... South Bend SB1365 Way Oil
or ISO 68 Equivlent
Amount Fill Oil Cup
Check/Add Frequency Before Every Use

Lift the oil cup cap shown in **Figure 34** to fill it with lubricant.



Figure 34. Bearing sleeve oil cup.

Headstock Gearing

Lubricant Type..... Grease NLGI #2 or Equivalent
Amount Two Pumps of Grease Gun
Check/Add Frequency 40 hrs. of Operation

Wipe-off grease fitting and add two pumps of grease from a grease gun (see **Figure 35**).




Figure 35. Headstock gearing grease fitting location.

Quill

Lubricant Type..... South Bend SB1365 Way Oil
 or ISO 68 Equivlent
 Amount Fill Oil Cup
 Check/Add Frequency 4 hrs. of Operation

Lift the oil cup cap shown in **Figure 36** to fill it with lubricant.




Figure 36. Quill oil cup location.

Ram Ways

Lubricant Type..... South Bend SB1365 Way Oil
 or ISO 68 Equivlent
 Amount Thin Coat
 Check/Add Frequency 40 hrs. of Operation

Move the ram back and forth as necessary to access the full length of the ways (see **Figure 37**), then use a clean shop rag to apply a thin coat of lubricant.

Note: Do not get any oil on the ram rack (refer to the next subsection).




Figure 37. Ram ways exposed for lubrication.

Headstock Rack & Pinion Gear

The interaction between the cast iron surfaces of these devices (see **Figures 38-39**) produces a dry powder that provides an adequate lubrication. However, if the machine is operated in an area prone to rust, a light coat of grease will help keep surface rust at bay.

Do not pack with grease or apply any other lubricant that could attract abrasives and cause caking that would interfere with smooth movement.




Figure 38. Headstock slide rack and pinion assembly (pinion hidden).



Figure 39. Headstock tilt rack and worm assembly.

Air Filters

The mill has numerous electrical components enclosed inside of the electrical box that generate substantial heat. To ensure efficient and long-lasting operation this heat must be removed.

The electrical box is fitted with two exhaust cooling fans and two inlet vents that have filters to keep the inside of the electrical box clean. These filters require periodic inspection and cleaning.

Before performing any task on the electrical box or its fans, **DISCONNECT THE MILL FROM POWER!**

Check/Clean Frequency40 hrs. of Operation

| Tools Needed | Qty |
|--|-------------|
| Hex Wrench 2.5mm | 1 |
| Screwdriver Standard #2..... | 1 |
| Solution of Mild Dish Soap and Water | As Required |

To clean air filters:

1. Use a thin bladed tool to carefully pry-off snap-on filter cover (see **Figure 40**).



Figure 40. Air filter element.

2. Wash filter pad in warm soapy water, pat dry with towel.
3. Reinstall exhaust filter and filter cover.

4. Working from outside of the electrical cabinet (see **Figure 41**), use a vacuum nozzle to remove collected dust from inlet vent filters.

If the filters are extremely clogged, remove the four screws and the external covers also shown in **Figure 41** and clean like exhaust fan filters.





Figure 41. Air filter external covers.

Coolant Reservoir

Hazards

As cutting fluid ages, heavy metals and dangerous microbes can accumulate and create a poison hazard. The risk of exposure to this hazard can be greatly reduced by replacing old cutting fluid on a monthly basis, as indicated in the maintenance schedule or according to manufacturer's recommendations.

The important thing to keep in mind when working with the cutting fluid is to minimize exposure to your skin, eyes, and respiratory system by wearing the proper PPE (personal protective equipment), such as splash-resistant safety glasses, long-sleeve gloves, protective clothing, and a NIOSH approved respirator.

| | |
|---|---|
|  | <p>! WARNING BIOLOGICAL & POISON HAZARD!</p> <p>Use the correct personal protection equipment when handling cutting fluid. Follow federal, state, and fluid manufacturer requirements for proper disposal.</p> |
|  | |

A small amount of coolant is lost during normal operation. Keep the coolant reservoir filled to the point where the strainer screen is slightly submerged under the surface of the coolant. By doing so a quick visual check can be made before every use. Under all circumstances (as checked with a dip wire), the coolant should never fall below a 2" level in the base reservoir. Change or service coolant according to manufacturer's instructions.

The coolant reservoir holds approximately five gallons (19 liters) of fluid.

Checking Coolant Level

1. Clean away debris and grime from coolant drain screen on base of mill (see **Figure 42**), and verify that screen is slightly submerged.




Figure 42. Location of the coolant drain screen.

NOTICE

Running coolant pump without adequate coolant in reservoir may permanently damage coolant pump and is not covered under warranty.

2. If coolant level in reservoir is less than 2", pour more coolant through screen and into reservoir until drain screen is seen to be slightly submerged.

Changing Coolant

Tools Needed

| | Qty |
|------------------------------|----------|
| Cleaning Solution | As Reqd. |
| Hex Wrench 3, 5mm | 1 Ea |
| Ratchet 1/2" Drive..... | 1 |
| Shallow Catch Pan..... | 1 |
| Bucket 5 Gal..... | 1 |
| Rubber Hose (optional) | 1 |

To change coolant:

1. Put on appropriate personal protective equipment.
2. Clean away chips and shavings from coolant drain screen on base of mill.
3. Place bucket on milling table.
4. Use coolant pump and nozzle to pump coolant from reservoir into bucket. If required, use rubber hose as nozzle extension.

Note: *In event that reservoir was full and coolant flow was foamy or had limited flow with valve fully open pump intake may be restricted and require cleaning. Otherwise go to Step 8.*

5. DISCONNECT MILL FROM POWER!
6. Remove coolant reservoir access panel from rear of column.
7. Remove pump mounting screws and move pump out of way (see **Figure 43**).




Figure 43. Rear access of coolant pump.

8. Place shallow catch pan under rear drain plug (see **Figure 44**) and remove plug.



Figure 44. Reservoir drain plug location (rear side of machine base).

9. Allow remaining coolant to drain, and wash out reservoir tank with a cleaner that is soluble with coolant used.
 10. Thoroughly flush and clean around base of pump intake.
- Tip:** Placing a series of magnets at bottom of coolant reservoir can help naturally remove fine metal chips and flakes from being recirculated through cooling system when cutting.
11. When reservoir and pump are clean and dry, reinstall pump (if removed), access panel, and drain plug.
 12. Refill reservoir through catch pan with coolant until drain screen stays slightly submerged.

Machine Storage

To avoid control box damage, and rust or corrosion damage to metal surfaces, you must properly prepare the mill for storage if it will not be operated for any length of time.

You also must make certain that the storage environment temperature will maintain between -13°F to 158°F (-25°C to +70°C), and the relative humidity will not exceed 90% (non-condensing).

To prepare mill for storage:

1. DISCONNECT MILL FROM POWER!
 2. Lubricate as directed in **Maintenance** section beginning on **Page 36**.
 3. Remove all coolant as directed in **Changing Coolant** section on **Page 42**.
 4. Blow out coolant lines with compressed air.
 5. Thoroughly clean all unpainted, bare metal surfaces, then coat them with quality rust preventative. Take care to ensure these surfaces are completely covered but that rust preventative is kept off painted surfaces.
- Tip:** *If mill will be out of service for less than a year, use way oil or good grade of medium-weight machine oil (not motor oil or WD-40) in place of rust preventative.*
6. Painted surfaces may be cleaned and waxed with any quality automotive car wax.
 - If machine will be out of service for year or longer, drain oiler and blow out oil lines with compressed air.
 - If machine will be out of service for year or longer, loosen the belts to prevent them from stretching during storage. Post a reminder on mill that belts need to be re-installed or tensioned before resuming operations.
 - If machine will be out of service for year or longer, place a few moisture-absorbing desiccant packs inside electrical and control panel boxes.
 7. Cover and place the machine in dry area that is out of direct sunlight and away from hazardous fumes, paint, solvents, or gas. Fumes and sunlight can bleach or discolor paint and plastic parts.

Adjusting Gibs

Gibs are tapered lengths of metal between two sliding surfaces. Gibs control the gap between these surfaces and how accurately they slide. Correctly adjusting the gibs is critical to producing good milling results.

Tight gibs make table movement more accurate but stiff. Loose gibs make moving the table less accurate but easier. The goal of gib adjustment is to remove unnecessary play without causing the ways to bind and the ballscrews to wear prematurely.

Gibs are adjusted with a screw at each end. The screws are adjusted in unison to move the gib back and forth to increase or decrease the gap between the ways. The process of properly adjusting the gibs is a trial-and-error process based on how much preload they apply to the ways.

Refer to **Figures 45–47** to identify the locations of the table, saddle, and knee gibs, and the adjustment screws for each.

The saddle and knee have three gibs each—two on each side, and one that is left of center. Adjust the gibs on the sides first, then adjust the left-center gib.

To adjust gibs:

1. DISCONNECT MILL FROM POWER!
2. Remove small parts, such as way wipers and covers, to access gib adjustment screws.
3. Loosen all table and knee locks, and clean and lightly oil ways.
4. Center table on saddle.
5. Loosen one gib adjustment screw and tighten opposing screw same amount to move gib.
6. Use handwheel crank to move the table and knee until you feel a slight drag.
7. Reinstall small parts, such as way wipers and covers that were removed to access gib adjustment screws.




Figure 45. Typical table gib and adjustment screw underneath the left side of the table.




Figure 46. Typical saddle gib adjustment screws.




Figure 47. Typical knee gib adjustment screws.

Adjusting X-, Y-, and Z- Ballscrew Backlash

This milling machine uses ballscrew technology for X-, Y-, and Z-axes movement. Unlike a standard half-nut and lead screw design, the ballscrew design requires no periodic adjustment and should last the life of the machine.

Main Belt Tensioning

Power is transferred from the motor to the spindle with a heavy-duty cogged or synchronous belt. With normal use, the belt will gradually stretch over time. When it does, perform the following procedure to re-tension it.

| Tools Needed | Qty |
|------------------------|-----|
| Hex Wrench 2.5mm | 1 |
| Hex Wrench 10mm | 1 |

To re-tension belt:

1. DISCONNECT MILL FROM POWER!
2. Loosen two motor mount cap screws, one on each side of motor (see **Figure 48**).




Figure 48. Belt tensioning controls.

3. Push belt tension adjustment lever back with moderate force until no slop exists. Correct adjustment is zero deflection with only slight pulley preload.
4. While holding tension, tighten adjustment cap screw against motor mounting plate to secure setting.

5. Re-tighten motor mount cap screws.

If it has been a long period of time and belt has not been inspected, or it is suspected that there is a belt problem, vent cover can be removed (see **Figure 49**) for belt inspection and belt changes.




Figure 49. Cogged belt inspection, cover removed.

Servo Motor Belt Replacement

Power is transferred from servo motor to X- and Y-axis ballscrews with cogged or synchronous belts. With normal use, belts will gradually require adjustment or replacement. When they do, follow these procedures.

X-Axis Belt

| Tools Needed | Qty |
|------------------------|-----|
| Hex Wrench 2.5mm | 1 |
| Hex Wrench 3mm | 1 |
| Hex Wrench 5mm | 1 |
| Wrench 10mm | 1 |
| Wrench 19mm | 1 |

To re-tension or replace belt:

1. DISCONNECT MILL FROM POWER!
2. Flip down folding handwheel lever and push on handwheel so it locks with shaft.

3. While holding handwheel locked with shaft, remove shaft nut shown in **Figure 50**.




Figure 50. X-axis handwheel.

4. Slide handwheel off of shaft.
5. Without losing shaft key (see **Figure 51**), slide hub off shaft.

Note: *If hub is tight, tap with block of wood and it should release and then slide off.*




Figure 51. X-axis hub.

6. Remove six cover screws and cover.
7. Loosen three motor mount cap screws (see **Figure 52**).




Figure 52. X-axis synchronous drive belt.

8. Loosen belt tensioner jam nut.
9. Adjust belt tensioner (see **Figure 53**) loosen belt.




Figure 53. X-axis drive belt tensioner.

10. Replace belt.
11. Tension belt so it is tight without slop. Correct adjustment is zero deflection with only slight pulley preload.
12. Retighten tensioner jam nut, motor mount bolts, and reinstall cover using its six screws.
13. Reinstall shaft key, hub, and handwheel.

Y-Axis Belt

Tools Needed

| | Qty |
|------------------------|-----|
| Hex Wrench 2.5mm | 1 |
| Hex Wrench 3mm | 1 |
| Hex Wrench 5mm | 1 |
| Wrench 19mm | 1 |

To tension or replace belt:

1. DISCONNECT MILL FROM POWER!
2. Flip down folding handwheel lever and push on handwheel so it locks with shaft.
3. While holding handwheel locked with shaft, remove shaft nut shown in **Figure 54**.




Figure 54. Y-axis handwheel assembly.

4. Slide handwheel off of shaft.
5. Without losing shaft key (see **Figure 55**), slide hub off shaft.

Note: *If hub is tight, tap with block of wood and it should release and then slide off.*




Figure 55. Y-axis hub assembly.

6. Remove six cover screws and cover.
7. Loosen four motor mount bolts (see **Figure 56**).




Figure 56. Y-axis synchronous drive belt.

8. Grasp motor from underside and lift slightly to de-tension belt.
9. Replace belt.
10. Lower motor to tension belt so it is tight without any slop. Correct adjustment is zero deflection with only slight pulley preload.
11. Retighten motor mount bolts, and reinstall cover using six screws.
12. Reinstall the shaft key, hub, and handwheel.

If you need replacement parts, or if you are unsure how to do any of the solutions given here, feel free to call us at (360) 734-1540.

| Symptom | Possible Cause | Possible Solution |
|--|--|---|
| Machine does not start or a breaker trips on start-up. | <ol style="list-style-type: none"> 1. EMERGENCY STOP button pushed in or at fault. 2. Main power switch not turned ON. 3. Main power switch at fault. 4. Plug/receptacle at fault or wired incorrectly. 5. Power supply switched OFF or at fault. 6. Motor connection wired incorrectly. 7. ON button or spindle direction switch at fault. 8. Motor windings or motor at fault. | <ol style="list-style-type: none"> 1. Rotate the button clockwise until it pops out; replace if necessary. 2. Make sure the electrical box door is closed and securely latched, then turn main power switch ON. 3. Replace main power switch. 4. Test for good contacts; correct wiring. 5. Ensure hot lines have correct voltage on all legs and main power supply is switched ON. 6. Correct motor wiring connections. 7. Replace faulty ON button or spindle direction switch. 8. Replace motor. |
| Machine stalls or is overloaded. | <ol style="list-style-type: none"> 1. Tool path is too aggressive. 2. Workpiece alignment is poor. 3. Dull or incorrect cutting tool. 4. Plug/receptacle at fault or wired incorrectly; incorrect voltage coming from power source. 5. Motor bearings at fault. 6. Motor has overheated. 7. Motor is at fault. | <ol style="list-style-type: none"> 1. Use smaller or sharper tooling; reduce the feed rate; reduce the spindle speed; use coolant. 2. Eliminate workpiece binding; use vise or clamps as required for proper workpiece alignment control. 3. Use sharp and correct cutting tool for the operation. 4. Test for good contact; correct wiring problems; ensure hot lines have correct voltage on all legs. 5. Test by rotating shaft; rotation grinding/loose shaft requires bearing replacement. 6. Clean off motor, let cool, and reduce workload. 7. Replace motor. |
| Machine has vibration or noisy operation. | <ol style="list-style-type: none"> 1. Tool holder or cutter is at fault. 2. Workpiece alignment is poor. 3. Motor or component is loose. 4. Pulley is loose. 5. Machine is incorrectly mounted to floor or sits unevenly. 6. Motor fan is rubbing on fan cover. 7. Pulley(s) slipping on shaft. 8. Motor bearings at fault. 9. Gearbox is at fault. | <ol style="list-style-type: none"> 1. Replace out-of-round tool holder; replace/re-sharpen cutter; use appropriate feed rate spindle speed. 2. Eliminate workpiece binding; use vise or clamps as required for proper workpiece alignment control. 3. Inspect/replace stripped or damaged bolts/nuts and re-tighten with thread locking fluid. 4. Re-align/replace shaft, pulley, set screw, and key as required. 5. Re-tighten/replace mounting bolts in floor; relocate/shim machine. 6. Replace dented fan cover or fan. 7. Replace loose pulley/shaft. 8. Test by rotating shaft; rotation grinding/loose shaft requires bearing replacement. 9. Rebuild gearbox for bad gear(s)/bearing(s). |

| Symptom | Possible Cause | Possible Solution |
|--|---|---|
| Workpiece chatters or vibrates during operation. | <ol style="list-style-type: none"> 1. Table/saddle/knee locks not tight. 2. Workpiece not securely clamped to table or mill vise. 3. Tool not secure or is damaged. 4. Spindle speed too fast/feed rate too slow. 5. Gibs are too loose. | <ol style="list-style-type: none"> 1. Tighten all locks on mill that are not associated with necessary table movement for the operation. 2. Check that clamping is tight and sufficient for the operation; make sure mill vise is clamped tight to table. 3. Properly secure the tool; replace if damaged. 4. Use correct spindle speed and feed rate. 5. Properly adjust gibs (Page 44). |
| Table hard to move. | <ol style="list-style-type: none"> 1. Table/saddle/knee locks are tightened down. 2. Chips have loaded up on the ways. 3. Ways are dry and in need of lubrication. 4. Gibs are too tight. | <ol style="list-style-type: none"> 1. Loosen the locks needed for movement. 2. Frequently clean away chips from the ways that build up during operation. 3. Troubleshoot the automatic oiler/refill (Page 37). 4. Properly adjust gibs (Page 44). |
| Bad surface finish. | <ol style="list-style-type: none"> 1. Wrong spindle speed/feed rate. 2. Dull/damaged tool; wrong tool for operation. 3. Wrong spindle rotation direction for tool. 4. Workpiece not securely clamped to table or mill vise. 5. Gibs are too loose. | <ol style="list-style-type: none"> 1. Use correct spindle speed and feed rate. 2. Sharpen/replace tool; use correct tool for operation. 3. Check for proper spindle rotation direction for tool. 4. Check that clamping is tight and sufficient for the operation; make sure mill vise is clamped tight to table. 5. Properly adjust gibs (Page 44). |
| Machine is loud when cutting; overheats or bogs down in the cut. | <ol style="list-style-type: none"> 1. Excessive depth of cut. 2. Dull tooling. 3. Feed rate too fast. | <ol style="list-style-type: none"> 1. Decrease depth of cut and allow chips to clear. 2. Use sharp tooling. 3. Decrease feed rate. |
| Breaking tooling. | <ol style="list-style-type: none"> 1. Spindle speed/feed rate too fast. 2. Tooling getting too hot. 3. Excessive depth of cut. 4. Workpiece not securely clamped to table or mill vise. 5. Gibs are too loose. | <ol style="list-style-type: none"> 1. Use correct spindle speed and feed rate. 2. Use coolant; reduce spindle RPM/feed rate. 3. Correct tool path to decrease depth of cut and allow chips to clear. 4. Check that clamping is tight and sufficient for the operation; make sure mill vise is clamped tight to table. 5. Properly adjust gibs. |

Electrical Safety Instructions

These pages are accurate at the time of printing. In the constant effort to improve, however, we may make changes to the electrical systems of future machines. Study this section carefully. If you see differences between your machine and what is shown in this section, call Technical Support at (360) 734-1540 for assistance BEFORE making any changes to the wiring on the machine.

Shock Hazard: It is extremely dangerous to perform electrical or wiring tasks while the machine is connected to the power source. Touching electrified parts will result in personal injury including but not limited to severe burns, electrocution, or death. For your own safety, disconnect machine from the power source before servicing electrical components or performing any wiring tasks!

Wire Connections: All connections must be tight to prevent wires from loosening during machine operation. Double-check all wires disconnected or connected during any wiring task to ensure tight connections.

Modifications: Using aftermarket parts or modifying the wiring beyond what is shown in the diagram may lead to unpredictable results, including serious injury or fire.

Motor Wiring: The motor wiring shown in these diagrams is current at the time of printing, but it may not match your machine. Always use the wiring diagram inside the motor junction box.





















Circuit Requirements: Connecting the machine to an improperly sized circuit will greatly increase the risk of fire. To minimize this risk, only connect the machine to a power circuit that meets the minimum requirements given in this manual.

Capacitors/Inverters: Some capacitors and power inverters store an electrical charge for up to 10 minutes after being disconnected from the power source. To reduce the risk of being shocked, wait at least this long before working on capacitors.

Wire/Component Damage: Damaged wires or components increase the risk of serious personal injury, fire, or machine damage. If you notice that any wires or components are damaged while performing a wiring task, replace those wires or components before completing the task.


Experiencing Difficulties: If you are experiencing difficulties understanding the information included in this section, contact our Technical Support at (360) 734-1540.

WIRING DIAGRAM COLOR KEY


| | | | | |
|---|---|---|--|---|
| BLACK  | BLUE WHITE  | RED  | PINK  | WHITE  |
| BLUE  | GREEN  | LIGHT BLUE  | PURPLE  | YELLOW GREEN  |
| BROWN  | GRAY  | ORANGE  | TUR-QUIOSE  | YELLOW  |
| BLACK GRAY  | GRAY BLACK  | GRAY WHITE  | LIGHT GREEN  | YELLOW BROWN  |

NOTICE: The photos and diagrams included in this section are best viewed in color. You can see them in color at www.southbendlathe.com.

Wiring Overview



Wiring Visual Index



General Component Wiring




Figure 57. Electrical cabinet wiring with equipment number tags.





Figure 58. Master power switch (QS1).



General Component Wiring (Cont.)

Control Panel Switch Box (as seen from behind)





Figure 59. Control panel switches.




Figure 60. Control panel switches.

General Component Wiring (Cont.)




Figure 61. X-Axis limit switch (LS1).




Figure 62. Y-Axis limit switch (LS2).






Figure 63. Automatic oiler (M13).



General Component Wiring (Cont.)





Figure 64. Spindle brake switch (LS7).




Figure 66. Spindle speed range switch (LS6).



Figure 65. Spindle motor wiring (220V) (M3).

General Component Wiring (Cont.)



Figure 67. Z-axis motor wiring (220V) (M2).





Figure 68. Z-axis crank safety switch (LS8).



General Component Wiring (Cont.)



Figure 69. Z-axis limit switches (LS9 & LS10).






Figure 70. Coolant pump motor wiring (220V) (M1).



General Component Wiring (Cont.)



Figure 71. Spindle limit switches (LS3 & LS5).




To Main Electrical Cabinet (see Figure 57)



Figure 72. Cooling fans (M9 & M10).

Part of Electrical Cabinet (see Figure 57)



General Component Wiring (Cont.)




Figure 73. Power drawbar air and oil controller (SOL.1).






Figure 74. Power drawbar control switches.



General Component Wiring (Cont.)




Figure 75. Machine mode indicator light.






Figure 76. Machine mode indicator light pigtail.


Electrical Schematics



| MACHINE TYPE | DATE | FILE NAME | PAGE |
|--------------|------|-----------|------|
| FAGOR 8055iM | | - | A1 |
| TITLE : | | DESIGN | |




| MACHINE TYPE | DATE | FILE NAME | PAGE |
|--------------|------|-----------|------|
| FAGOR 8055iM | - | - | A2 |
| TITLE : | - | - | - |





| | |
|--------------|-----------|
| MACHINE TYPE | DATE |
| FAGOR 8055iM | FILE NAME |
| TITLE : | DESIGN |
| - | - |
| - | - |

| | |
|------|----|
| PAGE | A3 |
|------|----|




| | | |
|--------------|-----------|----|
| MACHINE TYPE | DATE | |
| FAGOR 8055iM | FILE NAME | - |
| TITLE : | DESIGN | - |
| | PAGE | A4 |







| | | |
|--------------|-----------|----|
| MACHINE TYPE | DATE | |
| FAGOR 8055iM | FILE NAME | - |
| TITLE : | DESIGN | - |
| | PAGE | B2 |




| | | | |
|--------------|--|-----------|----|
| MACHINE TYPE | | DATE | |
| FAGOR 8055iM | | FILE NAME | - |
| TITLE : | | DESIGN | - |
| | | PAGE | B3 |




| | |
|--------------|-----------|
| MACHINE TYPE | DATE |
| FAGOR 8055iM | FILE NAME |
| TITLE : | DESIGN |
| - | - |
| - | PAGE |
| - | C1 |




| | | |
|--------------|--|-----------|
| MACHINE TYPE | | DATE |
| FAGOR 8055iM | | FILE NAME |
| TITLE : | | DESIGN |
| - | | - |
| - | | PAGE |
| - | | D1 |




| | | | |
|--------------|--|-----------|----|
| MACHINE TYPE | | DATE | |
| FAGOR 8055iM | | FILE NAME | - |
| TITLE : | | DESIGN | - |
| | | PAGE | E1 |




| | | | |
|--------------|--|-----------|----|
| MACHINE TYPE | | DATE | |
| FAGOR 8055iM | | FILE NAME | - |
| TITLE : | | DESIGN | - |
| | | PAGE | E2 |







| | |
|--------------|-----------|
| MACHINE TYPE | DATE |
| FAGOR 8055iM | FILE NAME |
| TITLE : | DESIGN |
| | PAGE |
| | F2 |




| DATE | FILE NAME | DESIGN | PAGE | G1 |
|--------------|-----------|--------------|------|----|
| - | - | - | - | - |
| MACHINE TYPE | | FAGOR 8055iM | | |
| TITLE : | | - | | |




| | | | |
|--------------|--|-----------|------|
| MACHINE TYPE | | DATE | PAGE |
| FAGOR 8055iM | | FILE NAME | G2 |
| TITLE : | | DESIGN | |
| | | | |




| | | | | | |
|--------------|--|--|-----------|--|------|
| MACHINE TYPE | | | DATE | | |
| FAGOR 8055iM | | | FILE NAME | | |
| TITLE : | | | DESIGN | | PAGE |
| | | | | | G3 |




| | | | |
|--------------|-----------|------|----|
| MACHINE TYPE | DATE | PAGE | G4 |
| FAGOR 8055iM | FILE NAME | - | - |
| TITLE : | DESIGN | - | - |




| | | | |
|--------------|--|-----------|----|
| MACHINE TYPE | | DATE | |
| FAGOR 8055iM | | FILE NAME | |
| TITLE : | | DESIGN | |
| | | PAGE | G5 |





| MACHINE TYPE | | DATE | FILE NAME | PAGE | G6 |
|--------------|--|--------|-----------|------|----|
| FAGOR 8055iM | | - | - | - | - |
| TITLE : | | DESIGN | | | |






| | | | |
|--------------|--|-----------|----|
| MACHINE TYPE | | DATE | |
| FAGOR 8055iM | | FILE NAME | |
| TITLE : | | DESIGN | |
| | | PAGE | G8 |






| | | | |
|--------------|--|-----------|-----|
| MACHINE TYPE | | DATE | - |
| FAGOR 8055iM | | FILE NAME | - |
| TITLE : | | DESIGN | - |
| | | PAGE | G10 |



Headstock



Headstock Parts List

| REF | PART # | DESCRIPTION |
|-----|--------------|---------------------------------|
| 1A | PSB10630001A | LEVER HANDLE AND HUB ASSEMBLY |
| 1 | PSB10630001 | BALL KNOB 3/8-16 |
| 2 | PSB10630002 | LEVER HANDLE |
| 3 | PSB10630003 | DOWNFEED SHAFT HUB |
| 4 | PSB10630004 | STEEL BALL 3/16 |
| 5 | PSB10630005 | COMPRESSION SPRING |
| 6 | PSB10630006 | CAP SCREW 5/16-18 X 1/4 |
| 7 | PSB10630007 | HUB RETAINER |
| 8 | PSB10630008 | PINION SHAFT HUB SLEEVE |
| 9 | PSB10630009 | CAP SCREW M5-.8 X 12 |
| 10 | PSB10630010 | RETURN SPRING COVER |
| 11 | PSB10630011 | FLAT COIL SPRING |
| 12 | PSB10630012 | KEY 3 X 3 X 18 RE |
| 13 | PSB10630013 | BLOCK HEAD STUD |
| 14 | PSB10630014 | QUILL PINION GEAR SHAFT 10T/16T |
| 15 | PSB10630015 | BALL KNOB 1/4-20 |
| 16 | PSB10630016 | SHIFT CRANK |
| 17 | PSB10630017 | SET SCREW 1/4-20 X 1/4 |
| 18 | PSB10630018 | COMPRESSION SPRING |
| 19 | PSB10630019 | GEAR SHIFT PLUNGER |
| 20 | PSB10630020 | SHIFT SLEEVE |
| 21 | PSB10630021 | WORM LINK |
| 22 | PSB10630022 | WORM SHAFT |
| 23 | PSB10630023 | SET SCREW M6-1 X 10 |
| 24 | PSB10630024 | KEY 4 X 4 X 18 RE |
| 25 | PSB10630025 | WORM GEAR |
| 26 | PSB10630026 | CLUSTER GEAR BEARING |
| 27 | PSB10630027 | FEED CLUSTER GEAR 17T/28T/22T |
| 28 | PSB10630028 | EXT RETAINING RING 16MM |
| 29 | PSB10630029 | BUSHING |
| 30 | PSB10630030 | THRUST SPACER |
| 31 | PSB10630031 | FEED REVERSE PINION GEAR |
| 32 | PSB10630032 | KEY 3 X 3 X 45 RE |
| 33 | PSB10630033 | FEED ENGAGE PIN |
| 34A | PSB10630034A | WORM GEAR CRADLE ASSEMBLY |
| 34 | PSB10630034 | WORM GEAR CRADLE |
| 35 | PSB10630035 | SET SCREW M5-.8 X 6 |
| 36 | PSB10630036 | FEED DRIVE WORM GEAR |
| 37 | PSB10630037 | SPACER |
| 38 | PSB10630038 | WORM CRADLE SLEEVE |
| 39 | PSB10630039 | EXT RETAINING RING 18MM |
| 40 | PSB10630040 | KEY 4 X 4 X 12 |
| 41 | PSB10630041 | FEED REVERSE PINION GEAR |
| 42 | PSB10630042 | CAP SCREW 5/16-18 X 1/2 |
| 43 | PSB10630043 | FLAT WASHER 8 X 21 X 2 |
| 44 | PSB10630044 | FEED BEVEL GEAR 24T |
| 45 | PSB10630045 | KEY 3 X 3 X 8 RE |
| 46 | PSB10630046 | CLUSTER GEAR SHAFT 18T/12T |
| 47 | PSB10630047 | FEED DRIVE CLUSTER GEAR 23T |
| 48 | PSB10630048 | NEEDLE BEARING BZ66Z |
| 49 | PSB10630049 | REVERSE CLUTCH ROD |
| 50A | PSB10630050A | FEED REVERSE BEVEL GEAR SET |

| REF | PART # | DESCRIPTION |
|-----|--------------|--------------------------------|
| 50 | PSB10630050 | FEED REVERSE GEAR |
| 51 | PSB10630051 | FEED REVERSE CLUTCH |
| 52 | PSB10630052 | ROLL PIN 3 X 20 |
| 53 | PSB10630053 | EXT RETAINING RING 12MM |
| 54 | PSB10630054 | BUSHING |
| 55 | PSB10630055 | KEY 3 X 3 X 10 RE |
| 56 | PSB10630056 | KEY 3 X 3 X 15 RE |
| 57 | PSB10630057 | WORM SHAFT |
| 58 | PSB10630058 | BUSHING |
| 59 | PSB10630059 | CAP SCREW M6-1 X 20 |
| 60 | PSB10630060 | SET SCREW M6-1 X 10 |
| 61 | PSB10630061 | FEED GEAR SHIFTER FORK |
| 62 | PSB10630062 | CLUSTER GEAR SHIFT CRANK |
| 63 | PSB10630063 | FEED SHIFT ROD |
| 64 | PSB10630064 | CLUSTER GEAR COVER |
| 65 | PSB10630065 | QUILL PINION SHAFT BUSHING |
| 66 | PSB10630066 | OVERLOAD CLUTCH WORM GEAR 30T |
| 67 | PSB10630067 | EXT RETAINING RING 15MM |
| 68A | PSB10630068A | PINION OVERLOAD CLUTCH ASSY |
| 68 | PSB10630068 | PINION OVERLOAD CLUTCH SHAFT |
| 69 | PSB10630069 | OVERLOAD CLUTCH |
| 70 | PSB10630070 | COMPRESSION SPRING |
| 71 | PSB10630071 | SET SCREW M5-.8 X 10 |
| 72 | PSB10630072 | PINION OVERLOAD CLUTCH COLLAR |
| 73 | PSB10630073 | CLUTCH RING |
| 74 | PSB10630074 | CLUTCH WASHER |
| 75 | PSB10630075 | EXT RETAINING RING 10MM |
| 76 | PSB10630076 | PIVOT STUD |
| 77 | PSB10630077 | OVERLOAD CLUTCH TRIP LEVER |
| 78 | PSB10630078 | ROLL PIN 5 X 20 |
| 79 | PSB10630079 | CLUTCH ARM COVER |
| 80 | PSB10630080 | CAP SCREW M5-.8 X 35 |
| 81 | PSB10630081 | HEX NUT 1/4-20 |
| 82 | PSB10630082 | SET SCREW 1/4-20 X 3/4 |
| 83 | PSB10630083 | COMPRESSION SPRING |
| 84 | PSB10630084 | OVERLOAD CLUTCH PLUNGER |
| 85 | PSB10630085 | OIL CUP FITTING 1/8 PT |
| 86 | PSB10630086 | INDICATOR ROD LOCK KNOB |
| 87 | PSB10630087 | INDICATOR ROD |
| 88 | PSB10630088 | REVERSE TRIP HEAD STUD |
| 89 | PSB10630089 | FEED REVERSE TRIP PLUNGER |
| 90 | PSB10630090 | REVERSE TRIP BALL LEVER |
| 91 | PSB10630091 | QUILL STOP BLOCK |
| 92 | PSB10630092 | CAP SCREW 3/8-16 X 5/8 |
| 93 | PSB10630093 | QUILL MICRO STOP (INCH) |
| 94 | PSB10630094 | STOP TRIP BAR |
| 95 | PSB10630095 | FEED TRIP BRACKET |
| 96 | PSB10630096 | LEVER HANDLE (STOP SHAFT TRIP) |
| 97 | PSB10630097 | TRIP PLUNGER BUSHING |
| 98 | PSB10630098 | FEED TRIP PLUNGER |
| 99 | PSB10630099 | FEED TRIP LEVER |
| 100 | PSB10630100 | TRIP LEVER PIN |


Headstock Parts List, continued

| REF | PART # | DESCRIPTION |
|-----|-------------|-----------------------|
| 101 | PSB10630101 | HEX NUT M4-0.7 |
| 102 | PSB10630102 | SET SCREW M4-.7X16 |
| 103 | PSB10630103 | HANDWHEEL CLUTCH |
| 104 | PSB10630104 | STEEL BALL 5MM |
| 105 | PSB10630105 | COMPRESSION SPRING |
| 106 | PSB10630106 | SET SCREW M8-1.25 X 6 |
| 107 | PSB10630107 | PHLP HD SCR M4-.7X 6 |
| 108 | PSB10630108 | QUILL DEPTH SCALE |
| 109 | PSB10630109 | ROLL PIN 3X16 |
| 110 | PSB10630110 | HANDWHEEL TYPE 3 |

| REF | PART # | DESCRIPTION |
|-----|-------------|---------------------------|
| 111 | PSB10630111 | FIXED HANDLE |
| 112 | PSB10630112 | KNURLED SLEEVE |
| 113 | PSB10630113 | QUILL WEDGE NUT |
| 114 | PSB10630114 | QUILL WEDGE SLEEVE |
| 115 | PSB10630115 | ADJUSTABLE LOCK HANDLE |
| 116 | PSB10630116 | SQUARE HEAD HARDENED BOLT |
| 117 | PSB10630117 | SPACER |
| 118 | PSB10630118 | HARD WASHER |
| 119 | PSB10630119 | HIGH NUT |
| 120 | PSB10630120 | QUILL HOUSING |

Quill & Spindle Feed

NOTE: Items shown are for reference purposes and all parts may not be available as single items.





Quill & Spindle Feed Parts List

| REF | PART # | DESCRIPTION |
|------|--------------|--------------------------------|
| 201 | PSB10630201 | SPINDLE NT40 |
| 202 | PSB10630202 | LOCK LUG |
| 203 | PSB10630203 | CAP SCREW M8-1.25 X 16 |
| 204 | PSB10630204 | NOSE CAP NT40 |
| 205 | PSB10630205 | QUILL END CAP |
| 206 | PSB10630206 | BALL BEARING 7210A5/P4 |
| 207 | PSB10630207 | BEARING SPACER |
| 208 | PSB10630208 | BEARING SPACER |
| 209 | PSB10630209 | SPANNER NUT L5M M50 X 1.5P-L |
| 210 | PSB10630210 | BALL BEARING 6206ZZ |
| 211 | PSB10630211 | EXT RETAINING RING 40MM |
| 212 | PSB10630212 | QUILL SKIRT |
| 213 | PSB10630213 | SET SCREW M5-.8 X 6 |
| 214 | PSB10630214 | QUILL NT40 |
| 215 | PSB10630215 | FLAT WASHER 5MM |
| 216 | PSB10630216 | PHLP HD SCR M5-.8 X 10 |
| 217 | PSB10630217 | DRAWBAR NT40 |
| 218 | PSB10630218 | DRAWBAR SPACER NT40 |
| 219 | PSB10630219 | QUILL HOUSING NT40 |
| 219A | PSB10630219A | QUILL HOUSING NT40 ASSEMBLY |
| 220 | PSB10630220 | BUTTON HD CAP SCR M3-.5 X 16 |
| 221 | PSB10630221 | BUTTON HD CAP SCR M4-.7 X 6 |
| 222 | PSB10630222 | SPINDLE DEPTH SCALE |
| 223 | PSB10630223 | CAP SCREW M6-1 X 40 |
| 224 | PSB10630224 | BUTTON HD CAP SCR M3-.5 X 20 |
| 225 | PSB10630225 | CAP SCREW M6-1 X 12 |
| 226 | PSB10630226 | FLAT WASHER 6MM |
| 227 | PSB10630227 | LIMIT SWITCH MOUNT |
| 228 | PSB10630228 | SPINDLE COVER |
| 229 | PSB10630229 | CAP SCREW M5-.8 X 16 |
| 230 | PSB10630230 | SPACER RING |
| 231 | PSB10630231 | RADIAL LOCK NUT M12 X 1P (VSR) |
| 232 | PSB10630232 | BALL BEARING 7201B |
| 233 | PSB10630233 | SPINDLE CASTING |
| 234 | PSB10630234 | BALL BEARING 6001UU |
| 235 | PSB10630235 | SPACER |
| 236 | PSB10630236 | FLANGE RING |

| REF | PART # | DESCRIPTION |
|-----|-------------|--|
| 237 | PSB10630237 | CAP SCREW M5-.8 X 10 |
| 238 | PSB10630238 | SYNCHRONOUS PULLEY |
| 239 | PSB10630239 | TIMING BELT HTD5M-187-13 HTD TYPE-5M |
| 240 | PSB10630240 | SPINDLE COVER |
| 241 | PSB10630241 | CAP SCREW M6-1 X 16 |
| 242 | PSB10630242 | ADAPTER PLATE |
| 243 | PSB10630243 | SIDE COVER |
| 244 | PSB10630244 | MOTOR COVER |
| 245 | PSB10630245 | SPINDLE SERVO MOTOR |
| 246 | PSB10630246 | CAP SCREW M5-.8 X 14 |
| 247 | PSB10630247 | MOTOR MOUNT |
| 248 | PSB10630248 | KEY 5 X 5 X 20 SRE |
| 249 | PSB10630249 | SET SCREW M4-.7 X 5 |
| 250 | PSB10630250 | TIMING PULLEY |
| 251 | PSB10630251 | MOTOR SIDE COVER |
| 252 | PSB10630252 | CAP SCREW M6-1 X 8 |
| 253 | PSB10630253 | BUTTON HD CAP SCR M5-.8 X 8 |
| 261 | PSB10630261 | BUTTON HD CAP SCR M4-.7 X 8 |
| 262 | PSB10630262 | SPINDLE COVER |
| 263 | PSB10630263 | WINDOW |
| 264 | PSB10630264 | CAP SCREW M4-.7 X 8 |
| 265 | PSB10630265 | FLAT WASHER 4MM |
| 266 | PSB10630266 | POINTER BRACKET |
| 267 | PSB10630267 | CAP SCREW 3/8-16 X 1-1/2 |
| 268 | PSB10630268 | CAP SCREW M6-1 X 25 |
| 269 | PSB10630269 | FEED NUT FORK |
| 270 | PSB10630270 | LUG KEY |
| 271 | PSB10630271 | BALL SCREW R20-5T4-F51-20 |
| 272 | PSB10630272 | FLAT WASHER 5MM |
| 273 | PSB10630273 | CAP SCREW M5-.8 X 20 |
| 274 | PSB10630274 | KEY 4 X 4 X 15 SRE |
| 275 | PSB10630275 | FITTING FEMALE 90 DEG 1/8 X M6-1 |
| 276 | PSB10630276 | FITTING MALE 90 DEG 4 X 1/8 |
| 277 | PSB10630277 | HEX NUT M3-.5 |
| 278 | PSB10630278 | LIMIT SWITCH MOUNT |
| 279 | PSB10630279 | LIMIT SWITCH V-106-1A5 [LS3] AND [LS4] |

Gearbox




NOTE: Items shown are for reference purposes and all parts may not be available as single items.

Gearbox Parts List

| REF | PART # | DESCRIPTION |
|------|--------------|----------------------------|
| 301 | PSB10630301 | KEY 8 X 8 X 15 RE |
| 302A | PSB10630302A | SPINDLE GEAR HUB ASSEMBLY |
| 302 | PSB10630302 | SPLINED GEAR HUB |
| 303 | PSB10630303 | SPINDLE BULL GEAR |
| 304 | PSB10630304 | BEARING SLEEVE |
| 305 | PSB10630305 | BALL BEARING 6910W |
| 306 | PSB10630306 | BEARING SPACER |
| 307A | PSB10630307A | BULL GEAR SPACER ASSEMBLY |
| 307 | PSB10630307 | BEARING SPACER |
| 308 | PSB10630308 | INT RETAINING RING 62MM |
| 309 | PSB10630309 | SPACER |
| 310 | PSB10630310 | EXT TOOTH WASHER |
| 311 | PSB10630311 | SPANNER NUT |
| 312 | PSB10630312 | BEARING SLEEVE WASHER |
| 313 | PSB10630313 | HEADED STEP PIN |
| 314 | PSB10630314 | COMPRESSION SPRING |
| 315 | PSB10630315 | FLAT HD CAP SCR M5-.8 X 10 |
| 316 | PSB10630316 | SQUARE BLOCK TAB |
| 317 | PSB10630317 | OIL CUP FITTING 1/8 PT |
| 318 | PSB10630318 | STEEL FLUTED RIVET 2 X 5MM |
| 319 | PSB10630319 | GEARBOX ID PLATE |
| 320 | PSB10630320 | STUD 1/2-13 |
| 321 | PSB10630321 | LOCK WASHER 1/2 |
| 322 | PSB10630322 | HEX NUT 1/2-13 |
| 323 | PSB10630323 | HEX NUT 5/8-11 |
| 324 | PSB10630324 | BELT PULLEY GEAR |
| 325 | PSB10630325 | CAP SCREW M5-.8 X 16 |

| REF | PART # | DESCRIPTION |
|-----|-------------|------------------------------------|
| 326 | PSB10630326 | BULL GEAR PINION BEARING CAP |
| 327 | PSB10630327 | WAVEY WASHER |
| 328 | PSB10630328 | BALL BEARING 6203W NSK |
| 329 | PSB10630329 | PINION GEAR 26T |
| 330 | PSB10630330 | SET SCREW M8-1.25 X 8 |
| 331 | PSB10630331 | PINION GEAR SHAFT |
| 332 | PSB10630332 | KEY 5 X 5 X 15 RE |
| 333 | PSB10630333 | GREASE FITTING 1/8 PT STRAIGHT |
| 334 | PSB10630334 | GEARBOX HOUSING |
| 335 | PSB10630335 | CAP SCREW M6-1 X 20 |
| 336 | PSB10630336 | DATA PLATE |
| 337 | PSB10630337 | BULL GEAR SHIFT PINION |
| 338 | PSB10630338 | HIGH-LOW DETENT PLATE |
| 339 | PSB10630339 | CAP SCREW M5-.8 X 12 |
| 340 | PSB10630340 | ROLL PIN 3 X 15 |
| 341 | PSB10630341 | SET SCREW M4-.7 X 5 |
| 342 | PSB10630342 | HIGH-LOW PINION BLOCK |
| 343 | PSB10630343 | CAP SCREW M4-.7 X 16 |
| 344 | PSB10630344 | HIGH-LOW DETENT PLUNGER |
| 345 | PSB10630345 | COMPRESSION SPRING |
| 346 | PSB10630346 | LEVER HANDLE (HIGH-LOW) |
| 347 | PSB10630347 | BALL KNOB 1/4-20 |
| 348 | PSB10630348 | PHLP HD SCR M5-.8 X 8 |
| 349 | PSB10630349 | CAP SCREW M4-.7 X 30 |
| 350 | PSB10630350 | SPINDLE GEAR CHANGE LIMIT SW [L56] |
| 351 | PSB10630351 | LIMIT SWITCH MOUNT |
| 352 | PSB10630352 | LIMIT SWITCH BOOT RUBBER |

Belt Housing



Reference View



NOTE: Items shown are for reference purposes and all parts may not be available as single items.

Belt Housing Parts List

| REF | PART # | DESCRIPTION |
|-----|-------------|-------------------------------|
| 401 | PSB10630401 | BUTTON HD CAP SCR M4-.7 X 6 |
| 402 | PSB10630402 | MOTOR FAN COVER |
| 403 | PSB10630403 | MOTOR FAN |
| 404 | PSB10630404 | CAP SCREW M12-1.75 X 35 |
| 405 | PSB10630405 | FLAT WASHER 12MM |
| 406 | PSB10630406 | MOTOR 5HP 220V 3-PH [M3] |
| 407 | PSB10630407 | BELT TENSION ADJUSTMENT LEVER |
| 408 | PSB10630408 | BALL KNOB 5/16-18 |
| 409 | PSB10630409 | MOTOR PULLEY |
| 410 | PSB10630410 | KEY 8 X 7 X 30 SRE |
| 411 | PSB10630411 | HARD WASHER |
| 412 | PSB10630412 | CAP SCREW M8-1.25 X 20 |
| 413 | PSB10630413 | CAP SCREW M6-1 X 20 |
| 414 | PSB10630414 | MOTOR ADJUSTMENT BLOCK |
| 415 | PSB10630415 | CAP SCREW M8-1.25 X 40 |
| 416 | PSB10630416 | SET SCREW M4-.7 X 16 |
| 417 | PSB10630417 | BEARING COVER |
| 418 | PSB10630418 | BELT HOUSING COVER |
| 419 | PSB10630419 | PHLP HD SCR M5-.8 X 8 |
| 420 | PSB10630420 | LIMIT SWITCH MOUNTING BLOCK |
| 421 | PSB10630421 | CAP SCREW M5-.8 X 16 |
| 422 | PSB10630422 | LIMIT SWITCH MJ2-1701 [LS7] |
| 423 | PSB10630423 | FLAT WASHER 4MM |
| 424 | PSB10630424 | CAP SCREW M4-.7 X 30 |
| 425 | PSB10630425 | LIMIT SWITCH COVER |
| 426 | PSB10630426 | PHLP HD SCR M5-.8 X 10 |
| 427 | PSB10630427 | BELT HOUSING |
| 428 | PSB10630428 | SPANNER NUT M45 X 1.5P |
| 429 | PSB10630429 | EXT TOOTH WASHER 45MM |
| 430 | PSB10630430 | BALL BEARING 6009W |
| 431 | PSB10630431 | BEARING SPACER |
| 432 | PSB10630432 | TIMING BELT 800-8YU-25 |

| REF | PART # | DESCRIPTION |
|-----|-------------|-----------------------------|
| 433 | PSB10630433 | SPINDLE TIMING PULLEY |
| 434 | PSB10630434 | BRAKE ASSEMBLY COVER |
| 435 | PSB10630435 | BUTTON HD CAP SCR M6-1 X 12 |
| 436 | PSB10630436 | FLAT WASHER 6MM |
| 437 | PSB10630437 | BRAKE BEARING CAP |
| 438 | PSB10630438 | BUTTON HD CAP SCR M6-1 X 16 |
| 439 | PSB10630439 | BRAKE SHOE PIVOT SLEEVE |
| 440 | PSB10630440 | PHLP HD SCR M3-.5 X 6 |
| 441 | PSB10630441 | EXTENSION SPRING |
| 442 | PSB10630442 | BRAKE SHOE SET |
| 443 | PSB10630443 | BALL BEARING 6012W |
| 444 | PSB10630444 | CAP SCREW M6-1 X 16 |
| 445 | PSB10630445 | BRAKE SEAT |
| 446 | PSB10630446 | SPACER |
| 447 | PSB10630447 | SPINDLE PULLEY HUB |
| 448 | PSB10630448 | KEY 8 X 7 X 70 RE |
| 449 | PSB10630449 | TIMING BELT 230L-100 |
| 450 | PSB10630450 | SPINDLE PULLEY HUB COLLAR |
| 451 | PSB10630451 | EXT RETAINING RING 13MM |
| 452 | PSB10630452 | SET SCREW M6-1 X 8 |
| 453 | PSB10630453 | BRAKE SHAFT SLEEVE |
| 454 | PSB10630454 | BRAKE SHAFT |
| 455 | PSB10630455 | E-CLIP 4MM |
| 456 | PSB10630456 | BRAKE LEVER PIVOT BRACKET |
| 457 | PSB10630457 | SET SCREW M5-.8 X 6 |
| 458 | PSB10630458 | HEADED PIN |
| 459 | PSB10630459 | LEVER HANDLE (BRAKE) |
| 460 | PSB10630460 | BALL KNOB 3/8-16 |
| 461 | PSB10630461 | BRAKE OPERATING FINGER |
| 462 | PSB10630462 | BRAKE FINGER PIVOT STUD |
| 463 | PSB10630463 | EXT RETAINING RING 7MM |

Ram




NOTE: Items shown are for reference purposes and all parts may not be available as single items.

| REF | PART # | DESCRIPTION |
|-----|-------------|----------------------------|
| 501 | PSB10630501 | CAP SCREW M8-1.25 X 25 |
| 502 | PSB10630502 | DOWEL PIN 8 X 30 |
| 503 | PSB10630503 | GEAR 33T |
| 504 | PSB10630504 | STEEL FLUTED RIVET 2 X 5MM |
| 505 | PSB10630505 | HEAD ROTATION SCALE |
| 506 | PSB10630506 | RAM ADAPTER, NT40 |
| 507 | PSB10630507 | POINTER |
| 508 | PSB10630508 | LOCK COLLAR |
| 509 | PSB10630509 | SET SCREW M6-1 X 6 |
| 510 | PSB10630510 | KEY 5 X 5 X 45 RE |
| 511 | PSB10630511 | HEAD TILT WORM GEAR |
| 512 | PSB10630512 | THRUST WASHER |
| 513 | PSB10630513 | HEAD TILT SCALE |
| 514 | PSB10630514 | TILT LOCK BOLT |
| 515 | PSB10630515 | FLAT WASHER 14MM |
| 516 | PSB10630516 | EXT RETAINING RING 32MM |

| REF | PART # | DESCRIPTION |
|-----|-------------|----------------------|
| 517 | PSB10630517 | PIVOT PIN |
| 518 | PSB10630518 | BUSHING |
| 519 | PSB10630519 | HEAD TILT WORM SHAFT |
| 520 | PSB10630520 | EYE BOLT 3/8-10 |
| 521 | PSB10630521 | RAM |
| 522 | PSB10630522 | RAM TURRET GIB |
| 523 | PSB10630523 | TURRET CLAMP BOLT |
| 524 | PSB10630524 | SHOULDER SCREW |
| 525 | PSB10630525 | RAM TURRET |
| 526 | PSB10630526 | ADJUSTMENT STUD |
| 527 | PSB10630527 | HEX NUT 3/8-16 |
| 528 | PSB10630528 | RAM LOCK PLUNGER |
| 529 | PSB10630529 | ADJUSTABLE HANDLE |
| 530 | PSB10630530 | TOOTHED PINION SHAFT |
| 531 | PSB10630531 | ROTATION SCALE |
| 532 | PSB10630532 | TURRET BRACKET |

Column, Knee & Saddle




Column, Knee & Saddle Parts List

| REF | PART # | DESCRIPTION |
|------|--------------|----------------------------------|
| 601 | PSB10630601 | COLUMN |
| 602 | PSB10630602 | COOLANT RESERVOIR COVER |
| 603 | PSB10630603 | PHLP HD SCR M5-.8 X10 |
| 604 | PSB10630604 | DRAIN PLUG 1/2 PT |
| 605 | PSB10630605 | FLAT WASHER 5MM |
| 606 | PSB10630606 | PHLP HD SCR M5-.8 X12 |
| 607 | PSB10630607 | CAP SCREW M8-1.25 X16 |
| 608 | PSB10630608 | ANGULAR CONTACT BEARING 3305 |
| 609 | PSB10630609 | BEARING CAP |
| 610 | PSB10630610 | CAP SCREW M6-1 X16 |
| 611 | PSB10630611 | KEY 5 X 5 X 15 RE |
| 612A | PSB10630612A | ELEVATION BALLSCREW ASSEMBLY |
| 612 | PSB10630612 | ELEVATION BALLSCREW |
| 613 | PSB10630613 | CAP SCREW M8-1.25 X 20 |
| 614 | PSB10630614 | ELEVATION BALLSCREW NUT |
| 615 | PSB10630615 | GREASE FITTING 1/8" NPT STRAIGHT |
| 616 | PSB10630616 | ELEVATING BALLSCREW HOUSING |
| 617 | PSB10630617 | CAP SCREW 3/8-16 X 1-1/2 |
| 618 | PSB10630618 | DRAIN SCREEN |
| 619 | PSB10630619 | CAP SCREW 1/2-13 X 1-3/4 |
| 620 | PSB10630620 | GIB ADJUSTMENT SCREW |
| 621 | PSB10630621 | KNEE GIB (LH) |
| 622 | PSB10630622 | KNEE GIB PLATE (LH) |
| 623 | PSB10630623 | GIB PLATE SCREW |
| 624 | PSB10630624 | KNEE GIB (RH) |
| 625 | PSB10630625 | KNEE GIB PLATE (RH) |
| 626 | PSB10630626 | COLUMN WIPER (LH) |
| 627 | PSB10630627 | COLUMN WIPER (RH) |
| 628 | PSB10630628 | KNEE GIB (CENT) |
| 629 | PSB10630629 | HEX NUT 1/2-20 |
| 630 | PSB10630630 | HARD WASHER |
| 631 | PSB10630631 | BEVEL GEAR |
| 632 | PSB10630632 | SPACER |
| 633 | PSB10630633 | KNEE |
| 634 | PSB10630634 | KNEE LOCK HANDLE PLUNGER |
| 635 | PSB10630635 | ADJUSTABLE HANDLE |
| 636 | PSB10630636 | SET SCREW M6-1 X 8 |
| 637 | PSB10630637 | BEVEL PINION GEAR |
| 638 | PSB10630638 | BALL BEARING 6204ZZ |
| 639 | PSB10630639 | EXT RETAINING RING 20MM |
| 640 | PSB10630640 | KEY 4 X 4 X 20 RE |
| 641 | PSB10630641 | MOTOR 3-PH 220V [M2] |
| 642 | PSB10630642 | LOCK WASHER 8MM |
| 643 | PSB10630643 | CAP SCREW M8-1.25 X 25 |
| 644 | PSB10630644 | PHLP HD SCR M5-.8 X 8 |
| 645 | PSB10630645 | ELEVATION MOTOR COVER |
| 647 | PSB10630647 | FIXED HANDLE |

| REF | PART # | DESCRIPTION |
|-----|-------------|--|
| 648 | PSB10630648 | ELEVATION CRANK |
| 649 | PSB10630649 | FLAT WASHER 6MM |
| 650 | PSB10630650 | BUSHING |
| 651 | PSB10630651 | SET SCREW M6-1 X 6 |
| 652 | PSB10630652 | COMPRESSION SPRING |
| 653 | PSB10630653 | ELEVATION SHAFT CLUTCH |
| 654 | PSB10630654 | DIAL RETAINER (FR) |
| 655 | PSB10630655 | VERTICAL DIAL (INCH) |
| 656 | PSB10630656 | DIAL RETAINER (RR) |
| 657 | PSB10630657 | BEARING RETAINER |
| 658 | PSB10630658 | BEARING SEAT |
| 659 | PSB10630659 | KEY 4 X 4 X 15 RE |
| 660 | PSB10630660 | ELEVATION SHAFT |
| 661 | PSB10630661 | CHIP GUARD (TOP) |
| 662 | PSB10630662 | CHIP GUARD (MIDDLE) |
| 663 | PSB10630663 | CHIP GUARD (MIDDLE) |
| 664 | PSB10630664 | CHIP GUARD (BOTTOM) |
| 665 | PSB10630665 | KNEE COVER (FR) |
| 666 | PSB10630666 | SADDLE WIPER (RR) |
| 667 | PSB10630667 | SADDLE |
| 668 | PSB10630668 | SADDLE GIB |
| 669 | PSB10630669 | ADJUSTABLE HANDLE |
| 670 | PSB10630670 | SADDLE LOCK PLUNGER |
| 671 | PSB10630671 | SADDLE GIB PLATE (LH) |
| 672 | PSB10630672 | CAP SCREW M12-1.75 X 35 |
| 673 | PSB10630673 | SADDLE GIB |
| 674 | PSB10630674 | SADDLE GIB PLATE (RH) |
| 675 | PSB10630675 | HANDLE PLUNGER (LH) |
| 676 | PSB10630676 | HANDLE PLUNGER (RH) |
| 677 | PSB10630677 | SADDLE WIPER (FR) |
| 678 | PSB10630678 | HEX BOLT 3/4-10 X 4 |
| 679 | PSB10630679 | HEX NUT 3/4-10 |
| 680 | PSB10630680 | FOOT PAD |
| 681 | PSB10630681 | FLAT WASHER 6MM |
| 682 | PSB10630682 | CAP SCREW M6-1 X 10 |
| 683 | PSB10630683 | HEX NUT M5-.8 |
| 684 | PSB10630684 | FLAT WASHER 5MM |
| 685 | PSB10630685 | LIMIT SWITCH BRACKET (LH) |
| 686 | PSB10630686 | ELEV CRANK LIMIT SWITCH TZ-5109 [L58] |
| 687 | PSB10630687 | CAP SCREW M5-.8 X 40 |
| 688 | PSB10630688 | TRAVEL STOP BRACKET |
| 689 | PSB10630689 | CAP SCREW M5-.8-16 |
| 690 | PSB10630690 | LIMIT SWITCH BRACKET (RH) |
| 691 | PSB10630691 | CAP SCREW M5-.8-12 |
| 692 | PSB10630692 | LIMIT SWITCH MJ2-1308 [L59] AND [L510] |
| 693 | PSB10630693 | LIMIT SWITCH COVER |

Table




NOTE: Items shown are for reference purposes and all parts may not be available as single items.

Table Parts List

| REF | PART # | DESCRIPTION |
|-----|-------------|----------------------------|
| 701 | PSB10630701 | HEX NUT 1/2-20 |
| 702 | PSB10630702 | HANDWHEEL TYPE-3 W/HANDLE |
| 703 | PSB10630703 | OUTER DIAL RETAINER |
| 704 | PSB10630704 | DIAL SCALE |
| 705 | PSB10630705 | INNER DIAL RETAINR (LH) |
| 706 | PSB10630706 | PULLEY COVER (FR) |
| 707 | PSB10630707 | FLAT WASHER 5MM |
| 708 | PSB10630708 | CAP SCREW M5-.8 X10 |
| 709 | PSB10630709 | CAP SCREW M6-1 X 20 |
| 710 | PSB10630710 | BEARING RETAINER OUTER |
| 711 | PSB10630711 | RING KEY SGE 300 17X 21 |
| 712 | PSB10630712 | TIMING BELT |
| 713 | PSB10630713 | PULLEY WHEEL HTD5M44T-17 |
| 714 | PSB10630714 | BEARING LOCK NUT YSR M20-1 |
| 715 | PSB10630715 | SPACER |
| 716 | PSB10630716 | CAP SCREW M6-1 X 16 |
| 717 | PSB10630717 | INNER BEARING RETAINER |
| 718 | PSB10630718 | ANGULAR CONTACT BEARING |
| 719 | PSB10630719 | ROLL PIN |
| 720 | PSB10630720 | CAP SCREW 3/8-16 X 1 |
| 721 | PSB10630721 | CROSSFEED BEARING BRACKET |
| 722 | PSB10630722 | KEY 3 X 3 X 20 RE |
| 723 | PSB10630723 | LATERAL BALLSCREW |
| 724 | PSB10630724 | CAP SCREW M5-.8 X 20 |
| 725 | PSB10630725 | PULLEY WHEEL HTD5M22T-19 |
| 726 | PSB10630726 | RING KEY SGE 300 19 X 24 |
| 727 | PSB10630727 | BEARING RETAINER |
| 728 | PSB10630728 | CAP SCREW M8-1.25 X 25 |
| 729 | PSB10630729 | FLAT WASHER 8MM |
| 730 | PSB10630730 | MOTOR MOUNTING BRACKET |
| 731 | PSB10630731 | SERVO MOTER ECMA-C20807E5 |
| 732 | PSB10630732 | FLAT WASHER 6MM |
| 733 | PSB10630733 | COVER |

| REF | PART # | DESCRIPTION |
|-----|-------------|---------------------------------------|
| 734 | PSB10630734 | RUBBER TABLE T-SLOT PLUG |
| 735 | PSB10630735 | LONGITUDINAL BALLSCREW |
| 736 | PSB10630736 | CAP SCREW M10-1.5 X 30 |
| 737 | PSB10630737 | FEED NUT BRACKET |
| 738 | PSB10630738 | BEARING BRACKET |
| 739 | PSB10630739 | BALL BEARING 6204ZZ |
| 740 | PSB10630740 | EXT RETAINING RING 20MM |
| 741 | PSB10630741 | BALLSCREW COVER |
| 742 | PSB10630742 | PHLP HD SCR M6-1 X 16 |
| 743 | PSB10630743 | BELT BOX |
| 744 | PSB10630744 | CAP SCREW M8-1.25 X 30 |
| 745 | PSB10630745 | TIMING BELT |
| 746 | PSB10630746 | PULLEY COVER |
| 747 | PSB10630747 | INNER DIAL RETAINER (RH) |
| 748 | PSB10630748 | MOTOR MOUNTING BRACKET (RH) |
| 749 | PSB10630749 | MOTOR ADJUSTMENT BLOCK |
| 750 | PSB10630750 | HEX NUT M6-1 |
| 751 | PSB10630751 | CAP SCREW M6-1 X 35 |
| 752 | PSB10630752 | LOCK WASHER 6MM |
| 753 | PSB10630753 | MOTOR COVER |
| 754 | PSB10630754 | MOTOR ACCESS COVER |
| 755 | PSB10630755 | STOP DOG BRACKET |
| 756 | PSB10630756 | STOP DOG |
| 757 | PSB10630757 | CAP SCREW M6-1 X 12 |
| 758 | PSB10630758 | PHLP HD SCR M5-.8 X 10 |
| 759 | PSB10630759 | LIMIT SWITCH 0519HU, X=[LS1], Y=[LS2] |
| 760 | PSB10630760 | LIMIT SWITCH FIXED SEAT |
| 761 | PSB10630761 | THREADED PLATE |
| 762 | PSB10630762 | FLAT WASHER 10MM |
| 763 | PSB10630763 | CAP SCREW 3/8-16 X 1/2 |
| 764 | PSB10630764 | LIMIT SWITCH BRACKET (LH) |
| 765 | PSB10630765 | TABLE 12.5" X 58" |


Lubrication System and Parts List



| REF | PART # | DESCRIPTION |
|-----|-------------|----------------------------|
| 801 | PSB10630801 | ELBOW JOINT M4 X 1/8PT |
| 802 | PSB10630802 | STRAIGHT TUBE ADAPTER NO 3 |
| 803 | PSB10630803 | CAP SCREW M6-1 X 25 |
| 804 | PSB10630804 | TUBE T-ADAPTER 4 X 4MM |
| 805 | PSB10630805 | OIL DISTRIBUTOR (7 PORT) |
| 806 | PSB10630806 | CAP SCREW M6-1 X 20 |
| 807 | PSB10630807 | AUTO OILER ASSEMBLY |
| 809 | PSB10630809 | THREADED PLUG M8-1.25 |

| REF | PART # | DESCRIPTION |
|-----|-------------|------------------------------|
| 810 | PSB10630810 | OIL DISTRIBUTOR (10 PORT) |
| 811 | PSB10630811 | CAP SCREW M5-.8 X 25 |
| 819 | PSB10630819 | OIL LINE (SPINDLE SUPPLY) |
| 820 | PSB10630820 | OIL LINE (KNEE SUPPLY) |
| 821 | PSB10630821 | OIL LINE ASSY (TABLE SUPPLY) |
| 822 | PSB10630822 | PLASTIC OIL LINE |
| 823 | PSB10630823 | METAL OIL LINE |
| 824 | PSB10630824 | PUMP OUTPUT FITTING |


Coolant System



| REF | PART # | DESCRIPTION |
|-----|-------------|-------------------------------------|
| 901 | PSB10630901 | CAP SCREW M6-1 X 20 |
| 902 | PSB10630902 | FLAT WASHER 6MM |
| 903 | PSB10630903 | PUMP 1/8HP 220V1-PH [M1] |
| 904 | PSB10630904 | BARBED HOSE FITTING 3/8 PT X 1/2 IN |
| 905 | PSB10630905 | THREADED HOSE CLAMP 3/4 IN |
| 906 | PSB10630906 | COOLANT HOSE 1/2 X 50 IN |
| 907 | PSB10630907 | BARBED HOSE FITTING 3/8 PT X 1/2 IN |
| 908 | PSB10630908 | COOLANT NOZZLE BRACKET |
| 909 | PSB10630909 | CAP SCREW M5-.8 X 12 |


| REF | PART # | DESCRIPTION |
|-----|-------------|-----------------------------------|
| 910 | PSB10630910 | PIPE ELBOW 90 DEG 3/8 PT X 3/8 IN |
| 911 | PSB10630911 | COOLANT VALVE |
| 912 | PSB10630912 | COOLANT NOZZLE 3/8 X 30 IN |
| 913 | PSB10630913 | PIPE ELBOW 90 DEG 3/8 PT X 1/2 IN |
| 914 | PSB10630914 | COOLANT HOSE 1/2 X 72 IN |
| 915 | PSB10630915 | HOSE CLAMP 3/4 IN |
| 916 | PSB10630916 | SPLASH PAN |
| 917 | PSB10630917 | CAP SCREW M5-.8 X 10 |
| 918 | PSB10630918 | FLAT WASHER 5MM |

Main Electrical Box




NOTE: Non digital data cables are field-repaired items that use standard copper wire and crimp-type terminals.

Electrical Control Box (Internal)



NOTE: Non digital data cables are field-repaired items that use standard copper wire and crimp-type terminals.

Electrical Control Box (External)




Electrical Box & Control Panel Parts List

Note: The alpha-numeric equipment number is shown in [brackets] below directly link electrical part number to the exact electrical part shown on the wiring schematics in this manual.

| REF | PART # | DESCRIPTION |
|------|-------------|--|
| 1000 | PSB10631000 | MAIN ELECTRICAL BOX ASSEMBLY |
| 1001 | PSB10631001 | MAIN ELECTRICAL BOX (EMPTY) |
| 1002 | PSB10631002 | DELTA POWER SUPPLY (SETTING 4.5A) [PW1] |
| 1003 | PSB10631003 | SERVO DRIVE X, ASD-B2-0421-B [N1] |
| 1004 | PSB10631004 | SERVO DRIVE Y, ASD-B2-0421-B [N2] |
| 1005 | PSB10631005 | SERVO DRIVE Z, ASD-B2-0421-B [N3] |
| 1006 | PSB10631006 | COOLING FAN [M9], [M10] |
| 1007 | PSB10631007 | POWER SWITCH 220V 3PH-50A [QS1 + LS11] |
| 1008 | PSB10631008 | CONTACTOR 24V 50/60 HZ [KM1] |
| 1009 | PSB10631009 | RELAY [KM1] |
| 1010 | PSB10631010 | CONTACTOR 24V 50/60 HZ [KM2] |
| 1011 | PSB10631011 | THERMAL RELAY 415V (SET TO 0.25-0.4A) [F1] |
| 1012 | PSB10631012 | CONTACTOR 24V 50/60 HZ [KM3] |
| 1013 | PSB10631013 | THERMAL RELAY 415V (SET TO 0.63-1A) [F2] |
| 1014 | PSB10631014 | CONTACTOR 24V 50/60 HZ [KM4] |
| 1015 | PSB10631015 | CIRCUIT BREAKER HAGER MY210 C10A [FU1] |
| 1016 | PSB10631016 | CIRCUIT BREAKER HAGER MY210 C10A [FU2] |
| 1017 | PSB10631017 | CIRCUIT BREAKER HAGER MY106 C6A [FU3] |
| 1018 | PSB10631018 | RELAY 24VDC [KR1] |
| 1019 | PSB10631019 | RELAY 24VDC, 5A, 30VDC/250VAC [KR2] |
| 1020 | PSB10631020 | RELAY 24VDC, 5A, 30VDC/250VAC [KR3] |
| 1021 | PSB10631021 | RELAY 24VDC, 5A, 30VDC/250VAC [KR4] |
| 1022 | PSB10631022 | RELAY 24VDC, 10A, 30VDC/250VAC [K1-K24] |
| 1023 | PSB10631023 | TRANSFORMER 50/60HZ 1PH [T1] |
| 1024 | PSB10631024 | VFD INVERTER 3.7KW/5HP 230V, 3PH [N4] |
| 1025 | PSB10631025 | FUSE HOLDER 110-250 AC (5A FUSE) [FU4] |
| 1026 | PSB10631026 | FUSE HOLDER 10-30 AC/DC (5A FUSE) [FU5] |
| 1027 | PSB10631027 | FUSE HOLDER 10-30 AC/DC (5A FUSE) [FU6] |
| 1028 | PSB10631028 | RELAY BOARD, 24 SOCKET [PCB1] |
| 1029 | PSB10631029 | GROUNDING PLATE |
| 1030 | PSB10631030 | JUNCTION BLOCK |
| 1031 | PSB10631031 | JUNCTION BLOCK |
| 1032 | PSB10631032 | JUNCTION BLOCK |
| 1033 | PSB10631033 | JUNCTION BLOCK |
| 1034 | PSB10631034 | DATA CABLE (CNTRL PNL TO MAIN ELE BOX) |
| 1035 | PSB10631035 | DATA CABLE (CNTRL PNL TO MAIN ELE BOX) |
| 1036 | PSB10631036 | CIRCUIT BREAKER COMB BUSBAR GV2 G445 |
| 1037 | PSB10631037 | FUSE 5A, 5 X 20MM |
| 1038 | PSB10631038 | COMM CABLE X-SERVO X-AXIS [CN1] |
| 1039 | PSB10631039 | AC SERVO MOTOR CABLE X-AXIS [CN2] |
| 1040 | PSB10631040 | AC SERVO MOTOR CABLE Y-AXIS [CN1] |

| REF | PART # | DESCRIPTION |
|------|-------------|--|
| 1041 | PSB10631041 | AC SERVO MOTOR CABLE Y-AXIS [CN2] |
| 1042 | PSB10631042 | AC SERVO MOTOR CABLE Z-AXIS [CN1] |
| 1043 | PSB10631043 | AC SERVO MOTOR CABLE Z-AXIS [CN2] |
| 1044 | PSB10631044 | WIRE HARNESS X-SERVO |
| 1045 | PSB10631045 | WIRE HARNESS Y-SERVO |
| 1046 | PSB10631046 | WIRE HARNESS Z-SERVO |
| 1060 | PSB10631060 | CONTROL BOX ASSEMBLY |
| 1061 | PSB10631061 | CONTROL BOX (EMPTY) |
| 1062 | PSB10631062 | PANEL UNIT FP8055/55IK MCU5B, VERS 14A |
| 1063 | PSB10631063 | CONTROL PANEL MEMBRANE |
| 1064 | PSB10631064 | FAGOR UNIT CN55IF-MC-CK-AIX-B-4-ABEHAV |
| 1065 | PSB10631065 | USB DATA CABLE |
| 1066 | PSB10631066 | CAT-5 DATA CABLE |
| 1067 | PSB10631067 | DATA CABLE (X1 CONNECTION) |
| 1068 | PSB10631068 | 3-CORD DATA CABLE (X8 CONNECTION) |
| 1069 | PSB10631069 | DATA CABLE (CNC TO CNTRL PANEL) |
| 1070 | PSB10631070 | DATA CABLE (X5 CONNECTION) |
| 1071 | PSB10631071 | DATA CABLE (X12 CONNECTION) |
| 1072 | PSB10631072 | DATA CABLE (X4 CONNECTION) |
| 1073 | PSB10631073 | DATA CABLE (X11 CONNECTION) |
| 1074 | PSB10631074 | DATA CABLE (X10 CONNECTION) |
| 1075 | PSB10631075 | 4-CORD DATA CABLE (X2 CONNECTION) |
| 1076 | PSB10631076 | DATA CABLE FOR CANNON PLUG ITEM #1077 |
| 1077 | PSB10631077 | CANNON PLUG RECEPTACLE |
| 1078 | PSB10631078 | HAND-HELD CONTROLLER W/CORD |
| 1079 | PSB10631079 | SERIAL PORT RECEPTACLE |
| 1080 | PSB10631080 | CAT-5 PORT RECEPTACLE |
| 1081 | PSB10631081 | DATA CONNECTION HOUSING AND COVER |
| 1082 | PSB10631082 | FIXED HANDLE |
| 1083 | PSB10631083 | AXIS INTERFACE BOARD |
| 1084 | PSB10631084 | STATUS LIGHT TOWER [H1] |
| 1085 | PSB10631085 | JOG CONTROL RHEOSTAT |
| 1086 | PSB10631086 | FEED CONTROL RHEOSTAT |
| 1087 | PSB10631087 | PLAIN BUTTON SW [HPB4, HPB6, HPB8, HPB9] |
| 1088 | PSB10631088 | BUTTON SWITCH YELLOW [HPB5] |
| 1089 | PSB10631089 | MAN BUTTON SW W/SAFETY COVER [HPB7] |
| 1090 | PSB10631090 | SWITCH BUTTON SERVO [HPB3] |
| 1091 | PSB10631091 | SWITCH BUTTON W/GREEN LIGHT [HPB2] |
| 1092 | PSB10631092 | SWITCH BUTTON W/RED LIGHT [HPB1] |
| 1093 | PSB10631093 | SWITCH BUTTON EMERGENCY STOP [SPB1] |


Accessories



| REF | PART # | DESCRIPTION |
|------|-------------|--------------------------|
| 1101 | PSB10631101 | TOOL BOX |
| 1102 | PSB10631102 | SCREWDRIVER #2 FLAT TIP |
| 1103 | PSB10631103 | SCREWDRIVER #2 PHILLIPS |
| 1104 | PSB10631104 | WRENCH 12 X 14 OPEN-ENDS |

| REF | PART # | DESCRIPTION |
|------|-------------|------------------------------|
| 1105 | PSB10631105 | WRENCH 19 X 21 CLOSED ENDS |
| 1106 | PSB10631106 | HEX WRENCH 10PC SET 1.5-10MM |
| 1107 | PSB10631107 | OIL BOTTLE |

Machine Labels (Left)



MODEL SB1063
12" X 58" CNC Knee Mill

WARNING!

Read and understand owner's manual before operating.

1. Read and understand owner's manual before operating.
2. Always wear ANSI-approved safety glasses and a face shield.
3. Properly ground machine—connected to permanently grounded metal wiring system or an equipment-grounding conductor.
4. Disconnect power before setting up, adjusting, or servicing.
5. Properly set up machine before starting.
6. DO NOT remove any electronic safety or limit switches.
7. Avoid getting entangled in moving parts—roll back long hair, roll up long sleeves, and DO NOT wear loose clothing, gloves, or jewelry.
8. Keep all guards and covers in place during operation.
9. Always remove adjustment tools before starting.
10. Always use a clamp or vice to secure workpiece to table during operation.
11. Never attempt to slow or stop spindle with hands or tools.
12. Always use proper feeds and speeds for operation and workpiece.
13. Never leave machine running unattended.
14. Always use a brush or vacuum to remove metal chips; DO NOT use your hands, rag, or compressed air.
15. DO NOT operate when tired or under influence of drugs or alcohol.
16. DO NOT operate in rain or wet locations.
17. Prevent unauthorized use by children or untrained users; restrict access or disable machine when unattended.

Spindle Motor: 3 HP, 230V, 3-Phase, 60 Hz
Full-Load Current Rating: 22A
Longitudinal Table Travel: 30" Z"
Cross Table Travel (T): 15-5/8"
Vertical Table Travel (Z): 16.5"
Max. Distance Spindle to Column: 27"
Max. Distance Spindle to Table: 117"
Spindle Feed Rate (V): 7, 21, 192, 118 IPM
Spindle Power: NF40
Spindle Speeds: Variable, 50-5000 RPM
Coolant Capacity: 25 Liters
Weight: 2314 lbs.


_____ S/N
_____ Date

Made in Mexico by South Bend Manufacturing

! WARNING

The safety labels provided with your machine are used to make the operator aware of the machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of these safety labels. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact South Bend Lathe Co. at (360) 734-1540 or www.southbendlathe.com to order new labels.

Machine Labels (Right)



| REF | PART # | DESCRIPTION |
|------|-------------|--------------------------|
| 1201 | PSB10631201 | ENTANGLEMENT LABEL |
| 1202 | PSB10631202 | DIRECTION ARROW LABEL |
| 1203 | PSB10631203 | FACESHIELD/GLASSES LABEL |
| 1204 | PSB10631204 | READ MANUAL LABEL |
| 1206 | PSB10631206 | MACHINE ID LABEL |
| 1209 | PSB10631209 | POWER LABEL |
| 1210 | PSB10631210 | DOOR CLOSED LABEL |
| 1211 | PSB10631211 | DRAWBAR SWITCH FACEPLATE |
| 1212 | PSB10631212 | AIR CONNECTION LABEL |

| REF | PART # | DESCRIPTION |
|------|-------------|-------------------------------|
| 1213 | PSB10631213 | MODEL NUMBER LABEL |
| 1214 | PSB10631214 | TOUCH-UP PAINT, SB DARK BLUE |
| 1215 | PSB10631215 | TOUCH-UP PAINT, SB LIGHT BLUE |
| 1216 | PSB10631216 | TOUCH-UP PAINT, SB GRAY |
| 1217 | PSB10631217 | SOUTH BEND NAMEPLATE |
| 1218 | PSB10631218 | ELECTRICITY LABEL |
| 1219 | PSB10631219 | SPINDLE SPEED RANGE LABEL |
| 1222 | PSB10631222 | BIOHAZARD LABEL |
| 1223 | PSB10631223 | FLUID CAPACITIES LABEL |

WARRANTY

This quality product is warranted by South Bend Lathe Company to the original buyer for one year from the date of purchase. This warranty does not apply to consumable parts, or defects due to any kind of misuse, abuse, negligence, accidents, repairs, alterations or lack of maintenance. We do not reimburse for third party repairs. In no event shall we be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our products.

We do not warrant or represent that this machine complies with the provisions of any law, act, code, regulation, or standard of any domestic or foreign government, industry, or authority. In no event shall South Bend's liability under this warranty exceed the original purchase price paid for this machine. Any legal actions brought against South Bend Lathe Company shall be tried in the State of Washington, County of Whatcom.

This is the sole written warranty for this machine. Any and all warranties that may be implied by law, including any merchantability or fitness, for any purpose, are hereby limited to the duration of this warranty. To take advantage of this warranty, contact us by mail or phone to give us the details of the problem you are having.

Thank you for your business and continued support.



southbendlathe.com

