

Hemp Spacing Chart



SPACING CHART FOR DIRECT DRIVE UNIT WITH 3 POCKET CHAIN						
Sprocket on OUTSIDE of Jackshaft	Sprocket on INSIDE of Jackshaft	Number of Teeth on Sprocket on Unit				
		7	8	9	10	11
7	11	24"	28"	32"	34"	36"
7	7	36"	42"	52"	60"	64"
8	7	42"	50"	56"	60"	64"
9	7	48"	54"	60"	68"	74"
10	7	52"	56"	62"	70"	82"
11	7	60"	72"	80"	88"	96"
Make sure HITCH and UNIT are level or parallel to the ground when planting						

Mechanical Transplanter Co.

1150 Central Ave, Holland, MI 49423 * Phone 616-396-8738 * Fax 616-396-3619

Website: www.mechanicaltransplanter.com